


# 2016 PARTS CATALOG

 **TOHATSU**



## BFT 115A

**OB NO.002-13ZX1-0AF  
1510EU/EX**



# Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of October 1, 2015.**
- See the Service Bulletin for any revision that is made after October 1, 2015.
- **Always specify the part number when ordering a part.**
  - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
  - Note that the illustrations (part drawings) can differ from the actual parts in shape.  
Illustrations are given just to help you to refer to the parts.
- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times.**



**Initial version issue date October 1, 2015**

## CONTENTS

|                            |                                                      |     |
|----------------------------|------------------------------------------------------|-----|
| E-1                        | CYLINDER HEAD COVER .....                            | 1   |
| E-3                        | CYLINDER BLOCK .....                                 | 3   |
| E-4                        | EXHAUST PIPE .....                                   | 7   |
| E-4-10                     | WATER HOSE .....                                     | 9   |
| E-5                        | OIL PUMP/FLYWHEEL .....                              | 11  |
| E-6                        | OIL PAN .....                                        | 13  |
| E-7                        | CRANKSHAFT/PISTON .....                              | 15  |
| E-9                        | CAMSHAFT/VALVE .....                                 | 19  |
| E-9-10                     | CHAIN CASE/THERMOSTAT .....                          | 23  |
| E-9-20                     | CYLINDER HEAD .....                                  | 25  |
| E-10                       | BALANCER SHAFT .....                                 | 29  |
| E-13                       | A.C.G BELT/SILENCER DUCT .....                       | 31  |
| E-14                       | INTAKE MANIFOLD/INJECTOR .....                       | 33  |
| E-15                       | THROTTLE BODY .....                                  | 37  |
| E-18                       | FUEL PUMP/FUEL HOSE .....                            | 39  |
| E-18-1                     | WATER SEPARATOR .....                                | 43  |
| E-18-10                    | VAPOR SEPARATOR ASSY .....                           | 45  |
| E-19                       | A.C.GENERATOR .....                                  | 49  |
| E-20                       | IGNITION COIL/SPARK PLUG .....                       | 53  |
| E-20-10                    | ELECTRONIC CONTROL UNIT .....                        | 55  |
| E-21                       | STARTER MOTOR .....                                  | 57  |
| F-2                        | SHIFT SHAFT .....                                    | 61  |
| F-3                        | GEAR CASE .....                                      | 65  |
| F-3-10                     | GEAR CASE ASSY .....                                 | 67  |
| F-3-20                     | EXTENSION CASE .....                                 | 69  |
| F-4                        | WATER PUMP/VERTICAL SHAFT .....                      | 71  |
| F-5                        | PROPELLER SHAFT/PROPELLER (LD/LU/XU) .....           | 75  |
| F-6                        | FUEL TUBE .....                                      | 79  |
| F-7                        | WIRE HARNESS .....                                   | 81  |
| F-7-10                     | STARTER CABLE .....                                  | 83  |
| F-7-20                     | FUSE BOX/RELAY .....                                 | 85  |
| F-7-30                     | CLAMP .....                                          | 87  |
| F-8                        | ENGINE COVER ASSY .....                              | 89  |
| F-8-10                     | FR.COVER BRACKET/FR.LOCK .....                       | 91  |
| F-8-20                     | UNDER COVER .....                                    | 95  |
| F-9                        | MOUNT CASE .....                                     | 97  |
| F-10                       | STERN BRACKET/SWIVEL CASE .....                      | 101 |
| F-11                       | POWER TRIM-TILT .....                                | 107 |
| F-12                       | LABELS .....                                         | 111 |
| F-13                       | TOOLS .....                                          | 113 |
| FOP-1                      | RIGGING HOSE KIT .....                               | 115 |
| FOP-2                      | METER .....                                          | 117 |
| FOP-6                      | CONTROL PANEL (1) .....                              | 119 |
| FOP-6-1                    | CONTROL PANEL (2) .....                              | 121 |
| FOP-7                      | TRIM ADJUST PLATE SET .....                          | 123 |
| FOP-8                      | REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT) ..... | 125 |
| FOP-8-2                    | REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT) .....   | 129 |
| FOP-8-4                    | REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT) .....      | 133 |
| FOP-8-6                    | REMOTE CONTROL .....                                 | 135 |
| FOP-9                      | BOLT KIT .....                                       | 141 |
| FOP-10                     | WATER PUMP IMPELLER KIT (1) .....                    | 143 |
| FOP-10-1                   | WATER PUMP IMPELLER KIT (2) .....                    | 145 |
| FOP-11                     | INTERFACE CABLE KIT .....                            | 147 |
| FOP-12                     | TROLLING CONTROL SWITCH .....                        | 149 |
| FOP-13                     | SPEED SENSOR TUBE KIT .....                          | 151 |
| INDEX .....                |                                                      | 153 |
| INDEX (Parts Number) ..... |                                                      | 159 |

## How to refer to the part information

### A. Reference with “Illustrated index”

**Fig. Number**

**Ref. Number/Part Number/Parts Name**

| Ref No. | Part No. | Description      | O'ry<br>BFT11A               | Remarks |
|---------|----------|------------------|------------------------------|---------|
| [=1]    | 1        | H2YB-12310-0102A | COVER COMP, CYLINDER HEAD    | 1       |
| [=1]    | 2        | HPN6-11234-000   | PACKING, CYLINDER HEAD COVER | 1       |
| [=1]    | 3        | HPIC-112345-004  | SEAL, SPARK PLUG TUBEMOD     | 4       |
| [=1]    | 4        | H2YB-12300-000   | COVER COMP, PLUG HOLE COIL   | 1       |
| [=1]    | 5        | H2YB-00034-000   | BOLT, SOCKET, 8X25           | 2       |
| [=1]    | 6        | H2YB-00031-000   | NUT, FLANGE CAP, 8MM         | 6       |
| [=1]    | 7        | H2YB-00461-000   | WASHER, HEAD COVER           | 6       |


### B. Reference with “Parts number index”

| INDEX (Parts Number) |       |           |         |
|----------------------|-------|-----------|---------|
| 100015154            | 15-15 | 100048854 | 1184-10 |
| 100015155            | 15-15 | 100048855 | 1184-10 |
| 100000015            | 5-10  | 100048856 | 1184-10 |
| 100000016            | 5-10  | 100048857 | 1184-10 |
| 100000017            | 5-10  | 100048858 | 1184-10 |
| 100000018            | 5-10  | 100048859 | 1184-10 |
| 100000019            | 5-10  | 100048860 | 1184-10 |
| 100000020            | 5-10  | 100048861 | 1184-10 |
| 100000021            | 5-10  | 100048862 | 1184-10 |
| 100000022            | 5-10  | 100048863 | 1184-10 |
| 100000023            | 5-10  | 100048864 | 1184-10 |
| 100000024            | 5-10  | 100048865 | 1184-10 |
| 100000025            | 5-10  | 100048866 | 1184-10 |
| 100000026            | 5-10  | 100048867 | 1184-10 |
| 100000027            | 5-10  | 100048868 | 1184-10 |
| 100000028            | 5-10  | 100048869 | 1184-10 |
| 100000029            | 5-10  | 100048870 | 1184-10 |
| 100000030            | 5-10  | 100048871 | 1184-10 |
| 100000031            | 5-10  | 100048872 | 1184-10 |
| 100000032            | 5-10  | 100048873 | 1184-10 |
| 100000033            | 5-10  | 100048874 | 1184-10 |
| 100000034            | 5-10  | 100048875 | 1184-10 |
| 100000035            | 5-10  | 100048876 | 1184-10 |
| 100000036            | 5-10  | 100048877 | 1184-10 |
| 100000037            | 5-10  | 100048878 | 1184-10 |
| 100000038            | 5-10  | 100048879 | 1184-10 |
| 100000039            | 5-10  | 100048880 | 1184-10 |
| 100000040            | 5-10  | 100048881 | 1184-10 |
| 100000041            | 5-10  | 100048882 | 1184-10 |
| 100000042            | 5-10  | 100048883 | 1184-10 |
| 100000043            | 5-10  | 100048884 | 1184-10 |
| 100000044            | 5-10  | 100048885 | 1184-10 |
| 100000045            | 5-10  | 100048886 | 1184-10 |
| 100000046            | 5-10  | 100048887 | 1184-10 |
| 100000047            | 5-10  | 100048888 | 1184-10 |
| 100000048            | 5-10  | 100048889 | 1184-10 |
| 100000049            | 5-10  | 100048890 | 1184-10 |
| 100000050            | 5-10  | 100048891 | 1184-10 |
| 100000051            | 5-10  | 100048892 | 1184-10 |
| 100000052            | 5-10  | 100048893 | 1184-10 |
| 100000053            | 5-10  | 100048894 | 1184-10 |
| 100000054            | 5-10  | 100048895 | 1184-10 |
| 100000055            | 5-10  | 100048896 | 1184-10 |
| 100000056            | 5-10  | 100048897 | 1184-10 |
| 100000057            | 5-10  | 100048898 | 1184-10 |
| 100000058            | 5-10  | 100048899 | 1184-10 |
| 100000059            | 5-10  | 100048900 | 1184-10 |
| 100000060            | 5-10  | 100048901 | 1184-10 |
| 100000061            | 5-10  | 100048902 | 1184-10 |
| 100000062            | 5-10  | 100048903 | 1184-10 |
| 100000063            | 5-10  | 100048904 | 1184-10 |
| 100000064            | 5-10  | 100048905 | 1184-10 |
| 100000065            | 5-10  | 100048906 | 1184-10 |
| 100000066            | 5-10  | 100048907 | 1184-10 |
| 100000067            | 5-10  | 100048908 | 1184-10 |
| 100000068            | 5-10  | 100048909 | 1184-10 |
| 100000069            | 5-10  | 100048910 | 1184-10 |
| 100000070            | 5-10  | 100048911 | 1184-10 |
| 100000071            | 5-10  | 100048912 | 1184-10 |
| 100000072            | 5-10  | 100048913 | 1184-10 |
| 100000073            | 5-10  | 100048914 | 1184-10 |
| 100000074            | 5-10  | 100048915 | 1184-10 |
| 100000075            | 5-10  | 100048916 | 1184-10 |
| 100000076            | 5-10  | 100048917 | 1184-10 |
| 100000077            | 5-10  | 100048918 | 1184-10 |
| 100000078            | 5-10  | 100048919 | 1184-10 |
| 100000079            | 5-10  | 100048920 | 1184-10 |
| 100000080            | 5-10  | 100048921 | 1184-10 |
| 100000081            | 5-10  | 100048922 | 1184-10 |
| 100000082            | 5-10  | 100048923 | 1184-10 |
| 100000083            | 5-10  | 100048924 | 1184-10 |
| 100000084            | 5-10  | 100048925 | 1184-10 |
| 100000085            | 5-10  | 100048926 | 1184-10 |
| 100000086            | 5-10  | 100048927 | 1       |

### C. Reference with “Parts name index”


[illegible]

## Part catalogue structure



- ① Fig. Number
- ② Fig. Title
- ③ Ref. Number
- ④ Parts Number
- ⑤ Parts Name
- ⑥ Q.ty
- ⑦ Remarks
- ⑧ Defferent specification
- ⑨ Direction Arrow
- ⑩ Parts enclosed within a dotted line are sub assembly parts.
- ⑪ A solid arrow indicates the block No. the part in question is connected to.

## How to check the part block and serial numbers



## Models, parts catalogue codes and applicable serial numbers

- Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

| Model    | Type | Parts catalogue type | Engine   |      | Applicable engine serial No. | Applicable frame serial No. |
|----------|------|----------------------|----------|------|------------------------------|-----------------------------|
|          |      |                      | Model    | Type |                              |                             |
| BFT 115A | LD   | LD                   | BFT 115D | SE1  | BEBHJ-1000001~               | BBHJ-6000079~               |
|          | LU   | LU                   |          |      |                              |                             |
|          | XU   | XU                   |          |      |                              |                             |

## Features of each type

- See the following table for the features of each type. (Items in brackets are optional)


| Specifications |             | Model | BFT 115A |     |     |
|----------------|-------------|-------|----------|-----|-----|
|                |             | Type  | LD       | LU  | XU  |
| Transom height | 508 mm      |       | ●        | ●   |     |
|                | 635 mm      |       |          |     | ●   |
| Propeller      | 14-1/2 x 15 |       | (●)      | (●) | (●) |
|                | 14-1/4 x 17 |       | (●)      | (●) | (●) |
|                | 14 x 19     |       | (●)      | (●) | (●) |
|                | 14 x 21     |       | (●)      | (●) | (●) |
|                | 14-1/2 x 23 |       | (●)      | (●) | (●) |
|                | 14 x 25     |       | (●)      | (●) | (●) |
|                | 15-1/2 x 13 |       | (●)      | (●) | (●) |
|                | 15-1/4 x 15 |       | (●)      | (●) | (●) |
|                | 15 x 17     |       | (●)      | (●) | (●) |
|                | 14-3/4 x 19 |       | (●)      | (●) | (●) |
|                | 14-1/2 x 21 |       | (●)      | (●) | (●) |
|                | 14-1/4 x 23 |       | (●)      | (●) | (●) |

## Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets ( ) underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name. (For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

### Bulk part number of fuel hose, general purpose hose and vinyl hose.


Example: 95001-75001-50M




### CAUTION: It is DANGEROUS to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.


E-1 CYLINDER HEAD COVER




E-3 CYLINDER BLOCK




E-4 EXHAUST PIPE




E-4-10 WATER HOSE




E-5 OIL PUMP/FLYWHEEL




E-6 OIL PAN




E-7 CRANKSHAFT/PISTON




E-9 CAMSHAFT/VALVE




E-9-10 CHAIN CASE/THERMOSTAT




**E-9-20 CYLINDER HEAD**




**E-10 BALANCER SHAFT**




**E-13 A.C.G BELT/SILENCER DUCT**




**E-14 INTAKE MANIFOLD/INJECTOR**




**E-15 THROTTLE BODY**




**E-18 FUEL PUMP/FUEL HOSE**




**E-18-1 WATER SEPARATOR**




**E-18-10 VAPOR SEPARATOR ASSY**




**E-19 A.C.GENERATOR**




E-20 IGNITION COIL/SPARK PLUG




E-20-10 ELECTRONIC CONTROL UNIT




E-21 STARTER MOTOR




F-2 SHIFT SHAFT




F-3 GEAR CASE




F-3-10 GEAR CASE ASSY




F-3-20 EXTENSION CASE




F-4 WATER PUMP/VERTICAL SHAFT




F-5 PROPELLER SHAFT/PROPELLER (LD/LU/XU)




F-6 FUEL TUBE




F-7 WIRE HARNESS




F-7-10 STARTER CABLE




F-7-20 FUSE BOX/RELAY




F-7-30 CLAMP




F-8 ENGINE COVER ASSY




F-8-10 FR.COVER BRACKET/FR.LOCK




F-8-20 UNDER COVER




F-9 MOUNT CASE




F-10 STERN BRACKET/SWIVEL CASE




F-11 POWER TRIM-TILT




F-12 LABELS






F-13 TOOLS




FOP-1 RIGGING HOSE KIT




FOP-2 METER





FOP-6 CONTROL PANEL (1)




FOP-6-1 CONTROL PANEL (2)




FOP-7 TRIM ADJUST PLATE SET




**FOP-8 REMOTE CONTROL  
(TOP MOUNT SINGLE TYRE) (RIGHT)**




**FOP-8-2 REMOTE CONTROL  
(TOP MOUNT DUAL TYRE) (RIGHT)**




**FOP-8-4 REMOTE CONTROL  
(FLUSH MOUNT TYRE) (RIGHT)**




**FOP-8-6 REMOTE CONTROL**




**FOP-9 BOLT KIT**




**FOP-10 WATER PUMP IMPELLER KIT (1)**




**FOP-10-1 WATER PUMP IMPELLER KIT (2)**




**FOP-11 INTERFACE CABLE KIT**




**FOP-12 TROLLING CONTROL SWITCH**




# FOP-13 SPEED SENSOR TUBE KIT






FR. 






| Ref.No. |    | Part No.         | Description               | Q' ty   | Remarks         |
|---------|----|------------------|---------------------------|---------|-----------------|
|         |    |                  |                           | BFT115A |                 |
| E-3     | 1  | HZY6-11100-405   | CRANKCASE COMP.           | 1       |                 |
| E-3     | 2  | HPNA-11106-300   | BOLT, SEALING, 20MM       | 1       |                 |
| E-3     | 3  | HPR4-11106-013   | BOLT, SEALING, 28MM       | 1       |                 |
| E-3     | 4  | HPNA-11135-000   | ORIFICE, LOWER BLOCK      | 1       |                 |
| E-3     | 5  | HZY6-11911-000   | HANGER, ENGINE            | 2       |                 |
| E-3     | 6  | HZY6-12000-415ZA | BLOCK ASSY., CYLINDER     | 1       | *NH8* DARK GRAY |
| E-3     | 7  | HZV5-12214-000   | WASHER, SEALING(22MM)     | 1       |                 |
| E-3     | 8  | HZY6-15152-000   | ORIFICE, OIL JET          | 1       |                 |
| E-3     | 9  | HPRB-15280-A00   | BODY COMP., OIL JET       | 2       |                 |
| E-3     | 10 | HPRA-15290-000   | BOLT COMP., OIL JET       | 2       |                 |
| E-3     | 11 | HZY6-15299-000   | BOLT-WASHER, 8X10         | 2       |                 |
| E-3     | 12 | H921-15611-000   | CAP, OIL(YELLOW)          | 1       |                 |
| E-3     | 13 | HZY6-30530-003   | SENSOR ASSY., KNOCK       | 1       |                 |
| E-3     | 14 | HZW9-32114-730   | BRACKET, CLIP B           | 1       |                 |
| E-3     | 15 | HZY6-32114-010   | BRACKET D, HARNESS CLIP   | 1       |                 |
| E-3     | 16 | HZY3-35673-003   | SENSOR ASSY., WATER       | 1       | TEMPERATURE     |
| E-3     | 17 | HRNA-37260-A01   | SENSOR, OIL PRESSURE      | 1       |                 |
| E-3     | 18 | HZY6-38552-000   | BRACKET, RELAY            | 1       |                 |
| E-3     | 19 | HZY6-90001-000   | BOLT, FLANGE, 8X55        | 2       |                 |
| E-3     | 20 | HZY6-90005-000   | BOLT, FLANGE, 12X83       | 1       |                 |
| E-3     | 21 | HPNA-90006-003   | BOLT-WASHER, 11X95        | 10      |                 |
| E-3     | 22 | HZW9-90011-000   | BOLT, FLANGE, 6X14(CT200) | 7       |                 |
| E-3     | 23 | HZW9-90016-000   | BOLT, FLANGE, 6X25        | 18      |                 |
| E-3     | 24 | HZY3-90026-000   | BOLT, FLANGE, 8X20        | 4       |                 |
| E-3     | 25 | HZY3-90054-000   | BOLT, FLANGE, 8X35        | 10      |                 |
| E-3     | 26 | HZV5-90081-010   | BOLT, SEALING, 22MM       | 1       |                 |
| E-3     | 27 | HZY6-90082-003   | CAP, BOLT, 8MM            | 1       |                 |
| E-3     | 28 | HZW4-90156-000   | BOLT, FLANGE, 8X50        | 4       |                 |
| E-3     | 29 | HZW4-90162-000   | BOLT, FLANGE, 10X70       | 1       |                 |




[illegible]


E-4 EXHAUST PIPE









[illegible]




| Ref.No. |    | Part No.           | Description              | Q'ty    | Remarks         |
|---------|----|--------------------|--------------------------|---------|-----------------|
|         |    |                    |                          | BFT115A |                 |
| E-5     | 1  | HZW1-12217-010     | BOLT, SEALING, 20MM      | 2       |                 |
| E-5     | 2  | HZY6-15100-000ZA   | PUMP ASSY., OIL          | 1       | *NH8* DARK GRAY |
| E-5     | 3  | HZY6-15112-000     | PACKING, OIL PUMP BODY   | 1       |                 |
| E-5     | 4  | HZY6-15121-000     | COVER, OIL PUMP          | 1       |                 |
| E-5     | 5  | HPE0-15231-000     | VALVE, RELIEF            | 1       |                 |
| E-5     | 6  | HPG6-15232-000     | SPRING, RELIEF VALVE     | 1       |                 |
| E-5     | 7  | HPC6-15233-000     | BOLT, SEALING, 18MM      | 1       |                 |
| E-5     | 8  | HZW5-15331-003     | ROTOR, INNER OIL PUMP    | 1       |                 |
| E-5     | 9  | HZW5-15341-003     | ROTOR, OUTER OIL PUMP    | 1       |                 |
| E-5     | 10 | HRTA-15400-004     | CARTRIDGE, OIL FILTER    | 1       | (TOYO ROKI)     |
| E-5     | 11 | HZY6-15410-010ZA   | FLANGE COMP., OIL FILTER | 1       | *NH8* DARK GRAY |
| E-5     | 12 | HZY6-31110-000ZA   | FLYWHEEL COMP.           | 1       | *TBLACK* BLACK  |
| E-5     | 13 | HZY3-31116-000     | BOSS, FLYWHEEL           | 1       |                 |
| E-5     | 14 | HZW5-90002-013     | BOLT, SPECIAL, 8MM       | 8       |                 |
| E-5     | 15 | HPH3-90011-000     | BOLT, FLANGE, 12MM       | 8       |                 |
| E-5     | 16 | HPH1-90015-013     | HOLDER, OIL FILTER       | 1       |                 |
| E-5     | 17 | HZW9-90016-000     | BOLT, FLANGE, 6X25       | 4       |                 |
| E-5     | 18 | HZW5-90018-000     | BOLT, FLANGE, 6X20       | 1       |                 |
| E-5     | 19 | HZV5-90081-010     | BOLT, SEALING, 22MM      | 2       |                 |
| E-5     | 20 | HZW5-91201-003     | OIL SEAL, 46X60X9        | 1       |                 |
| E-5     | 21 | HP01-91212-003     | OIL SEAL, 31X46X7(NOK)   | 1       |                 |
| E-5     | 22 | HVD6-91360-003     | O-RING, 22.5X2.4         | 2       |                 |
| E-5     | 23 | HCO-93600-06016-0A | SCREW, FLAT, 6X16        | 9       |                 |
| E-5     | 24 | HCO-94109-20000    | WASHER, DRAIN PLUG, 20MM | 2       |                 |
| E-5     | 25 | HCO-94301-10160    | DOWEL PIN, 10X16         | 1       |                 |
| E-5     | 26 | HCO-94301-14200    | DOWEL PIN, 14X20         | 1       |                 |
| E-5     | 27 | HCO-95701-08032-08 | BOLT, FLANGE, 8X32       | 5       |                 |
| E-5     | 28 | HCO-96220-50080    | ROLLER, 5X8              | 2       |                 |
|         |    |                    |                          |         |                 |



| Ref.No. |    | Part No.           | Description              | Q' ty   | Remarks      |
|---------|----|--------------------|--------------------------|---------|--------------|
|         |    |                    |                          | BFT115A |              |
| E-6     | 1  | HZY6-11321-010ZB   | CASE, OIL                | 1       | *TGRAY* GRAY |
| E-6     | 2  | HZY6-11381-010     | PACKING, OIL PAN         | 1       |              |
| E-6     | 3  | HZW5-15113-000     | RUBBER, OIL PUMP         | 1       |              |
| E-6     | 4  | HZY6-15220-010     | STRAINER COMP., OIL      | 1       |              |
| E-6     | 5  | HZY6-15655-000     | GAUGE COMP., OIL LEVEL   | 1       |              |
| E-6     | 6  | HZW1-19252-000     | GROMMET, WATER TUBE      | 1       |              |
| E-6     | 7  | HZY6-19254-000     | PLATE, WATER TUBE        | 1       |              |
| E-6     | 8  | HZY6-23172-000     | GASKET, MOUNT CASE       | 1       |              |
| E-6     | 9  | HZY6-90002-000     | BOLT, FLANGE, 10X40      | 16      |              |
| E-6     | 10 | HZY6-90017-000     | BOLT, FLANGE, 10X80      | 1       |              |
| E-6     | 11 | HZY6-90018-000     | BOLT, HEX., 12X70        | 1       |              |
| E-6     | 12 | HZY6-90019-000     | BOLT, HEX., 12X130       | 2       |              |
| E-6     | 13 | HZY3-90046-000     | BOLT, FLANGE, 8X100      | 1       |              |
| E-6     | 14 | HZW9-90102-000     | BOLT, FLANGE, 6X12       | 1       |              |
| E-6     | 15 | HZV5-90131-000     | BOLT, DRAIN PLUG         | 1       |              |
| E-6     | 16 | HZV5-90559-000     | WASHER, PLAIN, 12MM      | 3       |              |
| E-6     | 17 | HZE2-90601-000     | WASHER, DRAIN PLUG, 12MM | 1       |              |
| E-6     | 18 | HPC6-91324-000     | O-RING, 20.6X2.6         | 1       |              |
| E-6     | 19 | HCO-94301-06100    | DOWEL PIN, 6X10          | 2       |              |
| E-6     | 20 | HCO-94301-10160    | DOWEL PIN, 10X16         | 1       |              |
| E-6     | 21 | HCO-94301-14200    | DOWEL PIN, 14X20         | 1       |              |
| E-6     | 22 | HCO-95701-06018-09 | BOLT, FLANGE, 6X18       | 2       |              |
| E-6     | 23 | HCO-95701-10110-09 | BOLT, FLANGE, 10X110     | 2       |              |
|         |    |                    |                          |         |              |
|         |    |                    |                          |         |              |
|         |    |                    |                          |         |              |
|         |    |                    |                          |         |              |
|         |    |                    |                          |         |              |
|         |    |                    |                          |         |              |
|         |    |                    |                          |         |              |




| Ref.No. |    | Part No.       | Description                    | Q' ty   | Remarks   |
|---------|----|----------------|--------------------------------|---------|-----------|
|         |    |                |                                | BFT115A |           |
| E-7     | 1  | HZY6-13010-000 | RING SET, PISTON(STD.)         | 4       |           |
| E-7     | 2  | HZY6-13101-000 | PISTON A                       | 4       |           |
| E-7     | 2  | HZY6-13102-000 | PISTON B                       | 4       |           |
| E-7     | 3  | HPNA-13111-010 | PIN, PISTON                    | 4       |           |
| E-7     | 4  | HP5A-13115-000 | CLIP, PISTON PIN               | 8       |           |
| E-7     | 5  | HP8A-13204-A01 | BOLT, CONNECTING ROD           | 8       | #~1005879 |
| E-7     | 5  | HRBB-13204-004 | BOLT, CONNECTING ROD           | 8       | #1005880~ |
| E-7     | 6  | HPPA-13210-000 | ROD COMP., CONNECTING          | 4       | #~1005879 |
| E-7     | 6  | HR40-13210-A00 | ROD COMP., CONNECTING          | 4       | #1005880~ |
| E-7     | 7  | HZY6-13211-004 | BEARING A, CONNECTING ROD      | 8       | (BLUE)    |
| E-7     | 7  | HZY6-13212-004 | BEARING B, CONNECTING ROD      | 8       | (BLACK)   |
| E-7     | 7  | HZY6-13213-004 | BEARING C, CONNECTING ROD      | 8       | (BROWN)   |
| E-7     | 7  | HZY6-13214-004 | BEARING D, CONNECTING ROD      | 8       | (GREEN)   |
| E-7     | 7  | HZY6-13215-004 | BEARING E, CONNECTING ROD      | 8       | (YELLOW)  |
| E-7     | 7  | HZY6-13216-004 | BEARING F, CONNECTING ROD      | 8       | (PINK)    |
| E-7     | 7  | HZY6-13217-004 | BEARING G, CONNECTING ROD(RED) | 8       | (RED)     |
| E-7     | 8  | HPPA-13310-000 | CRANKSHAFT COMP.               | 1       | #~1005879 |
| E-7     | 8  | HR40-13210-A00 | CRANKSHAFT COMP.               | 1       | #1005880~ |
| E-7     | 9  | HPNA-13321-003 | BEARING A, MAIN UPPER(BLUE)    | 5       | (DAIDO)   |
| E-7     | 9  | HPNA-13322-003 | BEARING B, MAIN UPPER(BLACK)   | 5       | (DAIDO)   |
| E-7     | 9  | HPNA-13323-003 | BEARING C, MAIN UPPER(BROWN)   | 5       | (DAIDO)   |
| E-7     | 9  | HPNA-13324-003 | BEARING D, MAIN UPPER(GREEN)   | 5       | (DAIDO)   |
| E-7     | 9  | HPNA-13325-003 | BEARING E, MAIN UPPER(YELLOW)  | 5       | (DAIDO)   |
| E-7     | 9  | HPNA-13326-003 | BEARING F, MAIN UPPER(PINK)    | 5       | (DAIDO)   |
| E-7     |    |                |                                |         |           |
| E-7     | 10 | HZY6-13331-013 | WASHER, THRUST                 | 2       |           |
| E-7     | 11 | HPNA-13341-003 | BEARING A, MAIN LOWER(BLUE)    | 5       | (DAIDO)   |
| E-7     | 11 | HPNA-13342-003 | BEARING B, MAIN LOWER(BLACK)   | 5       | (DAIDO)   |
| E-7     | 11 | HPNA-13343-003 | BEARING C, MAIN LOWER(BROWN)   | 5       | (DAIDO)   |




[illegible]

FR. ➔




| Ref.No. |    | Part No.       | Description                    | Q' ty   | Remarks          |
|---------|----|----------------|--------------------------------|---------|------------------|
|         |    |                |                                | BFT115A |                  |
| E-9     | 1  | HZY5-14110-000 | CAMSHAFT COMP., IN.            | 1       |                  |
| E-9     | 2  | HPNA-14114-003 | PLATE, TDC PULSE               | 1       |                  |
| E-9     | 3  | HPNA-14115-000 | BOLT, SEALING, 14MM            | 2       |                  |
| E-9     | 4  | HZY6-14120-000 | CAMSHAFT COMP., EX.            | 1       |                  |
| E-9     | 5  | HPNA-14210-000 | SPROCKET, CAM CHAIN DRIVEN     | 1       | (46T)            |
| E-9     | 6  | HZY6-14311-000 | SPROCKET, CAM CHAIN DRIVEN IN. | 1       | (46T)            |
| E-9     | 7  | HR40-14401-A01 | CHAIN(176L)(BORG WARNER)       | 1       |                  |
| E-9     | 8  | HZY6-14510-003 | TENSIONER ASSY., CAM CHAIN     | 1       |                  |
| E-9     | 9  | HPNA-14511-003 | STOPPER(TOOL)                  | 1       |                  |
| E-9     | 10 | HPPA-14520-003 | ARM COMP., CAM CHAIN TENSIONER | 1       |                  |
| E-9     | 11 | HPPA-14530-003 | GUIDE COMP., CAM CHAIN         | 1       |                  |
| E-9     | 12 | HRWC-14540-A02 | GUIDE COMP. B, CAM CHAIN       | 1       |                  |
| E-9     | 13 | HRAA-14620-A00 | ARM ASSY., ROCKER              | 4       |                  |
| E-9     | 14 | HRAA-14624-A00 | ARM ASSY., EX. ROCKER          | 4       |                  |
| E-9     | 15 | HPNE-14631-000 | SHAFT, IN. ROCKER              | 1       |                  |
| E-9     | 16 | HR40-14633-A00 | SHAFT, EX. ROCKER              | 1       |                  |
| E-9     | 17 | HRAA-14647-A00 | WASHER, THRUST                 | 8       |                  |
| E-9     | 18 | HPNA-14711-000 | VALVE, IN.                     | 8       |                  |
| E-9     | 19 | HPRB-14721-A00 | VALVE, EX.                     | 8       |                  |
| E-9     | 20 | HPNA-14744-004 | SCREW, TAPPET ADJUSTING        | 8       |                  |
| E-9     | 21 | HPT0-14744-004 | SCREW, TAPPET ADJUSTING        | 8       |                  |
| E-9     | 22 | HZY6-14751-003 | SPRING, IN. VALVE(PINK)        | 8       | (NIPPON HATSUJO) |
| E-9     | 23 | HPNA-14762-003 | SPRING, EX. VALVE(GRAY)        | 8       | (NIPPON HATSUJO) |
| E-9     | 24 | HRAA-14765-A00 | RETAINER, VALVE SPRING         | 16      |                  |
| E-9     | 25 | HPT0-14775-000 | SEAT, VALVE SPRING             | 16      |                  |
| E-9     | 26 | HRGM-14781-A01 | COTTER, VALVE(FUJI VALVE)      | 32      |                  |
| E-9     | 27 | HPNA-90003-000 | BOLT, TENSIONER PIVOT          | 1       |                  |
| E-9     | 28 | HPNA-90032-000 | BOLT, FLANGE, 12X47            | 1       |                  |
| E-9     | 29 | HPNA-90042-003 | BOLT, FLANGE, 10X32            | 1       |                  |


FR. ➔




[illegible]




| Ref.No. |    | Part No.         | Description                   | Q' ty   | Remarks         |
|---------|----|------------------|-------------------------------|---------|-----------------|
|         |    |                  |                               | BFT115A |                 |
| E-9-10  | 1  | HZY6-11410-425ZA | CASE ASSY., CHAIN             | 1       | *NH8* DARK GRAY |
| E-9-10  | 2  | HZY6-11412-000   | COVER, CHAIN CASE             | 1       |                 |
| E-9-10  | 3  | HZY3-19300-023   | THERMOSTAT ASSY.              | 1       |                 |
| E-9-10  | 4  | HZY6-19300-003   | THERMOSTAT ASSY.              | 1       |                 |
| E-9-10  | 5  | HZY6-19313-000ZB | SPACER, THERMOSTAT COVER      | 1       | *TGRAY* GRAY    |
| E-9-10  | 6  | HZY6-19315-010   | COVER, THERMOSTAT             | 1       |                 |
| E-9-10  | 7  | HZY6-19318-010   | PACKING, THERMOSTAT COVER     | 1       |                 |
| E-9-10  | 8  | HZY6-19319-000   | PACKING, THERMOSTAT SPACER    | 1       |                 |
| E-9-10  | 9  | HZY6-32112-000   | BRACKET B, HARNESS CLIP       | 1       |                 |
| E-9-10  | 10 | HZY6-32113-000   | BRACKET C, HARNESS CLIP       | 1       |                 |
| E-9-10  | 11 | HZW5-35673-003   | SENSOR ASSY., WATER           | 1       | TEMPERATURE     |
| E-9-10  | 12 | HZY3-35673-003   | SENSOR ASSY., WATER           | 1       | TEMPERATURE     |
| E-9-10  | 13 | HPNB-37500-003   | SENSOR ASSY., CRANK           | 1       |                 |
| E-9-10  | 14 | HZW9-90011-000   | BOLT, FLANGE, 6X14(CT200)     | 5       |                 |
| E-9-10  | 15 | HZY3-90016-000   | BOLT, FLANGE, 6X28            | 13      |                 |
| E-9-10  | 16 | HZY3-90017-000   | BOLT, FLANGE, 6X16            | 1       |                 |
| E-9-10  | 17 | HZY3-90021-000   | BOLT, FLANGE, 6X14            | 3       |                 |
| E-9-10  | 18 | HZY6-90023-000   | BOLT, SPECIAL, 6X31           | 2       |                 |
| E-9-10  | 19 | HZY3-90040-000   | BOLT, FLANGE, 10X43           | 2       |                 |
| E-9-10  | 20 | HZY6-90059-000   | BOLT, FLANGE, 6X38            | 1       |                 |
| E-9-10  | 21 | HZW4-90162-000   | BOLT, FLANGE, 10X70           | 1       |                 |
| E-9-10  | 22 | HPNC-91212-004   | OIL SEAL, 43X58X7(ARAI)       | 1       |                 |
| E-9-10  | 23 | HPNA-91302-004   | O-RING, CHAIN CASE            | 1       |                 |
| E-9-10  | 24 | HZY6-91304-010   | PACKING, CHAIN CASE           | 1       |                 |
| E-9-10  | 25 | HPK2-91307-005   | O-RING, 9.5X1.5(HONDA KIKAKI) | 1       |                 |
| E-9-10  | 26 | HPNA-91307-003   | O-RING, 9.5X1.9               | 1       |                 |
| E-9-10  | 27 | HPNA-91333-003   | O-RING, 15X1.9                | 1       |                 |
| E-9-10  | 28 | HSP0-91546-A01   | CLAMP, 18.5MM                 | 1       |                 |
| E-9-10  | 29 | HZW9-19303-003   | RUBBER, RING                  | 2       |                 |

FR. 



| Ref.No. |    | Part No.           | Description                 | Q' ty   | Remarks         |
|---------|----|--------------------|-----------------------------|---------|-----------------|
|         |    |                    |                             | BFT115A |                 |
| E-9-20  | 1  | HZY6-06122-010ZA   | HEAD KIT, CYLINDER          | 1       | *NH8* DARK GRAY |
| E-9-20  | 2  | HPNA-12204-305     | GUIDE, IN. VALVE(OS)        | 8       |                 |
| E-9-20  | 3  | HPNA-12205-305     | GUIDE, EX. VALVE(OS)        | 8       |                 |
| E-9-20  | 4  | HPZ1-12210-003     | SEAL A, VALVE STEM(ARAI)    | 8       |                 |
| E-9-20  | 4  | HPZ1-12210-004     | SEAL A, VALVE STEM(NOK)     | 8       |                 |
| E-9-20  | 5  | HPZ1-12211-003     | SEAL B, VALVE STEM(ARAI)    | 8       |                 |
| E-9-20  | 5  | HPZ1-12211-004     | SEAL B, VALVE STEM(NOK)     | 8       |                 |
| E-9-20  | 6  | HZY6-12251-003     | GASKET COMP., CYLINDER HEAD | 1       |                 |
| E-9-20  | 7  | HRAA-15815-A02     | FILTER ASSY., SPOOL VALVE   | 1       |                 |
| E-9-20  | 8  | HZY9-15815-000     | COVER ASSY., OIL PATH       | 1       |                 |
| E-9-20  | 9  | HZY6-15834-000     | PLUG, VTC HOLE              | 1       |                 |
| E-9-20  | 10 | HZY6-15840-000ZA   | STRAINER ASSY., VTC         | 1       | *NH8* DARK GRAY |
| E-9-20  | 11 | HRAA-15845-A01     | FILTER ASSY., VTC           | 1       |                 |
| E-9-20  | 12 | HZY6-32116-000     | BRACKET F, CLIP             | 1       |                 |
| E-9-20  | 13 | HPNB-37510-003     | SENSOR ASSY., TDC           | 1       |                 |
| E-9-20  | 14 | HZY6-37521-000     | PLUG, TDC HOLE              | 1       |                 |
| E-9-20  | 15 | HPNA-90005-003     | BOLT-WASHER, 11X155         | 10      |                 |
| E-9-20  | 16 | HPNA-90011-003     | BOLT A, HEAD COVER          | 6       |                 |
| E-9-20  | 17 | HZY6-90011-000     | BOLT, FLANGE, 6X52          | 3       |                 |
| E-9-20  | 18 | HZY3-90017-000     | BOLT, FLANGE, 6X16          | 2       |                 |
| E-9-20  | 19 | HZW5-90018-000     | BOLT, FLANGE, 6X20          | 4       |                 |
| E-9-20  | 20 | HZY3-90021-000     | BOLT, FLANGE, 6X14          | 1       |                 |
| E-9-20  | 21 | HZY6-90048-010     | BOLT, SEALING, 20MM         | 1       |                 |
| E-9-20  | 22 | HZY6-91303-003     | O-RING, 15X1.9              | 1       |                 |
| E-9-20  | 23 | HPNA-91333-003     | O-RING, 15X1.9              | 1       |                 |
| E-9-20  | 24 | HCO-94109-20000    | WASHER, DRAIN PLUG, 20MM    | 1       |                 |
| E-9-20  | 25 | HCO-94301-10160    | DOWEL PIN, 10X16            | 20      |                 |
| E-9-20  | 26 | HCO-94301-14200    | DOWEL PIN, 14X20            | 2       |                 |
| E-9-20  | 27 | HCO-95701-06020-08 | BOLT, FLANGE, 6X20          | 1       |                 |

FR. 

[illegible]


FR. 

[illegible]




➡ E-7


FR. ➡








| Ref.No. |    | Part No.         | Description                  | Q' ty   | Remarks                  |
|---------|----|------------------|------------------------------|---------|--------------------------|
|         |    |                  |                              | BFT115A |                          |
| E-14    | 1  | HZY6-16089-000   | BOLT, FUEL PIPE              | 2       |                          |
| E-14    | 2  | HZY6-16450-003   | INJECTOR ASSY., FUEL         | 4       |                          |
| E-14    | 3  | HZY6-16451-000   | CLIP, INJECTOR               | 4       |                          |
| E-14    | 4  | HZY6-16621-000   | LINE, FUEL                   | 1       |                          |
| E-14    | 5  | HZY6-16740-003   | REGULATOR ASSY., PRESSURE    | 1       |                          |
| E-14    | 6  | HZY6-16744-010   | CAP, REGULATOR               | 1       |                          |
| E-14    | 7  | HZY6-16748-000   | TUBE, PRESSURE REGULATOR     | 1       | CONTROL                  |
| E-14    | 8  | HZY3-16752-000   | JOINT, FUEL PIPE             | 1       |                          |
| E-14    | 9  | HZY6-16752-000   | JOINT, FUEL PIPE             | 1       |                          |
| E-14    | 10 | HZY6-17051-000ZA | BASE, INJECTOR               | 1       | *NH8* DARK GRAY          |
| E-14    | 11 | HPNA-17055-004   | GASKET A, INJECTOR BASE      | 1       |                          |
| E-14    | 12 | HZY6-17105-000   | PACKING, INTAKE MANIFOLD     | 4       |                          |
| E-14    | 13 | HZY6-17109-000   | PACKING, THROTTLE BODY       | 1       |                          |
| E-14    | 14 | HZX1-17110-003   | MANIFOLD COMP., INLET        | 1       |                          |
| E-14    | 15 | HZY6-32111-000   | BRACKET A, HARNESS CLIP      | 4       |                          |
| E-14    | 16 | HPS4-36454-003   | FILTER COMP., ELECTRONIC AIR | 1       | CONTROL VALVE(TOYO ROKI) |
| E-14    | 17 | HZY6-36550-003   | VALVE ASSY., ELECTRONIC AIR  | 1       | CONTROL                  |
| E-14    | 18 | HZY6-36551-003   | PACKING, ELECTRONIC AIR      | 1       | CONTROL VALVE            |
| E-14    | 19 | H121-51640-730   | RUBBER, FR. CARRIER CUSHION  | 2       |                          |
| E-14    | 20 | HZW1-90014-000   | BOLT-WASHER, 8X35            | 2       |                          |
| E-14    | 21 | HZY3-90021-000   | BOLT, FLANGE, 6X14           | 4       |                          |
| E-14    | 22 | HZY3-90042-000   | BOLT, FLANGE, 6X10           | 4       |                          |
| E-14    | 23 | HZY6-90043-000   | BOLT, STUD 2, 8X25           | 2       |                          |
| E-14    | 24 | HZY6-90047-000   | BOLT, STUD, 8X32             | 2       |                          |
| E-14    | 25 | HZY3-90054-000   | BOLT, FLANGE, 8X35           | 3       |                          |
| E-14    | 26 | HZW4-90126-000   | BOLT, FLANGE, 8X45           | 2       |                          |
| E-14    | 27 | HZW4-90151-000   | BOLT, FLANGE, 8X25           | 5       |                          |
| E-14    | 28 | HZY3-90205-000   | NUT, FLANGE, 8MM             | 4       |                          |
| E-14    | 29 | HZW2-90301-F00   | NUT, FLANGE, 6MM             | 2       |                          |




FR.


[illegible]




| Ref.No. |    | Part No.           | Description                   | Q' ty   | Remarks              |
|---------|----|--------------------|-------------------------------|---------|----------------------|
|         |    |                    |                               | BFT115A |                      |
| E-15    | 1  | HZY6-16016-003     | SCREW SET                     | 1       |                      |
| E-15    | 2  | HZY6-16400-013     | THROTTLE BODY ASSY.           | 1       |                      |
| E-15    | 3  | HPY3-17249-000     | SPRING, AIR FLOW TUBE         | 1       |                      |
| E-15    | 4  | HZY9-17315-000     | BAND, AIR FLOW                | 1       |                      |
| E-15    | 5  | HZY6-17371-020     | CASE COMP., SILENCER          | 1       |                      |
| E-15    | 6  | HZY6-17374-000     | GROMMET, SILENCER             | 1       |                      |
| E-15    | 7  | HZY6-17397-013     | GROMMET, SILENCER DUCT        | 1       |                      |
| E-15    | 8  | HZY6-17398-000     | SPRING, SILENCER DUCT GROMMET | 1       |                      |
| E-15    | 9  | HZY6-32115-000     | BRACKET E, HARNESS CLIP       | 1       |                      |
| E-15    | 10 | HZY3-32128-000     | BRACKET, SENSOR CORD          | 1       |                      |
| E-15    | 11 | HRNA-37830-A01     | SENSOR ASSY., MAP             | 1       |                      |
| E-15    | 12 | HPGK-37835-A01     | O-RING                        | 1       |                      |
| E-15    | 13 | HPLC-37880-004     | SENSOR ASSY., AIR TEMP        | 1       | (MATSUSHITA DENSHI)  |
| E-15    | 14 | HP2A-37881-000     | GROMMET, TA SENSOR            | 1       |                      |
| E-15    | 15 | HZV5-40102-000     | GROMMET, UNDER CASE           | 3       |                      |
| E-15    | 16 | HZY6-90006-000     | SCREW, PAN, 5X18              | 1       |                      |
| E-15    | 17 | HZW1-90013-000     | BOLT-WASHER, 6X25             | 3       |                      |
| E-15    | 18 | HZY9-90017-000     | BOLT-WASHER, 5X30             | 1       |                      |
| E-15    | 19 | HZY3-90056-000     | BOLT, FLANGE, 6X12            | 1       |                      |
| E-15    | 20 | HZV1-90127-010     | BOLT, FLANGE, 8X60            | 4       |                      |
| E-15    | 21 | HZV3-90601-030     | CLAMP, TUBE(D17)              | 1       |                      |
| E-15    | 22 | HZV5-91553-010     | COLLAR, C.D.I. UNIT CASE      | 3       |                      |
| E-15    | 23 | HSF1-91595-003     | CLAMP, FUEL HOSE              | 1       |                      |
| E-15    | 24 | HCO-95003-07016-31 | TUBE, VINYL, 4X7X160          | 1       | (HC-95003-07001-60M) |
| E-15    | 25 | HCO-95005-12740-20 | TUBE, 12X740                  | 1       | (HC-95005-12001-20M) |
|         |    |                    |                               |         |                      |
|         |    |                    |                               |         |                      |
|         |    |                    |                               |         |                      |
|         |    |                    |                               |         |                      |



| Ref.No. |    | Part No.       | Description              | Q' ty   | Remarks |
|---------|----|----------------|--------------------------|---------|---------|
|         |    |                |                          | BFT115A |         |
| E-18    | 1  | HGHB-16163-610 | CLIP, TUBE               | 1       |         |
| E-18    | 2  | HZY6-16196-000 | TUBE COMP. C, AIR VENT   | 1       |         |
| E-18    | 3  | HZY6-16198-000 | TUBE B, AIR VENT         | 1       |         |
| E-18    | 4  | HZY6-16199-000 | TUBE COMP., AIR VENT     | 1       |         |
| E-18    | 5  | HZY6-16700-013 | PUMP ASSY., FUEL         | 1       |         |
| E-18    | 6  | HZY6-16755-003 | HOSE COMP., FUEL         | 1       |         |
| E-18    | 7  | HZY6-16860-000 | TUBE COMP. B, FUEL       | 1       |         |
| E-18    | 8  | HZV5-16881-000 | TUBE D, FUEL             | 1       |         |
| E-18    | 9  | H759-16911-003 | STRAINER, FUEL PUMP      | 1       |         |
| E-18    | 10 | HZW5-16915-000 | SUSPENSION, STRAINER     | 1       |         |
| E-18    | 11 | HMZ5-16952-000 | TUBE B, FUEL             | 1       |         |
| E-18    | 12 | HVM0-16965-771 | CLAMP, HOSE              | 2       |         |
| E-18    | 13 | HKV7-17368-671 | CLAMP, PIPE              | 1       |         |
| E-18    | 14 | HZY6-17723-020 | HOSE, PRESSURE REGULATOR | 1       | RETURN  |
| E-18    | 15 | HZY6-19269-000 | T-JOINT                  | 1       |         |
| E-18    | 16 | HZY6-19273-000 | TUBE G, WATER            | 1       |         |
| E-18    | 17 | HZY6-36135-003 | VALVE, CHECK             | 1       |         |
| E-18    | 18 | HSE0-53740-953 | CLIP, SENSOR HOSE        | 2       |         |
| E-18    | 19 | HZY6-90010-000 | BOLT, FLANGE, 6X27       | 2       |         |
| E-18    | 20 | HZW1-90014-000 | BOLT-WASHER, 8X35        | 2       |         |
| E-18    | 21 | HZW9-90016-000 | BOLT, FLANGE, 6X25       | 2       |         |
| E-18    | 22 | HZW5-90601-030 | CLAMP, TUBE(D10.7)       | 2       |         |
| E-18    | 23 | HZY6-90601-000 | CLIP, TUBE(B1 14.5)      | 1       |         |
| E-18    | 24 | HZV0-90604-000 | CLIP, TUBE(B12)          | 1       |         |
| E-18    | 25 | HZY6-90605-003 | CLIP, FUEL HOSE          | 1       |         |
| E-18    | 26 | HPA9-91317-003 | O-RING, 33.2X2.4(NOK)    | 1       |         |
| E-18    | 27 | HSE0-91547-003 | CLIP, HARNESS            | 1       |         |
| E-18    | 28 | HZW1-91554-000 | COLLAR, 8.5X14.5         | 2       |         |
| E-18    | 29 | HSM4-91558-003 | CLIP, TUBE(BLACK)(135MM) | 1       |         |






FR. 


| Ref.No. |    | Part No.       | Description              | Q' ty   | Remarks |
|---------|----|----------------|--------------------------|---------|---------|
|         |    |                |                          | BFT115A |         |
| E-18-1  | 1  | HZE2-16731-003 | CLIP, TUBE               | 1       |         |
| E-18-1  | 2  | HZY6-16800-003 | SEPARATOR ASSY., WATER   | 1       |         |
| E-18-1  | 3  | HZY6-16805-003 | CUP SET, WATER SEPARATOR | 1       |         |
| E-18-1  | 4  | HZY3-16807-003 | BUFFER, PLATE            | 1       |         |
| E-18-1  | 5  | HZY3-16818-003 | O-RING                   | 1       |         |
| E-18-1  | 6  | HZY6-16850-000 | TUBE COMP. A, FUEL       | 1       |         |
| E-18-1  | 7  | HZY6-16871-000 | TUBE C, FUEL             | 1       |         |
| E-18-1  | 8  | HZY6-16880-030 | TUBE ASSY. D, FUEL       | 1       |         |
| E-18-1  | 9  | HZY6-16881-000 | TUBE D, FUEL             | 1       |         |
| E-18-1  | 10 | HZY6-16890-000 | TUBE COMP. E, FUEL       | 1       |         |
| E-18-1  | 11 | HZY3-16900-003 | STRAINER COMP., FUEL     | 1       |         |
| E-18-1  | 12 | HZY3-16901-003 | STRAINER, FUEL           | 1       |         |
| E-18-1  | 13 | HZY3-16904-003 | SCREW, PAN, 5X12         | 6       |         |
| E-18-1  | 14 | HZY3-16912-003 | CUP, FUEL STRAINER       | 1       |         |
| E-18-1  | 15 | HZY6-16914-010 | STAY, FUEL STRAINER      | 1       |         |
| E-18-1  | 16 | HZY3-16915-010 | SUSPENSION, STRAINER     | 2       |         |
| E-18-1  | 17 | HZY3-16918-003 | O-RING                   | 2       |         |
| E-18-1  | 18 | HZY3-16919-003 | PLATE                    | 2       |         |
| E-18-1  | 19 | HMR5-16966-000 | JOINT, FUEL TUBE         | 1       |         |
| E-18-1  | 20 | HZY3-90021-000 | BOLT, FLANGE, 6X14       | 2       |         |
| E-18-1  | 21 | HZY6-90601-000 | CLIP, TUBE(B1 14.5)      | 1       |         |
| E-18-1  | 22 | HZW5-90602-030 | CLAMP, TUBE(D12)         | 2       |         |
| E-18-1  | 23 | HZV0-90604-000 | CLIP, TUBE(B12)          | 4       |         |
| E-18-1  | 24 | HSA0-90683-003 | CLIP, WIRE HARNESS, 25MM | 1       |         |
|         |    |                |                          |         |         |
|         |    |                |                          |         |         |
|         |    |                |                          |         |         |
|         |    |                |                          |         |         |
|         |    |                |                          |         |         |
|         |    |                |                          |         |         |

FR. →





| Ref.No. |    | Part No.       | Description         | Q' ty   | Remarks |
|---------|----|----------------|---------------------|---------|---------|
|         |    |                |                     | BFT115A |         |
| E-18-10 | 1  | HZY3-16011-000 | VALVE SET, FLOAT    | 1       |         |
| E-18-10 | 2  | HZY3-16013-000 | FLOAT SET           | 1       |         |
| E-18-10 | 3  | HZY6-16014-003 | STAY A, PLATE       | 1       |         |
| E-18-10 | 4  | HZY6-16017-043 | PUMP UNIT, FUEL     | 1       |         |
| E-18-10 | 5  | HZY6-16019-003 | BODY COMP., CHAMBER | 1       |         |
| E-18-10 | 6  | HZY6-16020-023 | COVER COMP.         | 1       |         |
| E-18-10 | 7  | HZY3-16024-000 | SCREW SET, DRAIN    | 1       |         |
| E-18-10 | 8  | HZY3-16026-000 | JOINT SET           | 1       |         |
| E-18-10 | 9  | HZY6-16036-003 | PUMP UNIT, FUEL(B)  | 1       |         |
| E-18-10 | 10 | HZY3-16041-000 | PLATE               | 1       |         |
| E-18-10 | 11 | HZY3-16042-000 | HOLDER              | 1       |         |
| E-18-10 | 12 | HZY3-16061-000 | COVER, WATER JACKET | 1       |         |
| E-18-10 | 13 | HZY3-16072-000 | O-RING              | 1       |         |
| E-18-10 | 14 | HZY3-16073-000 | O-RING              | 1       |         |
| E-18-10 | 15 | HZY3-16074-000 | O-RING              | 1       |         |
| E-18-10 | 16 | HZY3-16075-000 | O-RING              | 1       |         |
| E-18-10 | 17 | HZY3-16076-000 | O-RING              | 1       |         |
| E-18-10 | 18 | HZY3-16077-000 | O-RING              | 2       |         |
| E-18-10 | 19 | HZY3-16078-000 | O-RING              | 1       |         |
| E-18-10 | 20 | HZW5-16081-010 | SCREW-WASHER        | 21      |         |
| E-18-10 | 21 | HZY3-16082-000 | SCREW, PAN          | 2       |         |
| E-18-10 | 22 | HZY3-16083-000 | SCREW, WASHER       | 1       |         |
| E-18-10 | 23 | HZW5-16086-000 | COLLAR              | 8       |         |
| E-18-10 | 24 | HZW5-16087-000 | WASHER, PLAIN       | 8       |         |
| E-18-10 | 25 | HZY3-16087-000 | WASHER, PLAIN       | 1       |         |
| E-18-10 | 26 | HZY3-16088-000 | COLLAR              | 1       |         |
| E-18-10 | 27 | HZY6-16701-003 | CASE COMP., PUMP    | 1       |         |
| E-18-10 | 28 | HZW5-16708-003 | COVER, PUMP(B)      | 1       |         |
| E-18-10 | 29 | HZW5-16715-023 | COVER, PUMP(A)      | 1       |         |



FR. →




| Ref.No. |    | Part No.       | Description                 | Q' ty   | Remarks |
|---------|----|----------------|-----------------------------|---------|---------|
|         |    |                |                             | BFT115A |         |
| E-18-10 | 30 | HZY6-16718-013 | INSULATOR COMP.             | 1       |         |
| E-18-10 | 31 | HZY3-16721-000 | INSULATOR                   | 1       |         |
| E-18-10 | 32 | HZY6-16723-003 | RING                        | 1       |         |
| E-18-10 | 33 | HZY6-16730-063 | SEPARATOR ASSY., VAPOR      | 1       |         |
| E-18-10 | 34 | HZW5-16733-000 | GROMMET, VAPOR SEPARATOR    | 1       |         |
| E-18-10 | 35 | HZY3-16733-000 | GROMMET, VAPOR SEPARATOR    | 2       |         |
| E-18-10 | 36 | HZY6-16734-003 | STAY, PLATE                 | 1       |         |
| E-18-10 | 37 | HZY6-16736-003 | STAY, VAPOR SEPARATOR       | 1       |         |
| E-18-10 | 38 | HZY3-16752-000 | JOINT, FUEL PIPE            | 1       |         |
| E-18-10 | 39 | HZY6-16840-A00 | TUBE F, FUEL                | 1       |         |
| E-18-10 | 40 | HZY3-16911-010 | SCREEN COMP., FUEL STRAINER | 1       |         |
| E-18-10 | 41 | HZY3-16913-000 | SPRING, SET                 | 1       |         |
| E-18-10 | 42 | HZY6-32166-003 | HARNESS COMP.               | 1       |         |
| E-18-10 | 43 | HZW5-32168-003 | BAND                        | 1       |         |
| E-18-10 | 44 | HPP4-90009-E01 | BOLT, SEALING, 6MM          | 1       |         |
| E-18-10 | 45 | HZW1-90014-000 | BOLT-WASHER, 8X35           | 1       |         |
| E-18-10 | 46 | HZW9-90016-000 | BOLT, FLANGE, 6X25          | 4       |         |
| E-18-10 | 47 | HZY3-90017-000 | BOLT, FLANGE, 6X16          | 2       |         |
| E-18-10 | 48 | HZY3-90049-000 | BOLT, FLANGE, 8X30          | 1       |         |
| E-18-10 | 49 | HPD6-90430-003 | WASHER, SEALING, 6MM        | 1       |         |
| E-18-10 | 50 | HZY6-90607-000 | CLAMP, TUBE(8.0)            | 2       |         |
| E-18-10 | 51 | HMJ0-91301-003 | O-RING, 7.8X1.9(ARAI)       | 2       |         |
| E-18-10 | 52 | HZW1-91554-000 | COLLAR, 8.5X14.5            | 1       |         |
|         |    |                |                             |         |         |
|         |    |                |                             |         |         |
|         |    |                |                             |         |         |
|         |    |                |                             |         |         |
|         |    |                |                             |         |         |
|         |    |                |                             |         |         |
|         |    |                |                             |         |         |



| Ref.No. |    | Part No.       | Description                   | Q' ty   | Remarks   |
|---------|----|----------------|-------------------------------|---------|-----------|
|         |    |                |                               | BFT115A |           |
| E-19    | 1  | HZY6-11912-000 | HANGER B, ENGINE              | 1       |           |
| E-19    | 2  | HPZ1-31105-003 | HOLDER ASSY., BRUSH           | 1       |           |
| E-19    | 3  | HPJ7-31111-013 | BEARING, RR.                  | 1       |           |
| E-19    | 4  | HPJ7-31114-013 | BEARING, FR.                  | 1       |           |
| E-19    | 5  | HPD1-31138-004 | COVER, BEARING                | 1       |           |
| E-19    | 6  | HP64-31141-003 | PULLEY                        | 1       |           |
| E-19    | 7  | HPD1-31142-004 | NUT, PULLEY LOCK              | 1       |           |
| E-19    | 8  | HPE9-31145-941 | BOLT, STUD                    | 2       |           |
| E-19    | 9  | HPJ7-31146-003 | SCREW                         | 4       |           |
| E-19    | 10 | HPT0-31147-003 | SCREW-WASHER                  | 6       |           |
| E-19    | 11 | HPD1-31148-004 | SCREW-WASHER, 4X25            | 2       |           |
| E-19    | 12 | HPZ1-31149-003 | SCREW                         | 1       |           |
| E-19    | 13 | HPE9-31152-942 | BOLT-WASHER                   | 2       |           |
| E-19    | 14 | HPZ1-31153-003 | BOLT                          | 3       |           |
| E-19    | 15 | HZY6-31630-003 | GENERATOR ASSY., A.C.         | 1       | #~1005765 |
| E-19    | 15 | HZY6-31630-013 | GENERATOR ASSY., A.C.         | 1       | #1005766~ |
| E-19    | 16 | HZW5-31631-003 | ROTOR ASSY.                   | 1       |           |
| E-19    | 17 | HZY6-31636-010 | BRACKET COMP., A.C. GENERATOR | 1       |           |
| E-19    | 18 | HZY6-31637-000 | STAY, A.C. GENERATOR          | 1       |           |
| E-19    | 19 | HZW5-31639-003 | END COVER, RR.                | 1       |           |
| E-19    | 20 | HZW5-31644-003 | BUSH, INSULATION              | 1       |           |
| E-19    | 21 | HZW5-31710-003 | RECTIFIER ASSY.               | 1       |           |
| E-19    | 22 | HZY6-31750-003 | REGULATOR ASSY.               | 1       |           |
| E-19    | 23 | HZW5-90011-010 | BOLT, SPECIAL ADJUSTER        | 1       |           |
| E-19    | 24 | HZY3-90017-000 | BOLT, FLANGE, 6X16            | 1       |           |
| E-19    | 25 | HZY3-90026-000 | BOLT, FLANGE, 8X20            | 2       |           |
| E-19    | 26 | HZY3-90035-000 | BOLT, FLANGE, 8X28            | 4       |           |
| E-19    | 27 | HZY3-90055-000 | BOLT, TENSIONER               | 1       |           |
| E-19    | 28 | HZW4-90163-000 | BOLT, FLANGE, 10X80           | 1       |           |








FR. ➔


[illegible]











| Ref.No. |    | Part No.       | Description               | Q' ty   | Remarks                |
|---------|----|----------------|---------------------------|---------|------------------------|
|         |    |                |                           | BFT115A |                        |
| E-21    | 1  | HZY6-31200-003 | MOTOR ASSY., STARTER      | 1       |                        |
| E-21    | 2  | HZY3-31207-003 | CLUTCH COMP., OVERRUNNING | 1       | #~1004968<br>#~6000047 |
| E-21    | 2  | HZY9-31207-H01 | CLUTCH COMP., OVERRUNNING | 1       | #1004969~<br>#6000048~ |
| E-21    | 3  | HPY3-31215-004 | GEAR ASSY., PLANETARY     | 3       |                        |
| E-21    | 4  | HZY6-31216-003 | YOKE COMP.                | 1       |                        |
| E-21    | 5  | HZW5-31217-003 | ROTOR COMP.               | 1       |                        |
| E-21    | 6  | HPY3-31218-004 | BALL, STEEL               | 1       |                        |
| E-21    | 7  | HZY6-31226-003 | BRUSH SET                 | 1       | #~1004968<br>#~6000047 |
| E-21    | 7  | HZY6-31227-003 | BRUSH SET                 | 1       | #1004969~<br>#6000048~ |
| E-21    | 8  | HZW1-31229-004 | STOPPER SET, SLEEVE       | 1       | #~1004968<br>#~6000047 |
| E-21    | 8  | HZY9-31229-H01 | STOPPER SET, SLEEVE       | 1       | #1004969~<br>#6000048~ |
| E-21    | 9  | HZY6-31231-003 | HOLDER COMP., BRUSH       | 1       | #~1004968<br>#~6000047 |
| E-21    | 9  | HZY6-31232-003 | HOLDER COMP., BRUSH       | 1       | #1004969~<br>#6000048~ |
| E-21    | 10 | HZY6-31235-003 | BRACKET, FR.              | 1       |                        |
| E-21    | 11 | HZY6-31236-003 | BRACKET, RR.              | 1       |                        |
| E-21    | 12 | HZY6-31240-003 | SWITCH ASSY., MAGNET      | 1       | #~1004968<br>#~6000047 |
| E-21    | 12 | HZY9-31240-003 | SWITCH ASSY., MAGNET      | 1       | #1004969~<br>#6000048~ |
| E-21    | 13 | HZY6-31242-003 | SHAFT ASSY., CLUTCH       | 1       | #~1004968<br>#~6000047 |
| E-21    | 13 | HZY9-31242-H01 | SHAFT ASSY., CLUTCH       | 1       | #1004969~<br>#6000048~ |
| E-21    | 14 | HZY3-31246-003 | SHAFT ASSY., GEAR         | 1       | #~1004968<br>#~6000047 |
| E-21    | 14 | HZY9-31246-H01 | SHAFT ASSY., GEAR         | 1       | #1004969~<br>#6000048~ |
| E-21    | 15 | HZW1-31247-004 | GEAR ASSY., INTERNAL      | 1       | #~1004968<br>#~6000047 |
| E-21    | 16 | HZW1-31249-004 | PACKING                   | 1       | #~1004968<br>#~6000047 |
| E-21    | 17 | HZW1-31250-004 | LEVER SET                 | 1       |                        |
| E-21    | 18 | HZW1-31261-004 | BOLT A, THROUGH           | 2       |                        |
| E-21    | 19 | HZW1-90106-004 | SCREW, PAN, 6X22(SPECIAL) | 2       | #~1004968<br>#~6000047 |
| E-21    | 19 | HZY9-31226-H01 | SCREW, PAN, 6X22          | 2       | #1004969~<br>#6000048~ |
| E-21    | 20 | HZW1-90107-004 | SCREW, PAN, 5X8           | 2       |                        |
| E-21    | 21 | HZW4-90164-000 | BOLT, FLANGE, 10X90       | 2       |                        |




[illegible]




| Ref.No. |    | Part No.         | Description                 | Q' ty   | Remarks         |
|---------|----|------------------|-----------------------------|---------|-----------------|
|         |    |                  |                             | BFT115A |                 |
| F-2     | 1  | HZV5-17838-000   | LINKAGE, PIVOT              | 1       |                 |
| F-2     | 2  | HZY6-17840-000   | ROD COMP., THROTTLE         | 1       |                 |
| F-2     | 3  | HZY6-17845-000   | LINK, THROTTLE              | 1       |                 |
| F-2     | 4  | HZY6-17860-000   | PLATE COMP., THROTTLE       | 1       |                 |
| F-2     | 5  | HZY6-17877-010   | PLATE, REMOTE CONTROL CABLE | 1       |                 |
| F-2     | 6  | HZY6-17931-000   | ARM, THROTTLE               | 1       |                 |
| F-2     | 7  | H921-17936-000   | WASHER, PIVOT               | 1       |                 |
| F-2     | 8  | HZY6-24166-000   | ARM COMP., CLICK            | 1       |                 |
| F-2     | 9  | HZY6-24218-000   | SPRING, CLICK               | 1       |                 |
| F-2     | 10 | HZY6-24320-000   | ROD COMP. A, SHIFT(L)       | 1       | LD,LU           |
| F-2     | 10 | HZY6-24320-610   | ROD COMP. A, SHIFT(XL)      | 1       | XU              |
| F-2     | 11 | HZW1-24327-000   | RING, STOPPER               | 1       |                 |
| F-2     | 12 | HZY6-24610-000   | SHAFT COMP. A, SHIFT        | 1       |                 |
| F-2     | 13 | HZY6-24612-020   | ARM, SHIFT                  | 1       |                 |
| F-2     | 14 | HZY6-24614-000   | PLATE, SHIFT PIVOT          | 1       |                 |
| F-2     | 15 | HZY3-24618-000   | PIVOT, SHIFT                | 2       |                 |
| F-2     | 16 | HZY6-24618-000   | PIVOT, SHIFT SLIDE          | 1       |                 |
| F-2     | 17 | HZY3-24619-000   | PLATE, LOCK                 | 2       |                 |
| F-2     | 18 | HZY6-24620-000   | SHAFT COMP. B, SHIFT        | 1       |                 |
| F-2     | 19 | HZY6-24628-000   | BRACKET, SHIFT LINK         | 1       |                 |
| F-2     | 20 | HZY6-24629-000ZA | HOLDER, SEAL                | 1       | *NH8* DARK GRAY |
| F-2     | 21 | HZY6-32418-000   | BRACKET A, CABLE            | 1       |                 |
| F-2     | 22 | HZY3-35470-023   | SWITCH ASSY., NEUTRAL       | 1       |                 |
| F-2     | 23 | HZY6-35475-000   | BRACKET, NEUTRAL SWITCH     | 1       |                 |
| F-2     | 24 | HVM0-46391-003   | CLIP, BRAKE PIPE(A)         | 1       |                 |
| F-2     | 25 | HZY3-63205-000   | BUSH A, COVER LOCK          | 2       |                 |
| F-2     | 26 | H763-75538-C01   | BUSH, BLADE BRAKE           | 1       |                 |
| F-2     | 27 | HZY3-90017-000   | BOLT, FLANGE, 6X16          | 1       |                 |
| F-2     | 28 | HZY3-90021-000   | BOLT, FLANGE, 6X14          | 2       |                 |




| Ref.No. |    | Part No.           | Description               | Q' ty   | Remarks |
|---------|----|--------------------|---------------------------|---------|---------|
|         |    |                    |                           | BFT115A |         |
| F-2     | 29 | HZY3-90028-000     | BOLT, FLANGE, 6X18        | 2       |         |
| F-2     | 30 | HZW9-90102-000     | BOLT, FLANGE, 6X12        | 2       |         |
| F-2     | 31 | HZW9-90105-000     | BOLT, FLANGE, 6X20        | 2       |         |
| F-2     | 32 | HZV5-90302-003     | NUT, HEX., 20MM           | 1       |         |
| F-2     | 33 | HZW5-90501-000     | WASHER, SHIFT SHAFT       | 1       |         |
| F-2     | 34 | HZY3-90507-000     | WASHER, PLAIN, 12MM       | 1       |         |
| F-2     | 35 | HZV7-90508-000     | WASHER                    | 1       |         |
| F-2     | 36 | HZV4-90512-000     | WASHER, PLAIN, 6MM        | 2       |         |
| F-2     | 37 | H921-90518-000     | WASHER, PLAIN, 8MM        | 1       |         |
| F-2     | 38 | HZY3-90751-000     | PIN, LINK                 | 1       |         |
| F-2     | 39 | HZY6-90752-000     | PIN, SHIFT LINK           | 1       |         |
| F-2     | 40 | HZY6-90753-000     | PIN, LINK                 | 1       |         |
| F-2     | 41 | HZY6-90755-003     | PIN, SNAP, 12MM           | 1       |         |
| F-2     | 42 | HZY3-91001-003     | BEARING, NEEDLE, 20X28X13 | 1       | (SOLID) |
| F-2     | 43 | HZY3-91152-003     | RING, INNER(15X20X23)     | 1       |         |
| F-2     | 44 | HZW5-91251-003     | OIL SEAL, 14X26X6         | 1       |         |
| F-2     | 45 | HZY3-91255-003     | SEAL, WATER(14X26X8)      | 1       |         |
| F-2     | 46 | HP0X-91321-003     | O-RING, 25X2.4(NOK)       | 1       |         |
| F-2     | 47 | HSV1-91549-L01     | HOLDER, DRAIN TUBE        | 1       |         |
| F-2     | 48 | HCO-94001-05490-0S | NUT, HEX., 5MM            | 1       |         |
| F-2     | 49 | HCO-94540-04029    | E-RING, 4MM               | 3       |         |
| F-2     | 50 | HCO-94540-06029    | E-RING, 6MM               | 1       |         |
| F-2     | 51 | HCO-94540-12029    | E-RING, 12MM              | 1       |         |
|         |    |                    |                           |         |         |
|         |    |                    |                           |         |         |
|         |    |                    |                           |         |         |
|         |    |                    |                           |         |         |
|         |    |                    |                           |         |         |
|         |    |                    |                           |         |         |
|         |    |                    |                           |         |         |




| Ref.No. |    | Part No.           | Description           | Q' ty   | Remarks                       |
|---------|----|--------------------|-----------------------|---------|-------------------------------|
|         |    |                    |                       | BFT115A |                               |
| F-3     | 1  | HZW1-19286-B00     | PLATE, RUBBER SETTING | 1       |                               |
| F-3     | 2  | HKM3-32161-003     | BAND, WIRE            | 2       |                               |
| F-3     | 3  | HZY6-41101-020ZC   | CASE, GEAR            | 1       | *T107* BAY BLUE               |
| F-3     | 4  | HZW1-41102-B00     | GROMMET, GEAR CASE    | 1       |                               |
| F-3     |    |                    |                       |         |                               |
| F-3     | 6  | HZY6-41104-010     | SCREEN, R. WATER      | 1       |                               |
| F-3     | 7  | HZY6-41105-010     | SCREEN, L. WATER      | 1       |                               |
| F-3     | 8  | HZX2-41107-C00ZC   | TAB, TRIM             | 1       | *T107* BAY BLUE               |
| F-3     | 9  | HZW1-41109-B00     | METAL COMP., ANODE    | 2       |                               |
| F-3     | 10 | HZV5-41171-000     | END, NIPPLE           | 1       |                               |
| F-3     | 11 | HZV5-41172-000     | NIPPLE, SENSOR        | 1       |                               |
| F-3     | 12 | HZW9-90101-003     | BOLT, OIL CHECK       | 1       |                               |
| F-3     | 13 | HZY6-90103-000     | BOLT-WASHER, 10X32    | 1       |                               |
| F-3     | 14 | HZY3-90120-000     | BOLT, DRAIN PLUG      | 1       |                               |
| F-3     | 15 | HZY6-90123-000     | BOLT-WASHER, 10X40    | 7       |                               |
| F-3     | 16 | HZY1-90205-000     | NUT, SELF-LOCK, 6MM   | 1       |                               |
| F-3     | 17 | HZV4-90302-000     | NUT, SELF-LOCK, 5MM   | 1       |                               |
| F-3     | 18 | HZV5-90756-000     | DOWEL PIN, 6X10       | 2       |                               |
| F-3     | 19 | HZW4-91301-003     | O-RING, 6.9X1.45      | 2       |                               |
| F-3     | 20 | HCO-92101-06050-4J | BOLT, HEX., 6X50      | 1       |                               |
| F-3     | 21 | HCO-93700-05050-4J | SCREW, OVAL, 5X50     | 1       |                               |
| F-3     | 22 | HCO-95005-50140-30 | TUBE, 5X140           | 1       | (HC-95005-50001-30M)<br>LD,LU |
| F-3     | 22 | HCO-95005-50270-30 | TUBE, 5X270           | 1       | (HC-95005-50001-30M)<br>XU    |
|         |    |                    |                       |         |                               |
|         |    |                    |                       |         |                               |
|         |    |                    |                       |         |                               |
|         |    |                    |                       |         |                               |
|         |    |                    |                       |         |                               |
|         |    |                    |                       |         |                               |
|         |    |                    |                       |         |                               |









[illegible]




| Ref.No. |    | Part No.       | Description             | Q' ty   | Remarks |
|---------|----|----------------|-------------------------|---------|---------|
|         |    |                |                         | BFT115A |         |
| F-4     | 1  | H921-17936-000 | WASHER, PIVOT           | 1       |         |
| F-4     | 2  | HZW1-19210-B04 | IMPELLER, PUMP          | 1       |         |
| F-4     | 3  | HZY6-19221-A00 | HOUSING, IMPELLER       | 1       |         |
| F-4     | 4  | HZW1-19223-B00 | LINER, PUMP             | 1       |         |
| F-4     | 5  | HZY6-19231-000 | COVER, IMPELLER         | 1       |         |
| F-4     | 6  | HZY6-19234-000 | GASKET B, IMPELLER      | 1       |         |
| F-4     | 7  | HZY6-19251-000 | TUBE, WATER(L)          | 1       | LD,LU   |
| F-4     | 7  | HZY6-19251-611 | TUBE, WATER(XL)         | 1       | XU      |
| F-4     | 8  | HZW1-19253-B01 | RING, WATER TUBE SEAL   | 1       |         |
| F-4     | 9  | HZY6-24310-000 | ROD COMP., SHIFT        | 1       |         |
| F-4     |    |                |                         |         |         |
| F-4     | 10 | HZY3-24318-000 | SPRING, SHIFT ROD       | 1       |         |
| F-4     | 11 | HZY6-24343-000 | HOLDER, SHIFT ROD       | 1       |         |
| F-4     | 12 | HZW1-40204-000 | GROMMET, EXTENSION CASE | 1       |         |
| F-4     | 13 | HZY6-41112-010 | SHAFT, VERTICAL(L)      | 1       | LD,LU   |
| F-4     | 13 | HZY6-41112-611 | SHAFT, VERTICAL(XL)     | 1       | XU      |
| F-4     | 14 | HZW1-41116-B00 | SLINGER, OIL            | 1       |         |
| F-4     | 15 | HZZ3-41117-000 | HOUSING, WATER SEAL     | 1       |         |
| F-4     | 16 | HZY6-41131-000 | GEAR, PINION            | 1       |         |
| F-4     | 17 | H881-90105-000 | BOLT, HEX., 6X12        | 1       |         |
| F-4     | 18 | HZW9-90105-000 | BOLT, FLANGE, 6X20      | 2       |         |
| F-4     | 19 | HZY6-90116-000 | BOLT-WASHER, 8X40       | 4       |         |
| F-4     | 20 | HZW1-90242-000 | NUT, LOCK, 64MM         | 1       |         |
| F-4     | 21 | HZW5-90303-000 | NUT, HEX., 18MM         | 1       |         |
| F-4     | 22 | H723-90472-000 | WASHER, PLAIN, 12MM     | 1       |         |
| F-4     | 23 | HZW1-90518-B00 | SHIM A, GEAR(0.10)      | 1       |         |
| F-4     | 23 | HZW1-90519-B00 | SHIM B, GEAR(0.15)      | 1       |         |
| F-4     | 23 | HZW1-90520-B00 | SHIM C, GEAR(0.30)      | 1       |         |
| F-4     | 23 | HZW1-90521-B00 | SHIM D, GEAR(0.50)      | 1       |         |










| Ref.No. |    | Part No.         | Description                    | Q' ty   | Remarks                              |
|---------|----|------------------|--------------------------------|---------|--------------------------------------|
|         |    |                  |                                | BFT115A |                                      |
| F-5     | 1  | HZY6-24101-000   | SHIFTER, CLUTCH                | 1       |                                      |
| F-5     | 2  | HZW1-24102-B00   | PIN, SHIFTER, 8X47             | 1       |                                      |
| F-5     | 3  | HZW1-24103-B00   | RING, CROSS PIN                | 1       |                                      |
| F-5     | 4  | HZY6-24122-000   | SLIDER, SHIFT                  | 1       |                                      |
| F-5     | 5  | HZY6-24123-000   | SPRING, SHIFT                  | 2       |                                      |
| F-5     | 6  | HZY6-24124-000   | PLATE, SHIFT                   | 1       |                                      |
| F-5     | 7  | HZY6-41140-000   | GEAR COMP., BEVEL(FORWARD 30T) | 1       |                                      |
| F-5     | 8  | HZY6-41151-000   | GEAR, BEVEL(RVS. 30T)          | 1       |                                      |
| F-5     | 9  | HZY6-41161-000   | SHAFT, PROPELLER               | 1       |                                      |
| F-5     | 10 | HZY6-41201-000ZC | HOLDER, PROPELLER SHAFT        | 1       | *T107* BAY BLUE                      |
| F-5     | 11 | HZY3-58130-T00   | PROPELLER COMP., THREE BLADES  | 1       | (14-1/2X15)(SUS)                     |
| F-5     | 11 | HZY3-58130-T10   | PROPELLER COMP., THREE BLADES  | 1       | (14-1/4X17)(SUS)                     |
| F-5     | 11 | HZY3-58130-T20   | PROPELLER COMP., THREE BLADES  | 1       | (14X19)(SUS)                         |
| F-5     | 11 | HZY3-58130-T30   | PROPELLER COMP., THREE BLADES  | 1       | (14X21)(SUS)                         |
| F-5     | 11 | HZY3-58130-T40   | PROPELLER COMP., THREE BLADES  | 1       | (14-1/2X23)(SUS)                     |
| F-5     | 11 | HZY3-58130-T50   | PROPELLER COMP., THREE BLADES  | 1       | (14X25)(SUS)                         |
| F-5     | 11 | HZY3-58130-V01ZA | PROPELLER COMP., THREE BLADES  | 1       | (15-1/2X13)(AL)<br>*NH283* STIN GRAY |
| F-5     | 11 | HZY3-58130-V11ZA | PROPELLER COMP., THREE BLADES  | 1       | (15-1/4X15)(AL)<br>*NH283* STIN GRAY |
| F-5     | 11 | HZY3-58130-V21ZA | PROPELLER COMP., THREE BLADES  | 1       | (15X17)(AL)<br>*NH283* STIN GRAY     |
| F-5     | 11 | HZY3-58130-V31ZA | PROPELLER COMP., THREE BLADES  | 1       | (14-3/4X19)(AL)<br>*NH283* STIN GRAY |
| F-5     | 11 | HZY3-58130-V41ZA | PROPELLER COMP., THREE BLADES  | 1       | (14-1/2X21)(AL)<br>*NH283* STIN GRAY |
| F-5     | 11 | HZY3-58130-V51ZA | PROPELLER COMP., THREE BLADES  | 1       | (14-1/4X23)(AL)<br>*NH283* STIN GRAY |
| F-5     | 12 | HZY6-90104-000   | BOLT, FLANGE, 10X40            | 2       |                                      |
| F-5     | 13 | HZW1-90301-B00   | NUT, CASTLE, 18MM              | 1       |                                      |
| F-5     | 14 | HZY3-90506-000   | WASHER, PROPELLER THRUST       | 1       |                                      |
| F-5     | 15 | HZW5-90509-711   | WASHER, THRUST BEARING         | 1       |                                      |
| F-5     | 16 | HZY3-90512-000   | WASHER, PROPELLER              | 1       |                                      |
| F-5     | 17 | HZY3-90528-000   | SHIM A, BEVEL(0.10)            | 1       |                                      |
| F-5     | 17 | HZY3-90529-000   | SHIM B, BEVEL(0.15)            | 1       |                                      |




[illegible]




[illegible]




[illegible]




[illegible]



| Ref.No. |    | Part No.        | Description                   | Q' ty   | Remarks        |
|---------|----|-----------------|-------------------------------|---------|----------------|
|         |    |                 |                               | BFT115A |                |
| F-7-20  | 1  | HZY6-32370-004  | BOX ASSY., JUNCTION           | 1       |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  | 2  | HZY6-32371-004  | COVER COMP., FUSE             | 1       |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  | 3  | HZY6-38228-003  | FUSE, BLOCK 100A(L TYPE)      | 2       |                |
| F-7-20  | 4  | HZY6-38235-004  | PULLER, MINI FUSE             | 1       |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  | 5  | HSDA-39794-004  | RELAY ASSY., FUEL PUMP(DENSO) | 1       |                |
| F-7-20  | 6  | HZY6-39794-003  | RELAY ASSY., POWER(12V-20A)   | 3       | (MICRO ISO 4P) |
| F-7-20  | 7  | HZW9-90013-000  | BOLT, FLANGE, 6X12            | 3       |                |
| F-7-20  | 8  | HZW5-90018-000  | BOLT, FLANGE, 6X20            | 4       |                |
| F-7-20  | 9  | HZY6-90135-004  | SCREW-WASHER, 5X15            | 2       |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  |    |                 |                               |         |                |
| F-7-20  | 10 | HCO-98200-41000 | FUSE, MINI(10A)               | 4       |                |
| F-7-20  | 11 | HCO-98200-41500 | FUSE, MINI(15A)               | 3       |                |
| F-7-20  | 12 | HCO-98200-43000 | FUSE, MINI(30A)               | 3       |                |
|         |    |                 |                               |         |                |
|         |    |                 |                               |         |                |
|         |    |                 |                               |         |                |
|         |    |                 |                               |         |                |
|         |    |                 |                               |         |                |
|         |    |                 |                               |         |                |




[illegible]




[illegible]




| Ref.No. |    | Part No.         | Description                   | Q' ty   | Remarks         |
|---------|----|------------------|-------------------------------|---------|-----------------|
|         |    |                  |                               | BFT115A |                 |
| F-8-10  | 1  | HMG9-35701-950   | BAND(BLACK 3.5X140)           | 1       |                 |
| F-8-10  | 2  | HZY6-40105-020   | GROMMET, REMOTE CONTROL CABLE | 1       |                 |
| F-8-10  | 3  | HZW1-40107-700   | GROMMET, UNDER CASE(C)        | 1       |                 |
| F-8-10  | 4  | HZY3-40119-003   | BAND, UNDER CASE GROMMET      | 1       |                 |
| F-8-10  | 5  | HZY6-40154-000ZC | BRACKET, FR. UNDER COVER      | 1       | *T107* BAY BLUE |
| F-8-10  | 6  | HZY6-40155-000   | BRACKET, R. SIDE COVER        | 1       |                 |
| F-8-10  | 7  | HZY6-40157-000   | BRACKET, L. SIDE COVER        | 1       |                 |
| F-8-10  | 8  | HZY6-60180-003   | CABLE COMP. A, COVER LOCK     | 1       |                 |
| F-8-10  | 9  | HZY6-60185-003   | CABLE COMP. B, COVER LOCK     | 1       |                 |
| F-8-10  | 10 | HZY3-63201-000ZC | LEVER, COVER LOCK             | 1       | *T107* BAY BLUE |
| F-8-10  | 11 | HZY3-63205-000   | BUSH A, COVER LOCK            | 7       |                 |
| F-8-10  | 12 | HZY6-63205-000   | BUSH A, COVER LOCK            | 1       |                 |
| F-8-10  | 13 | HZY3-63208-000   | BUSH B, COVER LOCK            | 1       |                 |
| F-8-10  | 14 | HZY3-63212-000   | SPRING, COVER LOCK HOOK       | 2       |                 |
| F-8-10  | 15 | HZY6-63212-000   | SPRING, COVER LOCK HOOK       | 1       |                 |
| F-8-10  | 16 | HZY6-63223-000   | SPRING, LOCK LEVER RETURN     | 1       |                 |
| F-8-10  | 17 | HZY3-63224-000   | SHAFT, COVER OPEN             | 1       |                 |
| F-8-10  | 18 | HZY6-63225-000   | SHAFT, FR. LOCK               | 1       |                 |
| F-8-10  | 19 | HZY6-63240-000   | LOCK COMP., FR.               | 1       | ~#6000128       |
| F-8-10  | 19 | HZY6-63240-010   | LOCK COMP., FR.               | 1       | #6000129~       |
| F-8-10  | 20 | HZY3-63260-000   | LOCK COMP., SIDE              | 2       | ~#6000128       |
| F-8-10  | 20 | HZY3-63260-C00   | LOCK COMP., SIDE              | 2       | #6000129~       |
| F-8-10  | 21 | HZC0-63515-700   | CAP, L. SIDE COVER            | 1       |                 |
| F-8-10  | 22 | HZY6-90001-000   | BOLT, FLANGE, 8X55            | 2       |                 |
| F-8-10  | 23 | HZY3-90030-000   | BOLT, FLANGE, 6X22            | 2       |                 |
| F-8-10  | 24 | HZY6-90105-000   | BOLT-WASHER, 8X30             | 2       |                 |
| F-8-10  | 25 | HMM8-90501-610   | WASHER, PLAIN, 8MM            | 1       |                 |
| F-8-10  | 26 | HMM8-90502-610   | WASHER, PLAIN, 10MM           | 1       |                 |
| F-8-10  | 27 | HZW9-90506-000   | WASHER, WAVE, 10MM            | 2       |                 |




[illegible]




| Ref.No. |    | Part No.           | Description                | Q' ty   | Remarks         |
|---------|----|--------------------|----------------------------|---------|-----------------|
|         |    |                    |                            | BFT115A |                 |
| F-8-20  | 1  | HZY6-19289-000     | CAP, WATER JOINT           | 1       |                 |
| F-8-20  | 2  | HZY6-35640-003     | SWITCH ASSY., POWER TILT   | 1       |                 |
| F-8-20  | 3  | HZY3-35645-000     | STAY, POWER TILT SWITCH    | 1       |                 |
| F-8-20  | 4  | HZY6-40114-010     | GROMMET, POWER TILT SWITCH | 1       |                 |
| F-8-20  | 5  | HZY6-40116-000     | GROMMET, UNDER COVER       | 1       |                 |
| F-8-20  | 6  | HZY6-40151-010ZD   | COVER, FR. SEPARATE        | 1       | *T107* BAY BLUE |
| F-8-20  | 7  | HZY6-40152-300     | SEAL, FR. SEPARATE COVER   | 1       |                 |
| F-8-20  | 8  | HZY6-40212-020ZC   | COVER, DRAIN PLUG          | 1       | *T107* BAY BLUE |
| F-8-20  | 9  | HZY6-63711-010ZC   | COVER, R. ENGINE UNDER     | 1       | *T107* BAY BLUE |
| F-8-20  | 10 | HZY6-63716-010ZC   | COVER, L. ENGINE UNDER     | 1       | *T107* BAY BLUE |
| F-8-20  | 11 | HZY6-63718-000     | SEAL A, COVER UNDER        | 1       |                 |
| F-8-20  | 12 | HZY6-63719-000     | SEAL B, COVER UNDER        | 1       |                 |
| F-8-20  | 13 | HZY6-82873-000     | GROMMET, WATER CHECK       | 1       |                 |
| F-8-20  | 14 | HZY3-90111-000     | BOLT, SPECIAL, 6X17        | 12      |                 |
| F-8-20  | 15 | HZV5-90127-003     | SCREW, RIVET, 5X10         | 2       |                 |
| F-8-20  | 16 | HZY6-90301-000     | NUT, CLIP                  | 6       |                 |
| F-8-20  | 17 | H921-90302-000     | NUT, HEX., 16MM            | 1       |                 |
| F-8-20  | 18 | HZB5-90626-730     | CLIP(10.7MM)               | 2       |                 |
| F-8-20  | 19 | HHC4-90653-900     | CLIP, MUDGUARD             | 6       |                 |
| F-8-20  | 20 | HKJ2-90683-003     | CLIP, WIRE HARNESS         | 1       |                 |
| F-8-20  | 21 | HZY6-91553-000     | COLLAR, DISTANCE, 6.5X9X5  | 6       |                 |
| F-8-20  | 22 | HCO-93500-06025-4J | SCREW, PAN, 6X25           | 6       |                 |
| F-8-20  | 23 | HCO-95011-62000    | RUBBER B, STAND STOPPER    | 2       |                 |
|         |    |                    |                            |         |                 |
|         |    |                    |                            |         |                 |
|         |    |                    |                            |         |                 |
|         |    |                    |                            |         |                 |
|         |    |                    |                            |         |                 |
|         |    |                    |                            |         |                 |
|         |    |                    |                            |         |                 |




| Ref.No. |    | Part No.         | Description                  | Q' ty   | Remarks         |
|---------|----|------------------|------------------------------|---------|-----------------|
|         |    |                  |                              | BFT115A |                 |
| F-9     | 1  | HZW1-15665-020   | PIPE COMP., OIL LEVEL        | 1       |                 |
| F-9     | 2  | HGHB-16163-610   | CLIP, TUBE                   | 1       |                 |
| F-9     | 3  | HMN5-17195-000   | T-JOINT                      | 1       |                 |
| F-9     | 4  | HZV5-17202-310   | COLLAR, DISTANCE, 6.5X11X7.5 | 1       |                 |
| F-9     | 5  | HZY6-18130-000ZA | GUIDE COMP., EX.             | 1       | *NH8* DARK GRAY |
| F-9     | 6  | HZY6-18135-003   | GASKET, EX. GUIDE            | 1       |                 |
| F-9     | 7  | HZY6-18211-000   | PORT, IDLE EXHAUST           | 1       |                 |
| F-9     | 8  | HZY6-18212-000   | GASKET, IDLE EX. PORT        | 1       |                 |
| F-9     | 9  | HZY6-19256-000   | TUBE, WATER RELIEF           | 1       |                 |
| F-9     | 10 | HZY6-19267-010   | TUBE F, WATER                | 1       |                 |
| F-9     | 11 | HZY3-19270-000   | NUT, WATER MOUTH             | 1       |                 |
| F-9     | 12 | HZY3-19271-000   | JOINT, WATER HOSE            | 1       |                 |
| F-9     | 13 | HZY3-19272-000   | SEAT, WATER MOUTH            | 1       |                 |
| F-9     | 14 | HZZ3-19277-000   | COVER, FLUSH VALVE           | 1       |                 |
| F-9     | 15 | HZW9-19279-000   | SPRING, FLUSH VALVE          | 1       |                 |
| F-9     | 16 | HZY6-19290-003   | VALVE ASSY., RELIEF          | 1       |                 |
| F-9     | 17 | HZW9-19291-000   | VALVE, FLASH                 | 1       |                 |
| F-9     | 18 | HZY6-19295-000   | COVER, RELIEF VALVE          | 1       |                 |
| F-9     | 19 | HZW9-19297-000   | PACKING, FLASH VALVE         | 1       |                 |
| F-9     | 20 | HZW9-19317-000   | O-RING, THERMOSTAT COVER     | 1       |                 |
| F-9     | 21 | HZY6-23170-000ZA | CASE COMP., MOUNT            | 1       | *NH8* DARK GRAY |
| F-9     | 22 | HZY3-23173-010   | RUBBER, MOUNT CASE SEAL      | 1       |                 |
| F-9     | 23 | HZY6-90014-000   | BOLT, FLANGE, 8X30           | 4       |                 |
| F-9     | 24 | HZW9-90016-000   | BOLT, FLANGE, 6X25           | 3       |                 |
| F-9     | 25 | HZY3-90017-000   | BOLT, FLANGE, 6X16           | 1       |                 |
| F-9     | 26 | HZY3-90030-000   | BOLT, FLANGE, 6X22           | 2       |                 |
| F-9     | 27 | HZY6-90045-000   | BOLT, STUD, 10X55            | 2       |                 |
| F-9     | 28 | HZY3-90056-000   | BOLT, FLANGE, 6X12           | 1       |                 |
| F-9     | 29 | HZY3-90601-030   | CLAMP, TUBE(D10.5)           | 6       |                 |



[illegible]




| Ref.No. |    | Part No.         | Description                   | Q' ty   | Remarks         |
|---------|----|------------------|-------------------------------|---------|-----------------|
|         |    |                  |                               | BFT115A |                 |
| F-10    | 1  | HZW1-06411-020   | METAL KIT, ANODE              | 1       |                 |
| F-10    | 2  | HZV1-24210-010   | SPRING COMP., CLICK           | 1       |                 |
| F-10    | 3  | HZV4-24221-010   | SPRING, CLICK ASSIST          | 1       |                 |
| F-10    | 4  | HZY6-35660-013   | SENSOR ASSY., TRIM ANGLE      | 1       |                 |
| F-10    | 5  | HZX1-50100-000   | FRAME COMP., MOUNTING         | 1       |                 |
| F-10    | 6  | HZW5-50151-000   | MOUNT COMP., UPPER RUBBER     | 1       |                 |
| F-10    | 7  | HZY6-50167-000   | HOLDER, UPPER MOUNTING        | 1       |                 |
| F-10    | 8  | HZY6-50168-003   | GASKET, UPPER MOUNTING HOLDER | 1       |                 |
| F-10    | 9  | HZW1-50201-040ZC | CASE, SWIVEL                  | 1       | *T107* BAY BLUE |
| F-10    | 10 | HZZ5-50211-000   | LINER, SWIVEL CASE            | 2       |                 |
| F-10    | 11 | HZW1-50214-000   | BUSH, SWIVEL CASE             | 2       |                 |
| F-10    | 12 | HZW1-50301-070ZC | BRACKET, R. STERN             | 1       | *T107* BAY BLUE |
| F-10    | 13 | HZW1-50311-070ZC | BRACKET, L. STERN             | 1       | *T107* BAY BLUE |
| F-10    | 14 | HZW5-50341-010   | ROD, ADJUSTING                | 1       |                 |
| F-10    | 15 | HZY9-50381-000   | SHAFT, TILTING                | 1       |                 |
| F-10    | 16 | HZV5-50522-000   | BUSH, TILT ARM                | 2       |                 |
| F-10    | 17 | HZW1-50527-000   | BRACKET, TILTING              | 1       |                 |
| F-10    | 18 | HZW1-50529-000   | STOPPER, TILT                 | 2       |                 |
| F-10    | 19 | HZW1-53234-010   | PLATE, STEERING               | 1       |                 |
| F-10    | 20 | HZW5-53234-010   | PLATE, STEERING               | 1       |                 |
| F-10    | 21 | HZW1-53238-010   | ROD, STEERING                 | 1       |                 |
| F-10    | 22 | HZW1-56516-000   | RECEIVER, THRUST              | 2       |                 |
| F-10    | 23 | HZW1-56539-000   | COLLAR, LOWER CYLINDER        | 1       |                 |
| F-10    | 24 | HZW9-90009-000   | BOLT, FLANGE, 6X23            | 2       |                 |
| F-10    | 25 | HZW5-90101-000   | BOLT, STUD, 12X150            | 2       |                 |
| F-10    | 26 | HZW1-90102-000   | BOLT, 1/4-28UNF               | 2       |                 |
| F-10    | 27 | HZW1-90105-000   | BOLT, 3/8-24UNF               | 1       |                 |
| F-10    | 28 | HZW9-90105-000   | BOLT, FLANGE, 6X20            | 2       |                 |
| F-10    | 29 | HZW1-90108-000   | BOLT, HEX., 10X235            | 1       |                 |




| Ref.No. |    | Part No.       | Description               | Q' ty   | Remarks |
|---------|----|----------------|---------------------------|---------|---------|
|         |    |                |                           | BFT115A |         |
| F-10    | 30 | H881-90110-000 | BOLT, HEX., 6X14          | 1       |         |
| F-10    | 31 | HZZ3-90129-000 | BOLT, HEX., 12X119        | 6       |         |
| F-10    |    |                |                           |         |         |
| F-10    | 31 | HZX2-90129-000 | BOLT, HEX., 12X130        | 4       |         |
| F-10    |    |                |                           |         |         |
| F-10    | 32 | HZW9-90154-000 | BOLT, FLANGE, 10X25       | 2       |         |
| F-10    | 33 | HZW5-90302-003 | NUT, FLANGE, 12MM         | 2       |         |
| F-10    | 34 | HZV5-90304-013 | NUT, SELF-LOCK(7/8-14UNF) | 1       |         |
| F-10    | 35 | HZW1-90304-013 | NUT, SELF-LOCK(25X2.0)    | 1       |         |
| F-10    | 36 | HZW5-90304-000 | NUT, ADJUSTER ROD         | 1       |         |
| F-10    | 37 | HZW4-90306-003 | NUT, FLANGE, 10MM         | 3       |         |
| F-10    | 38 | HZV5-90307-003 | NUT, SELF-LOCK(3/8-24UNF) | 2       |         |
| F-10    | 39 | HZV5-90501-000 | WASHER, WAVE, 40MM        | 1       |         |
| F-10    | 40 | HZV5-90502-000 | WASHER, WAVE, 26MM        | 2       |         |
| F-10    | 41 | HZV5-90504-000 | WASHER, THRUST, 34MM      | 1       |         |
| F-10    | 42 | HZV4-90514-000 | WASHER, 10MM              | 3       |         |
| F-10    | 43 | H921-90511-000 | WASHER, PLAIN, 10MM       | 1       |         |
| F-10    | 44 | HZV5-90552-000 | WASHER, PLAIN, 12MM       | 6       |         |
| F-10    |    |                |                           |         |         |
| F-10    |    |                |                           |         |         |
| F-10    |    |                |                           |         |         |
| F-10    | 45 | HZV5-90559-000 | WASHER, PLAIN, 12MM       | 12      |         |
| F-10    |    |                |                           |         |         |
| F-10    |    |                |                           |         |         |
| F-10    |    |                |                           |         |         |
| F-10    | 46 | HZV5-90559-000 | WASHER, PLAIN, 12MM       | 1       |         |
| F-10    | 47 | HZV5-90563-000 | WASHER, PLAIN, 10MM       | 2       |         |
| F-10    | 48 | HZV5-90651-000 | CIRCLIP, EXTERNAL, 39MM   | 1       |         |
| F-10    | 49 | H763-90681-A01 | CLIP, WIRE HARNESS        | 1       |         |





[illegible]





| Ref.No. |    | Part No.       | Description             | Q' ty   | Remarks  |
|---------|----|----------------|-------------------------|---------|----------|
|         |    |                |                         | BFT115A |          |
| F-11    | 1  | HZY3-30280-003 | BREAKER ASSY.           | 1       |          |
| F-11    | 2  | HZY3-31106-003 | BRUSH ASSY.             | 1       |          |
| F-11    | 3  | HZV5-36104-821 | TUBE, SPIRAL            | 1       |          |
| F-11    | 4  | HZY6-36120-013 | MOTOR ASSY., POWER TILT | 1       |          |
| F-11    | 5  | HZY3-36122-013 | BRACKET ASSY.           | 1       |          |
| F-11    | 6  | HZY3-36123-013 | ARMATURE COMP.          | 1       |          |
| F-11    | 7  | HZY6-36129-013 | YOKE ASSY.              | 1       |          |
| F-11    | 8  | HZV5-36136-821 | SPRING, MOTOR           | 2       |          |
| F-11    | 9  | HZY3-40219-013 | WIRE, LEAD(1.5X116MM)   | 1       |          |
| F-11    | 10 | HZV5-50214-003 | BUSH, SWIVEL CASE       | 2       |          |
| F-11    | 11 | HZY6-56000-043 | TRIM-TILT ASSY., POWER  | 1       | LD,LU,XU |
| F-11    |    |                |                         |         |          |
| F-11    |    |                |                         |         |          |
| F-11    |    |                |                         |         |          |
| F-11    | 12 | HZY6-56100-013 | PUMP ASSY.              | 1       | LD,LU,XU |
| F-11    |    |                |                         |         |          |
| F-11    |    |                |                         |         |          |
| F-11    |    |                |                         |         |          |
| F-11    | 13 | HZW1-56110-701 | ROD COMP., PISTON(B)    | 2       |          |
| F-11    | 14 | HZW1-56113-701 | JOINT, DRIVE            | 1       |          |
| F-11    | 15 | HZW1-56115-305 | GUIDE COMP., ROD        | 2       |          |
| F-11    | 16 | HZY9-56115-003 | GUIDE COMP., ROD        | 2       |          |
| F-11    | 17 | HZW1-56116-701 | FILTER B                | 1       |          |
| F-11    | 18 | HZV5-56117-821 | RING, BACK UP           | 1       |          |
| F-11    | 19 | HZV5-56118-820 | BUSH, MOTOR CODE        | 1       |          |
| F-11    | 20 | HZW1-56120-305 | ROD COMP., PISTON       | 1       |          |
| F-11    | 21 | HZY9-56120-003 | ROD COMP., PISTON       | 1       |          |
| F-11    | 22 | HZW1-56130-702 | PISTON COMP., FREE      | 1       |          |
| F-11    | 23 | HZY3-56170-013 | VALVE COMP., MANUAL     | 1       |          |




| Ref.No. |    | Part No.        | Description            | Q' ty   | Remarks |
|---------|----|-----------------|------------------------|---------|---------|
|         |    |                 |                        | BFT115A |         |
| F-11    | 24 | HZW1-56180-701  | VALVE COMP., RESERVOIR | 1       |         |
| F-11    | 25 | HZV5-56513-000  | BUSH, LOWER CYLINDER   | 2       |         |
| F-11    | 26 | HZW1-56532-000  | PIN, UPPER CYLINDER    | 1       |         |
| F-11    | 27 | HZW1-56851-703  | TANK, OIL              | 1       |         |
| F-11    | 28 | HZW1-56860-701  | CAP COMP., OIL TANK    | 1       |         |
| F-11    | 29 | HZW1-90113-702  | BOLT, RECESSED         | 3       |         |
| F-11    | 30 | HZW1-90114-702  | BOLT, SOCKET(A)        | 1       |         |
| F-11    | 31 | HZW1-90115-702  | BOLT, SOCKET(B)        | 2       |         |
| F-11    | 32 | HZW1-90116-702  | BOLT, HEX.             | 4       |         |
| F-11    | 33 | HZV5-90119-000  | SCREW, PAN, 6X8        | 1       |         |
| F-11    | 34 | HZW1-90652-702  | CIRCLIP, INTERNAL      | 1       |         |
| F-11    | 35 | HZV5-91203-821  | OIL SEAL               | 1       |         |
| F-11    | 36 | HZW1-91207-013  | O-RING, 2.0X70.5       | 1       |         |
| F-11    | 37 | HZV5-91302-821  | O-RING, 1.8X69.6       | 1       |         |
| F-11    | 38 | HZV5-91316-821  | O-RING, 3.5X38.7       | 2       |         |
| F-11    | 39 | HZW1-91352-702  | O-RING, 1.8X7.7        | 6       |         |
| F-11    | 40 | HZW1-91353-703  | O-RING, 1.9X11         | 1       |         |
| F-11    | 41 | HZW1-91354-701  | O-RING, 3.5X35.7       | 2       |         |
| F-11    | 42 | HZW1-91355-701  | O-RING, 3.5X41.7       | 1       |         |
| F-11    | 43 | HZW1-91357-701  | O-RING SET, 3.5X31.7   | 2       |         |
| F-11    | 44 | HZW1-91358-701  | SEAL, WATER            | 2       |         |
| F-11    | 45 | HZW1-91361-701  | PACKING                | 2       |         |
| F-11    | 46 | HZW1-91557-701  | COLLAR, ORIFICE        | 1       |         |
| F-11    | 47 | HCO-94540-15029 | E-RING, 15MM           | 2       |         |
|         |    |                 |                        |         |         |
|         |    |                 |                        |         |         |
|         |    |                 |                        |         |         |
|         |    |                 |                        |         |         |
|         |    |                 |                        |         |         |
















[illegible]





[illegible]




| Ref.No. |    | Part No.       | Description                 | Q' ty   | Remarks |
|---------|----|----------------|-----------------------------|---------|---------|
|         |    |                |                             | BFT115A |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   | 2  | HZZ5-06325-600 | CABLE SET, PANEL INDICATOR  | 1       | (20FT)  |
| FOP-6   | 2  | HZZ5-06325-700 | CABLE SET, PANEL INDICATOR  | 1       | (25FT)  |
| FOP-6   | 2  | HZZ5-06325-800 | CABLE SET, PANEL INDICATOR  | 1       | (30FT)  |
| FOP-6   |    |                |                             |         |         |
| FOP-6   | 4  | HZZ5-32185-600 | CORD ASSY., INDICATOR(20FT) | 1       |         |
| FOP-6   | 4  | HZZ5-32185-700 | CORD ASSY., INDICATOR(25FT) | 1       |         |
| FOP-6   | 4  | HZZ5-32185-800 | CORD ASSY., INDICATOR(30FT) | 1       |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   | 9  | HZZ5-32580-600 | CABLE ASSY., SWITCH PANEL   | 1       | (20FT)  |
| FOP-6   | 9  | HZZ5-32580-700 | CABLE ASSY., SWITCH PANEL   | 1       | (25FT)  |
| FOP-6   | 9  | HZZ5-32580-800 | CABLE ASSY., SWITCH PANEL   | 1       | (30FT)  |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   | 12 | H952-32901-770 | TIE, CABLE(NATURAL)(2.4X92) | 6       |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |
| FOP-6   |    |                |                             |         |         |




| Ref.No. |    | Part No.        | Description                   | Q' ty   | Remarks |
|---------|----|-----------------|-------------------------------|---------|---------|
|         |    |                 |                               | BFT115A |         |
| FOP-6-1 | 1  | HZZ3-06323-R30  | PANEL KIT, SWITCH(4-LED)      | 1       | LD      |
| FOP-6-1 | 1  | HZZ3-06323-R10  | PANEL KIT, SWITCH(4-LED) (EU) | 1       | LU,XU   |
| FOP-6-1 | 2  | HMT8-18334-770  | NUT, FLANGE, 5MM              | 4       |         |
| FOP-6-1 | 3  | HZZ3-32346-R31  | PANEL, CONTROL                | 1       | LD      |
| FOP-6-1 | 3  | HZZ3-32346-R11  | PANEL, CONTROL                | 1       | LU,XU   |
| FOP-6-1 | 4  | HZZ5-32545-000  | HARNESS ASSY., SWITCH PANEL   | 1       |         |
| FOP-6-1 | 5  | HZV5-32823-003  | PLUG, INNER CONNECTOR         | 8       |         |
| FOP-6-1 | 6  | HZV5-32824-003  | PLUG, OUTER CONNECTOR         | 3       |         |
| FOP-6-1 | 7  | HZZ3-35100-R11  | SWITCH ASSY., COMBINATION     | 1       |         |
| FOP-6-1 | 8  | HZV5-36180-033  | SWITCH ASSY., EMERGENCY STOP  | 1       |         |
| FOP-6-1 | 9  | HZV4-36182-651  | CORD COMP., EMERGENCY         | 1       |         |
| FOP-6-1 | 10 | HZV4-36187-652  | CLIP, EMERGENCY LOCK          | 1       |         |
| FOP-6-1 | 11 | HZZ5-37210-712  | LAMP ASSY., INDICATION(4-LED) | 1       |         |
| FOP-6-1 | 12 | H341-38403-672  | PLATE, WINKER BUZZER          | 1       |         |
| FOP-6-1 | 13 | HZV5-38410-003  | BUZZER COMP., WARNING         | 1       |         |
| FOP-6-1 | 14 | HZZ5-38414-003  | BRACKET, BUZZER               | 1       |         |
| FOP-6-1 | 15 | HZW5-90109-000  | SCREW, PAN, 5X40              | 4       |         |
| FOP-6-1 | 16 | H921-90302-000  | NUT, HEX., 16MM               | 1       |         |
| FOP-6-1 | 17 | HSC2-90649-003  | BAND, WIRE HARNESS(NATURAL)   | 1       | (150MM) |
| FOP-6-1 | 18 | HCO-94103-05400 | WASHER, PLAIN, 5MM            | 4       |         |
| FOP-6-1 | 19 | HCO-94111-05400 | WASHER, SPRING, 5MM           | 4       |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |
|         |    |                 |                               |         |         |





[illegible]





| Ref.No. |    | Part No.       | Description                    | Q' ty   | Remarks                |
|---------|----|----------------|--------------------------------|---------|------------------------|
|         |    |                |                                | BFT115A |                        |
| FOP-8   | 1  | HZZ3-06240-R30 | BOX KIT, REMOTE CONTROL        | 1       | (TOP MOUNT SINGLE)(R.) |
| FOP-8   | 2  | HZW5-06241-U00 | SPACER KIT, REMOTE CONTROL BOX | 1       | (TOP MOUNT SINGLE)     |
| FOP-8   | 3  | HZW5-24810-U01 | HOUSING ASSY., L. INNER        | 1       | (TOP MOUNT)            |
| FOP-8   | 4  | HZW5-24811-U01 | HANDLE, REMOTE CONTROL         | 1       |                        |
| FOP-8   | 5  | HZW5-24812-U01 | COVER, L. GRIP                 | 1       |                        |
| FOP-8   | 6  | HZW5-24813-U01 | GRIP, REMOTE CONTROL HANDLE    | 1       |                        |
| FOP-8   | 7  | HZW5-24814-U01 | CAP, GRIP                      | 1       |                        |
| FOP-8   | 8  | HZW5-24815-U01 | CAP, SWITCH                    | 1       |                        |
| FOP-8   | 9  | HZW5-24816-U01 | BUTTON, THROTTLE               | 1       |                        |
| FOP-8   | 10 | HZW5-24817-U01 | PLATE, HANDLE                  | 1       |                        |
| FOP-8   | 11 | HZW5-24818-U01 | PLATE, CABLE CLAMP             | 1       |                        |
| FOP-8   | 12 | HZW5-24819-U01 | BRACKET, REMOTE CONTROL        | 2       | HOUSING                |
| FOP-8   | 13 | HZW5-24820-U01 | HOUSING COMP., REMOTE CONTROL  | 1       | BOX                    |
| FOP-8   | 14 | HZW5-24825-U01 | HOUSING, LEAD                  | 1       |                        |
| FOP-8   | 15 | HZW5-24826-U01 | PLATE, DWELL                   | 1       |                        |
| FOP-8   | 16 | HZW5-24831-U01 | TERMINAL, CABLE                | 2       |                        |
| FOP-8   | 17 | HZW5-24832-U01 | SPACER, CABLE CLAMP            | 1       |                        |
| FOP-8   | 18 | HZW5-24834-U01 | PACKING, SINGLE                | 1       |                        |
| FOP-8   | 19 | HZW7-32530-U00 | SUB HARNESS ASSY., POWER       | 1       | TRIM-TILT(A)           |
| FOP-8   | 20 | HZW5-35370-U02 | SWITCH ASSY., POWER TRIM-TILT  | 1       | (A)                    |
| FOP-8   | 21 | HZZ3-87703-R81 | MARK, REMOTE CONTROL(SINGLE)   | 1       |                        |
| FOP-8   | 22 | HZW5-90101-U00 | SCREW, PAN, 5X16               | 2       |                        |
| FOP-8   | 23 | HZW5-90102-U00 | SCREW, PAN, 5X10               | 1       |                        |
| FOP-8   | 24 | HZW5-90103-U01 | SCREW, PAN, 5X20               | 2       |                        |
| FOP-8   | 25 | HZW5-90104-U00 | SCREW, PAN, 5X18               | 4       |                        |
| FOP-8   | 26 | HZW5-90105-U01 | SCREW, PAN, 4X10               | 2       |                        |
| FOP-8   | 27 | HZW5-90106-U00 | SCREW, PAN, 6X18               | 2       |                        |
| FOP-8   | 28 | HZW5-90107-U00 | SCREW, PAN, 5X40               | 4       |                        |
| FOP-8   | 29 | HZW5-90301-U00 | NUT, HEX., 5MM                 | 4       |                        |



[illegible]




| Ref.No. |    | Part No.       | Description                    | Q' ty   | Remarks              |
|---------|----|----------------|--------------------------------|---------|----------------------|
|         |    |                |                                | BFT115A |                      |
| FOP-8-2 | 1  | HZZ3-06240-R60 | BOX KIT, REMOTE CONTROL        | 1       | (TOP MOUNT DUAL)(R.) |
| FOP-8-2 | 2  | HZW5-06241-U10 | SPACER KIT, REMOTE CONTROL BOX | 1       | (TOP MOUNT DUAL)     |
| FOP-8-2 | 3  | HZW5-24810-U01 | HOUSING ASSY., L. INNER        | 1       | (TOP MOUNT)          |
| FOP-8-2 | 4  | HZW5-24810-U11 | HOUSING ASSY., R. INNER        | 1       | (TOP MOUNT)          |
| FOP-8-2 | 5  | HZW5-24811-U01 | HANDLE, REMOTE CONTROL         | 2       |                      |
| FOP-8-2 | 6  | HZW5-24812-U01 | COVER, L. GRIP                 | 1       |                      |
| FOP-8-2 | 7  | HZW5-24813-U01 | GRIP, REMOTE CONTROL HANDLE    | 2       |                      |
| FOP-8-2 | 8  | HZW5-24813-U21 | COVER, DUAL GRIP               | 1       |                      |
| FOP-8-2 | 9  | HZW5-24814-U01 | CAP, GRIP                      | 2       |                      |
| FOP-8-2 | 10 | HZW5-24816-U01 | BUTTON, THROTTLE               | 2       |                      |
| FOP-8-2 | 11 | HZW5-24817-U01 | PLATE, HANDLE                  | 2       |                      |
| FOP-8-2 | 12 | HZW5-24818-U01 | PLATE, CABLE CLAMP             | 1       |                      |
| FOP-8-2 | 13 | HZW5-24819-U01 | BRACKET, REMOTE CONTROL        | 2       | HOUSING              |
| FOP-8-2 | 14 | HZW5-24820-U21 | HOUSING COMP., DUAL REMOTE     | 1       | CONTROL BOX          |
| FOP-8-2 | 15 | HZW5-24825-U01 | HOUSING, LEAD                  | 2       |                      |
| FOP-8-2 | 16 | HZW5-24826-U01 | PLATE, DWELL                   | 2       |                      |
| FOP-8-2 | 17 | HZW5-24831-U01 | TERMINAL, CABLE                | 4       |                      |
| FOP-8-2 | 18 | HZW5-24832-U01 | SPACER, CABLE CLAMP            | 2       |                      |
| FOP-8-2 | 19 | HZW5-24834-U21 | PACKING, DUAL                  | 1       |                      |
| FOP-8-2 | 20 | HZW7-32530-U00 | SUB HARNESS ASSY., POWER       | 1       | TRIM-TILT(A)         |
| FOP-8-2 | 21 | HZW7-32530-U10 | SUB HARNESS ASSY., POWER       | 1       | TRIM-TILT(B)         |
| FOP-8-2 | 22 | HZW5-35370-U02 | SWITCH ASSY., POWER TRIM-TILT  | 1       | (A)                  |
| FOP-8-2 | 23 | HZW5-35370-U12 | SWITCH ASSY., POWER TRIM-TILT  | 1       | (B)                  |
| FOP-8-2 | 24 | HZZ3-87703-R01 | MARK, REMOTE CONTROL(DUAL)     | 1       |                      |
| FOP-8-2 | 25 | HZW5-90101-U00 | SCREW, PAN, 5X16               | 3       |                      |
| FOP-8-2 | 26 | HZW5-90102-U00 | SCREW, PAN, 5X10               | 2       |                      |
| FOP-8-2 | 27 | HZW5-90103-U01 | SCREW, PAN, 5X20               | 4       |                      |
| FOP-8-2 | 28 | HZW5-90104-U00 | SCREW, PAN, 5X18               | 4       |                      |
| FOP-8-2 | 29 | HZW5-90105-U01 | SCREW, PAN, 4X10               | 4       |                      |




[illegible]




| Ref.No. |    | Part No.        | Description                   | Q' ty   | Remarks           |
|---------|----|-----------------|-------------------------------|---------|-------------------|
|         |    |                 |                               | BFT115A |                   |
| FOP-8-4 | 1  | HZZ3-06240-R40  | BOX KIT, REMOTE CONTROL       | 1       | (FLUSH MOUNT)(R.) |
| FOP-8-4 | 2  | HZW7-24810-U01  | HOUSING ASSY., R. INNER       | 1       | (FLUSH MOUNT)     |
| FOP-8-4 | 3  | HZW7-24811-U01  | HANDLE, REMOTE CONTROL        | 1       |                   |
| FOP-8-4 | 4  | HZW7-24812-U01  | COVER, GRIP                   | 1       |                   |
| FOP-8-4 | 5  | HZW7-24813-U01  | ARM, NEUTRAL LOCK             | 1       |                   |
| FOP-8-4 | 6  | HZW7-24814-U01  | COVER, LOCK ARM               | 1       |                   |
| FOP-8-4 | 7  | HZW7-24815-U01  | SPRING, NEUTRAL LOCK ARM      | 1       |                   |
| FOP-8-4 | 8  | HZW5-24816-U01  | BUTTON, THROTTLE              | 1       |                   |
| FOP-8-4 | 9  | HZW7-24817-U01  | SHAFT, THROTTLE BUTTON        | 1       |                   |
| FOP-8-4 | 10 | HZW5-24826-U01  | PLATE, DWELL                  | 1       |                   |
| FOP-8-4 | 11 | HZW7-24830-U01  | COVER ASSY.                   | 1       |                   |
| FOP-8-4 | 12 | HZW5-24831-U01  | TERMINAL, CABLE               | 2       |                   |
| FOP-8-4 | 13 | HZW5-24832-U01  | SPACER, CABLE CLAMP           | 1       |                   |
| FOP-8-4 | 14 | HZW7-24832-U01  | HOLDER, NEUTRAL LOCK          | 1       |                   |
| FOP-8-4 | 15 | HZW7-24833-U01  | BASE                          | 1       |                   |
| FOP-8-4 | 16 | HZW7-32530-U20  | SUB HARNESS ASSY., POWER      | 1       | TRIM-TILT(C)      |
| FOP-8-4 | 17 | HZW7-35370-U02  | SWITCH ASSY., POWER TRIM-TILT | 1       | (C)               |
| FOP-8-4 | 18 | HZW7-87701-U01  | MARK, HANDLE FLUSH MOUNT      | 1       |                   |
| FOP-8-4 | 19 | HZW7-87703-U00  | MARK, FLUSH MOUNT             | 1       |                   |
| FOP-8-4 | 20 | HZW5-90101-U00  | SCREW, PAN, 5X16              | 1       |                   |
| FOP-8-4 | 21 | HZW7-90101-U01  | SCREW, TRUSS, 4X12            | 1       |                   |
| FOP-8-4 | 22 | HZW7-90102-U01  | SCREW, PAN, 5X30              | 4       |                   |
| FOP-8-4 | 23 | HZW7-90103-U01  | SCREW, PAN, 6X35              | 3       |                   |
| FOP-8-4 | 24 | HZW7-90104-U01  | SCREW, TAPPING, 6X30          | 3       |                   |
| FOP-8-4 | 25 | HZW7-90301-U01  | NUT, HEX., 6MM                | 3       |                   |
| FOP-8-4 | 26 | HZW5-90501-U00  | WASHER, LOCK, 5MM             | 4       |                   |
| FOP-8-4 | 27 | HZW7-90502-U00  | WASHER, PLAIN, 6MM            | 3       |                   |
| FOP-8-4 | 28 | HCO-94540-06029 | E-RING, 6MM                   | 2       |                   |
|         |    |                 |                               |         |                   |




| Ref.No. |    | Part No.       | Description                    | Q' ty   | Remarks |
|---------|----|----------------|--------------------------------|---------|---------|
|         |    |                |                                | BFT115A |         |
| FOP-8-6 | 1  | HZZ3-24800-R00 | BOX ASSY., REMOTE CONTROL      | 1       | LD      |
| FOP-8-6 | 1  | HZZ3-24800-R50 | BOX ASSY., REMOTE CONTROL      | 1       | LU,XU   |
| FOP-8-6 | 2  | HZV5-24811-010 | HANDLE, REMOTE CONTROL         | 1       |         |
| FOP-8-6 | 3  | HZV5-24812-000 | LEVER, HANDLE LOCK             | 1       |         |
| FOP-8-6 | 4  | HZV5-24813-000 | GRIP, REMOTE CONTROL HANDLE    | 1       |         |
| FOP-8-6 | 5  | HZV5-24814-010 | CAP, HANDLE                    | 1       |         |
| FOP-8-6 | 6  | HZV5-24815-010 | BLOCK, NEUTRAL LOCK            | 1       |         |
| FOP-8-6 | 7  | HZV5-24816-000 | SPRING, REMOTE CONTROL HANDLE  | 1       |         |
| FOP-8-6 | 8  | HZV5-24817-000 | PLATE, LEVER SETTING           | 1       |         |
| FOP-8-6 | 9  | HZV5-24818-003 | CLAMP, HARNESS                 | 1       |         |
| FOP-8-6 | 10 | HZV5-24820-010 | HOUSING COMP., REMOTE CONTROL  | 1       | BOX(A)  |
| FOP-8-6 | 11 | HZV5-24830-010 | HOUSING COMP., REMOTE CONTROL  | 1       | BOX(B)  |
| FOP-8-6 | 12 | HZV5-24836-000 | HOUSING, REMOTE CONTROL BOX(C) | 1       |         |
| FOP-8-6 | 13 | HZV5-24841-000 | WHEEL, CONTROL                 | 1       |         |
| FOP-8-6 | 14 | HZV5-24845-000 | ARM COMP., SHIFT LINK          | 1       |         |
| FOP-8-6 | 15 | HZV5-24850-000 | PLATE COMP., SLIDING           | 1       |         |
| FOP-8-6 | 16 | HZV5-24854-000 | COLLAR, SLIDING PLATE          | 1       |         |
| FOP-8-6 | 17 | HZV5-24855-000 | PIVOT, SHIFT                   | 2       |         |
| FOP-8-6 | 18 | HZV5-24860-000 | ARM COMP., LINK JOINT          | 1       |         |
| FOP-8-6 | 19 | HZV5-24865-000 | BRACKET, LINK JOINT            | 1       |         |
| FOP-8-6 | 20 | HZV5-24875-000 | WHEEL, ACCELERATOR             | 1       |         |
| FOP-8-6 | 21 | HZV5-24876-000 | SPRING, ACCELERATOR WHEEL      | 1       |         |
| FOP-8-6 | 22 | HZV5-24878-000 | LEVER, IDLE                    | 1       |         |
| FOP-8-6 | 23 | HZV5-24881-000 | PLATE, SPRING SETTING          | 2       |         |
| FOP-8-6 | 24 | HZV5-24883-000 | SPRING, SHIFT CLICK            | 1       |         |
| FOP-8-6 | 25 | HZV5-24884-000 | SPRING, CHOKE RETURN           | 1       |         |
| FOP-8-6 | 26 | HZV5-24885-000 | SPACER, REMOTE CONTROL BOX     | 1       |         |
| FOP-8-6 | 27 | HZV5-24887-000 | SPACER, CLICK SPRING           | 1       |         |
| FOP-8-6 | 28 | HZV5-24891-000 | BLOCK, THROTTLE FRICTION       | 1       |         |




| Ref.No. |    | Part No.       | Description                    | Q' ty   | Remarks |
|---------|----|----------------|--------------------------------|---------|---------|
|         |    |                |                                | BFT115A |         |
| FOP-8-6 | 29 | HZV5-24892-000 | BOLT, FRICTION                 | 1       |         |
| FOP-8-6 | 30 | HZV5-24894-000 | SPACER, NEUTRAL SWITCH         | 1       |         |
| FOP-8-6 | 31 | HZV5-24895-000 | CLAMP, POWER TILT CORD         | 1       |         |
| FOP-8-6 | 32 | HZV5-24897-000 | PIPE, HARNESS GUIDE            | 1       |         |
| FOP-8-6 | 33 | HZV5-24898-000 | SPACER, CABLE CLAMP            | 1       |         |
| FOP-8-6 | 34 | HZZ5-32530-000 | CABLE ASSY., REMOTE CONTROL(B) | 1       |         |
| FOP-8-6 | 35 | HZV5-32823-003 | PLUG, INNER CONNECTOR          | 7       |         |
| FOP-8-6 | 36 | HZV5-32824-003 | PLUG, OUTER CONNECTOR          | 1       |         |
| FOP-8-6 | 37 | H952-32901-770 | TIE, CABLE(NATURAL)(2.4X92)    | 1       |         |
| FOP-8-6 | 38 | HZZ3-35100-R11 | SWITCH ASSY., COMBINATION      | 1       |         |
| FOP-8-6 | 39 | HZV5-35370-823 | SWITCH ASSY., POWER TRIM-TILT  | 1       |         |
| FOP-8-6 | 40 | HMG9-35701-950 | BAND(BLACK 3.5X140)            | 1       |         |
| FOP-8-6 | 41 | HZV5-36180-033 | SWITCH ASSY., EMERGENCY STOP   | 1       |         |
| FOP-8-6 | 42 | HZV4-36182-651 | CORD COMP., EMERGENCY          | 1       |         |
| FOP-8-6 | 43 | HZV4-36187-652 | CLIP, EMERGENCY LOCK           | 1       |         |
| FOP-8-6 | 44 | HZZ5-37210-013 | LAMP ASSY., INDICATION         | 1       |         |
| FOP-8-6 | 45 | H341-38403-672 | PLATE, WINKER BUZZER           | 1       |         |
| FOP-8-6 | 46 | HZV5-38410-003 | BUZZER COMP., WARNING          | 1       |         |
| FOP-8-6 | 47 | HZZ3-87701-R00 | PLATE, REMOTE CONTROL          | 1       | LD      |
| FOP-8-6 |    |                |                                |         |         |
| FOP-8-6 |    |                |                                |         |         |
| FOP-8-6 | 48 | HZW9-87702-800 | MARK, FAST IDLE                | 1       |         |
| FOP-8-6 | 49 | HZW9-90008-000 | BOLT, FLANGE, 8X35             | 1       |         |
| FOP-8-6 | 50 | HMM4-90105-000 | SCREW, PAN, 6X10               | 1       |         |
| FOP-8-6 | 51 | HZW4-90108-000 | SCREW, FLAT, 5X12              | 2       |         |
| FOP-8-6 | 52 | HZV5-90125-000 | SCREW, 6X95                    | 3       |         |
| FOP-8-6 | 53 | H921-90302-000 | NUT, HEX., 16MM                | 1       |         |
| FOP-8-6 | 54 | HZV4-90304-000 | NUT, HEX., 6MM                 | 3       |         |
| FOP-8-6 | 55 | HZW4-90401-000 | WASHER, PLAIN, 4MM             | 2       |         |




| Ref.No. |    | Part No.           | Description                 | Q' ty   | Remarks |
|---------|----|--------------------|-----------------------------|---------|---------|
|         |    |                    |                             | BFT115A |         |
| FOP-8-6 | 56 | HZW4-90402-000     | WASHER, PLAIN, 5MM          | 2       |         |
| FOP-8-6 | 57 | HZV4-90502-000     | WASHER, PLAIN, 5MM          | 1       |         |
| FOP-8-6 | 58 | H921-90504-010     | WASHER, PLAIN, 6MM          | 5       |         |
| FOP-8-6 | 59 | H921-90512-010     | WASHER, 6MM                 | 6       |         |
| FOP-8-6 | 60 | H921-90518-000     | WASHER, PLAIN, 8MM          | 1       |         |
| FOP-8-6 | 61 | HZV5-90557-000     | WASHER, 28MM                | 1       |         |
| FOP-8-6 | 62 | HZV5-90751-000     | PIN, LOCK, 6MM              | 2       |         |
| FOP-8-6 | 63 | HZV5-90772-000     | PIN, 6X6                    | 1       |         |
| FOP-8-6 | 64 | HZV5-91151-000     | ROLLER, CLICK               | 1       |         |
| FOP-8-6 | 65 | HSB6-91475-000     | CLIP, WIRE HARNESS(6.3MM)   | 1       |         |
| FOP-8-6 | 66 | HZV5-91567-000     | COLLAR, LINK JOINT          | 2       |         |
| FOP-8-6 | 67 | HZV5-91570-000     | COLLAR, DISTANCE, 6X10X43.5 | 3       |         |
| FOP-8-6 | 68 | HCO-92101-05016-4J | BOLT, HEX., 5X16            | 1       |         |
| FOP-8-6 | 69 | HCO-93500-05010-4J | SCREW, PAN, 5X10            | 2       |         |
| FOP-8-6 | 70 | HCO-93901-250J0    | SCREW, TAPPING, 5X8         | 2       |         |
| FOP-8-6 | 71 | HCO-93901-251J0    | SCREW, TAPPING, 5X10        | 3       |         |
| FOP-8-6 | 72 | HCO-93901-252J0    | SCREW, TAPPING, 5X12        | 1       |         |
| FOP-8-6 | 73 | HCO-93903-262J0    | SCREW, TAPPING, 6X16        | 2       |         |
| FOP-8-6 | 74 | HCO-93905-255J0    | SCREW, TAPPING, 5X25        | 7       |         |
| FOP-8-6 | 75 | HCO-94001-06490-0S | NUT, HEX., 6MM              | 1       |         |
| FOP-8-6 | 76 | HCO-94002-05490-0S | NUT, HEX., 5MM              | 1       |         |
| FOP-8-6 | 77 | HCO-94540-03029    | E-RING, 3MM                 | 1       |         |
| FOP-8-6 | 78 | HCO-94540-04029    | E-RING, 4MM                 | 1       |         |
| FOP-8-6 | 79 | HCO-94540-07029    | E-RING, 7MM                 | 1       |         |
|         |    |                    |                             |         |         |
|         |    |                    |                             |         |         |
|         |    |                    |                             |         |         |
|         |    |                    |                             |         |         |
|         |    |                    |                             |         |         |





[illegible]




[illegible]




[illegible]



[illegible]



[illegible]



[illegible]

# INDEX

|                                      |            |                                 |            |
|--------------------------------------|------------|---------------------------------|------------|
| <A>                                  |            |                                 |            |
| ARM ASSY., EX. ROCKER .....          | E-9-14     | BOLT, FLANGE, 10X25 .....       | F-10-32    |
| ARM ASSY., ROCKER .....              | E-9-13     | BOLT, FLANGE, 10X32 .....       | E-9-29     |
| ARM COMP., CAM CHAIN TENSIONER ..... | E-9-10     | BOLT, FLANGE, 10X40 .....       | E-6-9      |
| ARM COMP., CLICK .....               | F-2-8      | BOLT, FLANGE, 10X40 .....       | F-3-20-8   |
| ARM COMP., LINK JOINT .....          | FOP-8-6-18 | BOLT, FLANGE, 10X40 .....       | F-5-12     |
| ARM COMP., SHIFT LINK .....          | FOP-8-6-14 | BOLT, FLANGE, 10X43 .....       | E-9-10-19  |
| ARM, NEUTRAL LOCK .....              | FOP-8-4-5  | BOLT, FLANGE, 10X45 .....       | E-4-11     |
| ARM, SHIFT .....                     | F-2-13     | BOLT, FLANGE, 10X70 .....       | E-3-29     |
| ARM, THROTTLE .....                  | F-2-6      | BOLT, FLANGE, 10X70 .....       | E-9-10-21  |
| ARMATURE COMP. ....                  | F-11-6     | BOLT, FLANGE, 10X75 .....       | E-4-8      |
| <B>                                  |            | BOLT, FLANGE, 10X80 .....       | E-6-10     |
| BAG, TOOL, 230MM .....               | F-13-12    | BOLT, FLANGE, 10X80 .....       | E-19-28    |
| BALL, STEEL .....                    | E-21-6     | BOLT, FLANGE, 10X90 .....       | E-21-21    |
| BALL, STEEL, #7(7/32) .....          | F-5-29     | BOLT, FLANGE, 12MM .....        | E-5-15     |
| BALL, STEEL, #9(9/32) .....          | F-5-30     | BOLT, FLANGE, 12X47 .....       | E-9-28     |
| BAND .....                           | E-18-10-43 | BOLT, FLANGE, 12X83 .....       | E-3-20     |
| BAND(BLACK 3.5X140) .....            | F-8-10-1   | BOLT, FLANGE, 6X10 .....        | E-14-22    |
| BAND(BLACK 3.5X140) .....            | FOP-8-6-40 | BOLT, FLANGE, 6X12 .....        | E-6-14     |
| BAND, AIR FLOW .....                 | E-15-4     | BOLT, FLANGE, 6X12 .....        | E-15-19    |
| BAND, HARNESS .....                  | E-14-30    | BOLT, FLANGE, 6X12 .....        | F-2-30     |
| BAND, HARNESS OFFSET(10) .....       | F-7-30-2   | BOLT, FLANGE, 6X12 .....        | F-3-20-9   |
| BAND, UNDER CASE GROMMET .....       | F-8-10-4   | BOLT, FLANGE, 6X12 .....        | F-7-3      |
| BAND, WIRE .....                     | F-3-2      | BOLT, FLANGE, 6X12 .....        | F-7-10-10  |
| BAND, WIRE .....                     | FOP-13-3   | BOLT, FLANGE, 6X12 .....        | F-7-20-7   |
| BAND, WIRE HARNESS(NATURAL) .....    | FOP-6-1-17 | BOLT, FLANGE, 6X12 .....        | F-9-28     |
| BASE .....                           | FOP-8-4-15 | BOLT, FLANGE, 6X14 .....        | E-4-9      |
| BASE, INJECTOR .....                 | E-14-10    | BOLT, FLANGE, 6X14 .....        | E-9-10-17  |
| BEARING A, CONNECTING ROD .....      | E-7-7      | BOLT, FLANGE, 6X14 .....        | E-9-20-20  |
| BEARING A, MAIN LOWER(BLUE) .....    | E-7-11     | BOLT, FLANGE, 6X14 .....        | E-10-15    |
| BEARING A, MAIN UPPER(BLUE) .....    | E-7-9      | BOLT, FLANGE, 6X14 .....        | E-14-21    |
| BEARING B, CONNECTING ROD .....      | E-7-7      | BOLT, FLANGE, 6X14 .....        | E-18-1-20  |
| BEARING B, MAIN LOWER(BLACK) .....   | E-7-11     | BOLT, FLANGE, 6X14 .....        | F-2-28     |
| BEARING B, MAIN UPPER(BLACK) .....   | E-7-9      | BOLT, FLANGE, 6X14(CT200) ..... | E-3-22     |
| BEARING C, CONNECTING ROD .....      | E-7-7      | BOLT, FLANGE, 6X14(CT200) ..... | E-9-10-14  |
| BEARING C, MAIN LOWER(BROWN) .....   | E-7-11     | BOLT, FLANGE, 6X14(CT200) ..... | F-7-10-9   |
| BEARING C, MAIN UPPER(BROWN) .....   | E-7-9      | BOLT, FLANGE, 6X16 .....        | E-9-10-16  |
| BEARING D, CONNECTING ROD .....      | E-7-7      | BOLT, FLANGE, 6X16 .....        | E-9-20-18  |
| BEARING D, MAIN LOWER(GREEN) .....   | E-7-11     | BOLT, FLANGE, 6X16 .....        | E-18-10-47 |
| BEARING D, MAIN UPPER(GREEN) .....   | E-7-9      | BOLT, FLANGE, 6X16 .....        | E-19-24    |
| BEARING E, CONNECTING ROD .....      | E-7-7      | BOLT, FLANGE, 6X16 .....        | F-2-27     |
| BEARING E, MAIN LOWER(YELLOW) .....  | E-7-11     | BOLT, FLANGE, 6X16 .....        | F-9-25     |
| BEARING E, MAIN UPPER(YELLOW) .....  | E-7-9      | BOLT, FLANGE, 6X18 .....        | E-6-22     |
| BEARING F, CONNECTING ROD .....      | E-7-7      | BOLT, FLANGE, 6X18 .....        | F-2-29     |
| BEARING F, MAIN LOWER(PINK) .....    | E-7-11     | BOLT, FLANGE, 6X20 .....        | E-5-18     |
| BEARING F, MAIN UPPER(PINK) .....    | E-7-9      | BOLT, FLANGE, 6X20 .....        | E-9-34     |
| BEARING G, CONNECTING ROD(RED) ..... | E-7-7      | BOLT, FLANGE, 6X20 .....        | E-9-20-19  |
| BEARING, FR .....                    | E-19-4     | BOLT, FLANGE, 6X20 .....        | E-9-20-27  |
| BEARING, NEEDLE(25X32X26) .....      | F-5-24     | BOLT, FLANGE, 6X20 .....        | E-20-10-5  |
| BEARING, NEEDLE .....                | F-4-26     | BOLT, FLANGE, 6X20 .....        | F-2-31     |
| BEARING, NEEDLE, 20X28X13 .....      | F-2-42     | BOLT, FLANGE, 6X20 .....        | F-4-18     |
| BEARING, NEEDLE, 30X37X26 .....      | F-5-20     | BOLT, FLANGE, 6X20 .....        | F-7-20-8   |
| BEARING, RADIAL BALL, 50X90X20 ..... | F-5-23     | BOLT, FLANGE, 6X20 .....        | F-10-28    |
| BEARING, RR .....                    | E-19-3     | BOLT, FLANGE, 6X22 .....        | E-4-10     |
| BEARING, TAPER ROLLER .....          | F-4-27     | BOLT, FLANGE, 6X22 .....        | F-7-10-11  |
| BEARING, TAPER, 50X90X28 .....       | F-5-22     | BOLT, FLANGE, 6X22 .....        | F-8-10-23  |
| BEARING, THRUST(F) .....             | F-5-21     | BOLT, FLANGE, 6X22 .....        | F-9-26     |
| BELT, A.C. GENERATOR(4PK810) .....   | E-13-3     | BOLT, FLANGE, 6X23 .....        | F-10-24    |
| BLOCK ASSY., CYLINDER .....          | E-3-6      | BOLT, FLANGE, 6X25 .....        | E-3-23     |
| BLOCK, NEUTRAL LOCK .....            | FOP-8-6-6  | BOLT, FLANGE, 6X25 .....        | E-5-17     |
| BLOCK, THROTTLE FRICTION .....       | FOP-8-6-28 | BOLT, FLANGE, 6X25 .....        | E-10-19    |
| BODY COMP., CHAMBER .....            | E-18-10-5  | BOLT, FLANGE, 6X25 .....        | E-18-21    |
| BODY COMP., OIL JET .....            | E-3-9      | BOLT, FLANGE, 6X25 .....        | E-18-10-46 |
| BODY, TROLLING CONTROL SWITCH .....  | FOP-12-3   | BOLT, FLANGE, 6X25 .....        | F-9-24     |
| BOLT .....                           | E-19-14    | BOLT, FLANGE, 6X27 .....        | E-18-19    |
| BOLT A, HEAD COVER .....             | E-9-20-16  | BOLT, FLANGE, 6X28 .....        | E-9-10-15  |
| BOLT A, THROUGH .....                | E-21-18    | BOLT, FLANGE, 6X30 .....        | E-9-35     |
| BOLT COMP., OIL JET .....            | E-3-10     | BOLT, FLANGE, 6X32 .....        | E-9-20-28  |
| BOLT KIT, SIDE REMOTE CONTROL .....  | FOP-9-1    | BOLT, FLANGE, 6X32 .....        | E-10-20    |
| BOLT, 1/4-28UNF .....                | F-10-26    | BOLT, FLANGE, 6X38 .....        | E-9-10-20  |
| BOLT, 3/8-24UNF .....                | F-10-27    | BOLT, FLANGE, 6X52 .....        | E-9-20-17  |
| BOLT, CHAIN GUIDE .....              | E-10-9     | BOLT, FLANGE, 8X100 .....       | E-6-13     |
| BOLT, CONNECTING ROD .....           | E-7-5      | BOLT, FLANGE, 8X110 .....       | E-9-20-30  |
| BOLT, CONNECTING ROD .....           | E-7-5      | BOLT, FLANGE, 8X18 .....        | F-7-10-12  |
| BOLT, COVER LOCK .....               | F-8-8      | BOLT, FLANGE, 8X20 .....        | E-3-24     |
| BOLT, DRAIN PLUG .....               | E-6-15     | BOLT, FLANGE, 8X20 .....        | E-19-25    |
| BOLT, DRAIN PLUG .....               | F-3-14     | BOLT, FLANGE, 8X25 .....        | E-14-27    |
| BOLT, FLANGE, 10X105 .....           | E-10-18    | BOLT, FLANGE, 8X28 .....        | E-19-26    |
| BOLT, FLANGE, 10X110 .....           | E-6-23     | BOLT, FLANGE, 8X30 .....        | E-18-10-48 |
|                                      |            | BOLT, FLANGE, 8X30 .....        | F-9-23     |
|                                      |            | BOLT, FLANGE, 8X32 .....        | E-5-27     |
|                                      |            | BOLT, FLANGE, 8X35 .....        | E-3-25     |
|                                      |            | BOLT, FLANGE, 8X35 .....        | E-14-25    |
|                                      |            | BOLT, FLANGE, 8X35 .....        | F-10-56    |
|                                      |            | BOLT, FLANGE, 8X35 .....        | FOP-8-6-49 |
|                                      |            | BOLT, FLANGE, 8X45 .....        | E-14-26    |
|                                      |            | BOLT, FLANGE, 8X50 .....        | E-3-28     |
|                                      |            | BOLT, FLANGE, 8X50 .....        | E-10-16    |
|                                      |            | BOLT, FLANGE, 8X55 .....        | E-3-19     |
|                                      |            | BOLT, FLANGE, 8X55 .....        | E-10-10    |
|                                      |            | BOLT, FLANGE, 8X55 .....        | F-8-10-22  |
|                                      |            | BOLT, FLANGE, 8X60 .....        | E-15-20    |
|                                      |            | BOLT, FLANGE, 8X75 .....        | E-10-17    |
|                                      |            | BOLT, FLANGE, 8X90 .....        | E-9-20-29  |
|                                      |            | BOLT, FRICTION .....            | FOP-8-6-29 |
|                                      |            | BOLT, FUEL PIPE .....           | E-14-1     |
|                                      |            | BOLT, HEX .....                 | F-11-32    |
|                                      |            | BOLT, HEX., 10X235 .....        | F-10-29    |
|                                      |            | BOLT, HEX., 12X119 .....        | F-10-31    |
|                                      |            | BOLT, HEX., 12X130 .....        | E-6-12     |
|                                      |            | BOLT, HEX., 12X130 .....        | F-10-31    |
|                                      |            | BOLT, HEX., 12X225 .....        | F-3-20-11  |
|                                      |            | BOLT, HEX., 12X70 .....         | E-6-11     |
|                                      |            | BOLT, HEX., 4X20 .....          | FOP-12-7   |
|                                      |            | BOLT, HEX., 5X16 .....          | FOP-8-6-68 |
|                                      |            | BOLT, HEX., 6X12 .....          | F-4-17     |
|                                      |            | BOLT, HEX., 6X14 .....          | F-10-30    |
|                                      |            | BOLT, HEX., 6X50 .....          | F-3-20     |
|                                      |            | BOLT, OIL CHECK .....           | F-3-12     |
|                                      |            | BOLT, RECESSED .....            | F-11-29    |
|                                      |            | BOLT, SEALING, 14MM .....       | E-9-3      |
|                                      |            | BOLT, SEALING, 18MM .....       | E-5-7      |
|                                      |            | BOLT, SEALING, 20MM .....       | E-3-2      |
|                                      |            | BOLT, SEALING, 20MM .....       | E-5-1      |
|                                      |            | BOLT, SEALING, 20MM .....       | E-9-20-21  |
|                                      |            | BOLT, SEALING, 22MM .....       | E-3-26     |
|                                      |            | BOLT, SEALING, 22MM .....       | E-5-19     |
|                                      |            | BOLT, SEALING, 28MM .....       | E-3-3      |
|                                      |            | BOLT, SEALING, 6MM .....        | E-18-10-44 |
|                                      |            | BOLT, SOCKET(A) .....           | F-11-30    |
|                                      |            | BOLT, SOCKET(B) .....           | F-11-31    |
|                                      |            | BOLT, SOCKET, 6X16 .....        | F-8-9      |
|                                      |            | BOLT, SOCKET, 6X20 .....        | F-8-7      |
|                                      |            | BOLT, SOCKET, 6X25 .....        | E-1-5      |
|                                      |            | BOLT, SOCKET, 6X25 .....        | E-20-3     |
|                                      |            | BOLT, SPECIAL ADJUSTER .....    | E-19-23    |
|                                      |            | BOLT, SPECIAL, 6X17 .....       | F-8-20-14  |
|                                      |            | BOLT, SPECIAL, 6X220 .....      | FOP-9-2    |
|                                      |            | BOLT, SPECIAL, 6X31 .....       | E-9-10-18  |
|                                      |            | BOLT, SPECIAL, 8MM .....        | E-5-14     |
|                                      |            | BOLT, STUD .....                | E-19-8     |
|                                      |            | BOLT, STUD 2, 8X25 .....        | E-14-23    |
|                                      |            | BOLT, STUD, 10X55 .....         | F-9-27     |
|                                      |            | BOLT, STUD, 12X150 .....        | F-10-25    |
|                                      |            | BOLT, STUD, 8X32 .....          | E-14-24    |
|                                      |            | BOLT, TENSIONER .....           | E-19-27    |
|                                      |            | BOLT, TENSIONER PIVOT .....     | E-9-27     |
|                                      |            | BOLT-WASHER .....               | E-19-13    |
|                                      |            | BOLT-WASHER, 10X30 .....        | E-10-11    |
|                                      |            | BOLT-WASHER, 10X32 .....        | F-3-13     |
|                                      |            | BOLT-WASHER, 10X40 .....        | F-3-15     |
|                                      |            | BOLT-WASHER, 11X155 .....       | E-9-20-15  |
|                                      |            | BOLT-WASHER, 11X95 .....        | E-3-21     |
|                                      |            | BOLT-WASHER, 16X49 .....        | E-7-15     |
|                                      |            | BOLT-WASHER, 5X30 .....         | E-15-18    |
|                                      |            | BOLT-WASHER, 6X25 .....         | E-13-5     |
|                                      |            | BOLT-WASHER, 6X25 .....         | E-15-17    |
|                                      |            | BOLT-WASHER, 6X27(CT200) .....  | E-20-10-4  |
|                                      |            | BOLT-WASHER, 8X10 .....         | E-3-11     |
|                                      |            | BOLT-WASHER, 8X30 .....         | F-3-20-10  |
|                                      |            | BOLT-WASHER, 8X30 .....         | F-8-10-24  |
|                                      |            | BOLT-WASHER, 8X35 .....         | E-14-20    |
|                                      |            | BOLT-WASHER, 8X35 .....         | E-18-20    |
|                                      |            | BOLT-WASHER, 8X35 .....         | E-18-10-45 |
|                                      |            | BOLT-WASHER, 8X40 .....         | F-4-19     |
|                                      |            | BOLT-WASHER, 8X40 .....         | FOP-10-1-8 |
|                                      |            | BOSS, FLYWHEEL .....            | E-5-13     |
|                                      |            | BOX ASSY., JUNCTION .....       | F-7-20-1   |
|                                      |            | BOX ASSY., REMOTE CONTROL ..... | FOP-8-6-1  |

|                                     |            |                                    |            |                                         |             |
|-------------------------------------|------------|------------------------------------|------------|-----------------------------------------|-------------|
| BOX ASSY., REMOTE CONTROL .....     | FOP-8-6-1  | CASE ASSY., CHAIN .....            | E-9-10-1   | COLLAR, 8.5X14.5. ....                  | E-18-28     |
| BOX KIT, REMOTE CONTROL .....       | FOP-8-1    | CASE ASSY., ELECTRONIC PARTS. .... | E-20-10-1  | COLLAR, 8.5X14.5. ....                  | E-18-10-52  |
| BOX KIT, REMOTE CONTROL .....       | FOP-8-2-1  | CASE ASSY., GEAR(L) .....          | F-3-10-1   | COLLAR, C.D.I. UNIT CASE .....          | E-13-8      |
| BOX KIT, REMOTE CONTROL .....       | FOP-8-4-1  | CASE ASSY., GEAR(XL) .....         | F-3-10-1   | COLLAR, C.D.I. UNIT CASE .....          | E-15-22     |
| BRACKET A, CABLE .....              | F-2-21     | CASE COMP., MOUNT .....            | F-9-21     | COLLAR, C.D.I. UNIT CASE .....          | E-20-10-6   |
| BRACKET A, COUPLER .....            | F-7-10-1   | CASE COMP., PUMP .....             | E-18-10-27 | COLLAR, C.D.I. UNIT CASE .....          | F-7-10-17   |
| BRACKET A, HARNESS CLIP .....       | E-14-15    | CASE COMP., SILENCER .....         | E-15-5     | COLLAR, CAMSHAFT .....                  | E-9-33      |
| BRACKET ASSY. ....                  | F-11-5     | CASE, EXTENSION. ....              | F-3-20-1   | COLLAR, DISTANCE .....                  | F-4-34      |
| BRACKET B, CABLE .....              | F-7-10-6   | CASE, EXTENSION(L) .....           | F-3-20-1   | COLLAR, DISTANCE .....                  | FOP-10-1-11 |
| BRACKET B, HARNESS CLIP .....       | E-9-10-9   | CASE, GEAR .....                   | F-3-3      | COLLAR, DISTANCE(A) .....               | FOP-9-3     |
| BRACKET C, HARNESS CLIP .....       | E-9-10-10  | CASE, OIL .....                    | E-6-1      | COLLAR, DISTANCE(B) .....               | FOP-9-4     |
| BRACKET COMP., A.C. GENERATOR ..... | E-19-17    | CASE, SWIVEL .....                 | F-10-9     | COLLAR, DISTANCE, 6.5X11X7.5 .....      | F-9-4       |
| BRACKET D, HARNESS CLIP .....       | E-3-15     | CHAIN(176L)(BORG WARNER) .....     | E-9-7      | COLLAR, DISTANCE, 6.5X9X3 .....         | F-8-12      |
| BRACKET, CLIP B .....               | E-15-9     | CHAIN(62L) .....                   | E-10-5     | COLLAR, DISTANCE, 6.5X9X5 .....         | F-8-20-21   |
| BRACKET F, CLIP .....               | E-9-20-12  | CIRCLIP, EXTERNAL, 14MM .....      | F-5-28     | COLLAR, DISTANCE, 6X10X43.5 .....       | FOP-8-6-67  |
| BRACKET, BUZZER .....               | FOP-6-1-14 | CIRCLIP, EXTERNAL, 39MM .....      | F-10-48    | COLLAR, LINK JOINT .....                | FOP-8-6-66  |
| BRACKET, CLIP B .....               | E-3-14     | CIRCLIP, INTERNAL .....            | F-11-34    | COLLAR, LOWER CYLINDER .....            | F-10-23     |
| BRACKET, FR. ....                   | E-21-10    | CIRCLIP, INTERNAL, 40 .....        | F-3-20-16  | COLLAR, LOWER MOUNTING .....            | F-3-20-6    |
| BRACKET, FR. UNDER COVER .....      | F-8-10-5   | CLAMP .....                        | F-6-5      | COLLAR, ORIFICE .....                   | F-11-46     |
| BRACKET, HOOK .....                 | F-8-3      | CLAMP .....                        | F-6-8      | COLLAR, SLIDING PLATE .....             | FOP-8-6-16  |
| BRACKET, L. SIDE COVER .....        | F-8-10-7   | CLAMP .....                        | FOP-1-2    | COLLAR, STEERING ROD .....              | F-10-53     |
| BRACKET, L. STERN .....             | F-10-13    | CLAMP B, WATER TUBE .....          | E-4-12     | CONTROL UNIT, ELECTRONIC .....          | E-20-10-3   |
| BRACKET, LINK JOINT .....           | FOP-8-6-19 | CLAMP, 18.5MM .....                | E-9-10-28  | CORD ASSY., INDICATOR(20FT) .....       | FOP-6-4     |
| BRACKET, NEUTRAL SWITCH .....       | F-2-23     | CLAMP, 18.5MM .....                | E-13-7     | CORD ASSY., INDICATOR(25FT) .....       | FOP-6-4     |
| BRACKET, R. SIDE COVER .....        | F-8-10-6   | CLAMP, ENGINE SUB CORD .....       | F-7-30-3   | CORD ASSY., INDICATOR(30FT) .....       | FOP-6-4     |
| BRACKET, R. STERN .....             | F-10-12    | CLAMP, FUEL HOSE .....             | E-15-23    | CORD COMP., EMERGENCY .....             | FOP-6-1-9   |
| BRACKET, RELAY .....                | E-3-18     | CLAMP, HARNESS .....               | FOP-8-6-9  | CORD COMP., EMERGENCY .....             | FOP-8-6-42  |
| BRACKET, REMOTE CONTROL .....       | FOP-8-12   | CLAMP, HOSE .....                  | E-18-12    | COTTER, VALVE(FUJI VALVE) .....         | E-9-26      |
| BRACKET, REMOTE CONTROL .....       | FOP-8-2-13 | CLAMP, HOSE .....                  | F-7-30-1   | COVER ASSY. ....                        | FOP-8-4-11  |
| BRACKET, RR. ....                   | E-21-11    | CLAMP, PIPE .....                  | E-18-13    | COVER ASSY., ENGINE *T107BAY BLUE ..... | F-8-1       |
| BRACKET, SENSOR CORD .....          | E-15-10    | CLAMP, POWER TILT CORD .....       | FOP-8-6-31 | COVER ASSY., ENGINE *T107BAY BLUE ..... | F-8-1       |
| BRACKET, SHIFT LINK .....           | F-2-19     | CLAMP, PURGE HOSE .....            | E-18-30    | COVER ASSY., OIL PATH .....             | E-9-20-8    |
| BRACKET, TILTING .....              | F-10-17    | CLAMP, TUBE(8.0) .....             | E-18-10-50 | COVER B, TERMINAL .....                 | F-7-10-5    |
| BRACKET, TROLLING CONTROL .....     | FOP-12-4   | CLAMP, TUBE(D10.5) .....           | E-4-10-8   | COVER B, TERMINAL(L) .....              | F-7-2       |
| BRACKET, WATER TUBE CLAMP .....     | E-4-5      | CLAMP, TUBE(D10.5) .....           | F-9-29     | COVER B, TERMINAL(L) .....              | F-7-10-4    |
| BREAKER ASSY. ....                  | F-11-1     | CLAMP, TUBE(D10.7) .....           | F-9-31     | COVER COMP. ....                        | E-18-10-6   |
| BRUSH ASSY. ....                    | F-11-2     | CLAMP, TUBE(D10.7) .....           | E-18-22    | COVER COMP., CYLINDER HEAD .....        | E-1-1       |
| BRUSH SET .....                     | E-21-7     | CLAMP, TUBE(D12) .....             | E-18-1-22  | COVER COMP., FUSE .....                 | F-7-20-2    |
| BRUSH SET .....                     | E-21-7     | CLAMP, TUBE(D17) .....             | E-15-21    | COVER COMP., PLUG HOLE COIL .....       | E-1-4       |
| BUFFER, PLATE .....                 | E-18-1-4   | CLAMP, TUBE(D25.0) .....           | E-4-10-10  | COVER, BEARING .....                    | E-19-5      |
| BUSH A, COVER LOCK .....            | F-2-25     | CLAMP, TUBE(D32.5) .....           | E-4-10-9   | COVER, CHAIN CASE .....                 | E-9-10-2    |
| BUSH A, COVER LOCK .....            | F-8-10-11  | CLAMP, WATER TUBE .....            | E-4-10-11  | COVER, DRAIN PLUG .....                 | F-8-20-8    |
| BUSH A, COVER LOCK .....            | F-8-10-12  | CLIP B1, TUBE .....                | F-9-32     | COVER, DUAL GRIP .....                  | FOP-8-2-8   |
| BUSH B, COVER LOCK .....            | F-8-10-13  | CLIP(10.7MM) .....                 | F-8-20-18  | COVER, EX. MANIFOLD .....               | E-4-3       |
| BUSH COMP., VERTICAL SHAFT .....    | F-3-20-2   | CLIP(14MM) .....                   | FOP-13-12  | COVER, FLUSH VALVE .....                | F-9-14      |
| BUSH, BLADE BRAKE .....             | F-2-26     | CLIP, BRAKE PIPE(A) .....          | F-2-24     | COVER, FR. SEPARATE .....               | F-8-20-6    |
| BUSH, INSULATION .....              | E-19-20    | CLIP, EMERGENCY LOCK .....         | FOP-6-1-10 | COVER, GRIP .....                       | FOP-8-4-4   |
| BUSH, LOWER CYLINDER .....          | F-11-25    | CLIP, EMERGENCY LOCK .....         | FOP-8-6-43 | COVER, IMPELLER .....                   | F-4-5       |
| BUSH, MOTOR CODE .....              | F-11-19    | CLIP, FUEL HOSE .....              | E-18-25    | COVER, IMPELLER .....                   | FOP-10-1-5  |
| BUSH, MOTOR CODE .....              | FOP-13-8   | CLIP, FUEL TUBE, 14. ....          | E-14-31    | COVER, L. ENGINE UNDER .....            | F-8-20-10   |
| BUSH, SWIVEL CASE .....             | F-10-11    | CLIP, FUEL TUBE, 14. ....          | F-7-10-15  | COVER, L. GRIP .....                    | FOP-8-5     |
| BUSH, SWIVEL CASE .....             | F-11-10    | CLIP, HARNESS .....                | E-18-27    | COVER, L. GRIP .....                    | FOP-8-2-6   |
| BUSH, TILT ARM .....                | F-10-16    | CLIP, HARNESS BAND(BLACK) .....    | E-3-40     | COVER, LOCK ARM .....                   | FOP-8-4-6   |
| BUTTON, THROTTLE .....              | FOP-8-9    | CLIP, HARNESS BAND(BLACK) .....    | F-7-6      | COVER, OIL PUMP .....                   | E-5-4       |
| BUTTON, THROTTLE .....              | FOP-8-2-10 | CLIP, HARNESS BAND(BLACK) .....    | F-7-10-16  | COVER, PUMP(A) .....                    | E-18-10-29  |
| BUTTON, THROTTLE .....              | FOP-8-4-8  | CLIP, HARNESS BAND(BLACK) .....    | FOP-11-6   | COVER, PUMP(B) .....                    | E-18-10-28  |
| BUZZER COMP., WARNING .....         | FOP-6-1-13 | CLIP, HARNESS BAND(NATURAL) .....  | E-4-17     | COVER, R. ENGINE UNDER .....            | F-8-20-9    |
| BUZZER COMP., WARNING .....         | FOP-8-6-46 | CLIP, INJECTOR .....               | E-14-3     | COVER, RELIEF VALVE .....               | F-9-18      |
| <C> .....                           |            | CLIP, MUDGUARD .....               | F-8-20-19  | COVER, STARTER TERMINAL .....           | F-7-10-3    |
| CABLE ASSY., REMOTE CONTROL(B) ...  | FOP-8-6-34 | CLIP, PISTON PIN .....             | E-7-4      | COVER, THERMOSTAT .....                 | E-9-10-6    |
| CABLE ASSY., STARTER .....          | F-7-10-2   | CLIP, SENSOR HOSE .....            | E-18-18    | COVER, WATER JACKET .....               | E-18-10-12  |
| CABLE ASSY., SWITCH PANEL .....     | FOP-6-9    | CLIP, TUBE .....                   | E-18-1     | CRANKCASE COMP. ....                    | E-3-1       |
| CABLE ASSY., SWITCH PANEL .....     | FOP-6-9    | CLIP, TUBE .....                   | E-18-1-1   | CRANKSHAFT COMP. ....                   | E-7-8       |
| CABLE ASSY., SWITCH PANEL .....     | FOP-6-9    | CLIP, TUBE .....                   | F-9-2      | CRANKSHAFT COMP. ....                   | E-7-8       |
| CABLE COMP. A, COVER LOCK .....     | F-8-10-8   | CLIP, TUBE(B1 14.5) .....          | E-18-23    | CUP SET, WATER SEPARATOR .....          | E-18-1-3    |
| CABLE COMP. B, COVER LOCK .....     | F-8-10-9   | CLIP, TUBE(B1 14.5) .....          | E-18-1-21  | CUP, FUEL STRAINER .....                | E-18-1-14   |
| CABLE SET, PANEL INDICATOR .....    | FOP-6-2    | CLIP, TUBE(B12) .....              | E-18-24    | <D> .....                               |             |
| CABLE SET, PANEL INDICATOR .....    | FOP-6-2    | CLIP, TUBE(B12) .....              | E-18-1-23  | DAMPER, HOOK .....                      | F-8-4       |
| CABLE SET, PANEL INDICATOR .....    | FOP-6-2    | CLIP, TUBE(B12) .....              | F-9-30     | DOWEL PIN, 10X12 .....                  | E-7-17      |
| CAMSHAFT COMP., EX. ....            | E-9-4      | CLIP, TUBE(B8) .....               | FOP-13-11  | DOWEL PIN, 10X16 .....                  | E-5-25      |
| CAMSHAFT COMP., IN. ....            | E-9-1      | CLIP, TUBE(BLACK)(135MM) .....     | E-18-29    | DOWEL PIN, 10X16 .....                  | E-6-20      |
| CAP COMP., OIL TANK .....           | F-11-28    | CLIP, TUBE, 3.5. ....              | E-13-6     | DOWEL PIN, 10X16 .....                  | E-9-20-25   |
| CAP, BOLT, 8MM .....                | E-3-27     | CLIP, WIRE HARNESS .....           | F-7-5      | DOWEL PIN, 13X14 .....                  | E-3-34      |
| CAP, GRIP .....                     | FOP-8-7    | CLIP, WIRE HARNESS .....           | F-8-20-20  | DOWEL PIN, 13X20 .....                  | E-3-33      |
| CAP, GRIP .....                     | FOP-8-2-9  | CLIP, WIRE HARNESS .....           | F-10-49    | DOWEL PIN, 14X20 .....                  | E-5-26      |
| CAP, HANDLE .....                   | FOP-8-6-5  | CLIP, WIRE HARNESS(6.3MM) .....    | FOP-8-6-65 | DOWEL PIN, 14X20 .....                  | E-6-21      |
| CAP, L. SIDE COVER .....            | F-8-10-21  | CLIP, WIRE HARNESS, 25MM .....     | E-18-1-24  | DOWEL PIN, 14X20 .....                  | E-9-20-26   |
| CAP, OIL(YELLOW) .....              | E-3-12     | CLUTCH COMP., OVERRUNNING .....    | E-21-2     | DOWEL PIN, 18X13 .....                  | E-10-12     |
| CAP, REGULATOR .....                | E-14-6     | CLUTCH COMP., OVERRUNNING .....    | E-21-2     | DOWEL PIN, 18X22 .....                  | E-3-32      |
| CAP, SWITCH .....                   | FOP-8-8    | COIL COMP., PLUG HOLE .....        | E-20-1     | DOWEL PIN, 4.2X10.3 .....               | E-9-32      |
| CAP, WATER JOINT .....              | F-8-20-1   | COLLAR .....                       | E-18-10-23 | DOWEL PIN, 6X10 .....                   | E-6-19      |
| CARTRIDGE, OIL FILTER .....         | E-5-10     | COLLAR .....                       | E-18-10-26 | DOWEL PIN, 6X10 .....                   | F-3-18      |
| CASE ASSY., BALANCER HOLDER .....   | E-10-1     | COLLAR, 8.5X14.5. ....             | E-14-35    |                                         |             |

|                                     |            |                                     |            |                                    |            |
|-------------------------------------|------------|-------------------------------------|------------|------------------------------------|------------|
| DOWEL PIN, 6X10.....                | F-3-20-17  | GUIDE, EX. VALVE(OS).....           | E-9-20-3   | LEVER, IDLE.....                   | FOP-8-6-22 |
| DOWEL PIN, 6X10.....                | F-4-25     | GUIDE, IN. VALVE(OS).....           | E-9-20-2   | LINE, FUEL.....                    | E-14-4     |
| DOWEL PIN, 8X10.....                | E-10-13    | <H>                                 |            | LINER, PUMP.....                   | F-4-4      |
| DRIVER, SCREW(NO.2 + -).....        | F-13-1     | HANDLE, REMOTE CONTROL.....         | FOP-8-4    | LINER, PUMP.....                   | FOP-10-1-4 |
| DUCT A, SILENCER.....               | E-13-1     | HANDLE, REMOTE CONTROL.....         | FOP-8-2-5  | LINER, SWIVEL CASE.....            | F-10-10    |
| DUCT B, SILENCER.....               | E-13-2     | HANDLE, REMOTE CONTROL.....         | FOP-8-4-3  | LINK, THROTTLE.....                | F-2-3      |
| <E>                                 |            | HANDLE, REMOTE CONTROL.....         | FOP-8-6-2  | LINKAGE, PIVOT.....                | F-2-1      |
| END COVER, RR.....                  | E-19-19    | HANGER B, ENGINE.....               | E-19-1     | LOCK COMP., FR.....                | F-8-10-19  |
| END, NIPPLE.....                    | F-3-10     | HANGER, ENGINE.....                 | E-3-5      | LOCK COMP., FR.....                | F-8-10-19  |
| END, NIPPLE.....                    | FOP-13-5   | HARNESS ASSY., MAIN WIRE.....       | F-7-1      | LOCK COMP., SIDE.....              | F-8-10-20  |
| E-RING, 10MM.....                   | F-4-35     | HARNESS ASSY., REMOTE CONTROL.....  | FOP-11-2   | LOCK COMP., SIDE.....              | F-8-10-20  |
| E-RING, 12MM.....                   | F-2-51     | HARNESS ASSY., SWITCH PANEL.....    | FOP-6-1-4  | <M>                                |            |
| E-RING, 15MM.....                   | F-11-47    | HARNESS COMP.....                   | E-18-10-42 | MANIFOLD COMP., EX.....            | E-4-2      |
| E-RING, 3MM.....                    | FOP-8-6-77 | HARNESS, TROLLING CONTROL.....      | FOP-12-5   | MANIFOLD COMP., INLET.....         | E-14-14    |
| E-RING, 4MM.....                    | F-2-49     | HEAD KIT, CYLINDER.....             | E-9-20-1   | MARK, CAUTION(PICTOGRAPH).....     | F-12-7     |
| E-RING, 4MM.....                    | FOP-8-6-78 | HOLDER.....                         | E-18-10-11 | MARK, FAST IDLE.....               | FOP-8-6-48 |
| E-RING, 6MM.....                    | F-2-50     | HOLDER ASSY., BRUSH.....            | E-19-2     | MARK, FLUSH MOUNT.....             | FOP-8-4-19 |
| E-RING, 6MM.....                    | F-8-10-29  | HOLDER COMP., BRUSH.....            | E-21-9     | MARK, FR. ENBLEM(115).....         | F-12-4     |
| E-RING, 6MM.....                    | FOP-8-36   | HOLDER COMP., BRUSH.....            | E-21-9     | MARK, HANDLE FLUSH MOUNT.....      | FOP-8-4-18 |
| E-RING, 6MM.....                    | FOP-8-2-41 | HOLDER, DRAIN TUBE.....             | F-2-47     | MARK, L. SIDE STRIPE(BFT115A)..... | F-12-10    |
| E-RING, 6MM.....                    | FOP-8-4-28 | HOLDER, NEUTRAL LOCK.....           | FOP-8-4-14 | MARK, R. SIDE STRIPE(BFT115A)..... | F-12-3     |
| E-RING, 7MM.....                    | FOP-8-6-79 | HOLDER, OIL FILTER.....             | E-5-16     | MARK, REMOTE CONTROL(DUAL).....    | FOP-8-2-24 |
| <F>                                 |            | HOLDER, PROPELLER SHAFT.....        | F-5-10     | MARK, REMOTE CONTROL(SINGLE).....  | FOP-8-21   |
| FILTER ASSY., SPOOL VALVE.....      | E-9-20-7   | HOLDER, SEAL.....                   | F-2-20     | MARK, RR.(BFT115A).....            | F-12-2     |
| FILTER ASSY., VTC.....              | E-9-20-11  | HOLDER, SHIFT ROD.....              | F-4-11     | METAL COMP., ANODE.....            | F-3-9      |
| FILTER B.....                       | F-11-17    | HOLDER, UPPER MOUNTING.....         | F-10-7     | METAL KIT, ANODE.....              | F-10-1     |
| FILTER COMP., ELECTRONIC AIR.....   | E-14-16    | HOSE.....                           | F-6-6      | METAL, ANODE.....                  | E-4-1      |
| FLANGE COMP., OIL FILTER.....       | E-5-11     | HOSE.....                           | F-6-7      | METAL, BALANCER SHAFT(DAIDO).....  | E-10-8     |
| FLOAT SET.....                      | E-18-10-2  | HOSE COMP., FUEL.....               | E-18-6     | METER LEAD WIRE.....               | FOP-2-6    |
| FLYWHEEL COMP.....                  | E-5-12     | HOSE KIT, RIGGING.....              | FOP-1-1    | MOTOR ASSY., POWER TILT.....       | F-11-4     |
| FRAME COMP., MOUNTING.....          | F-10-5     | HOSE, PRESSURE REGULATOR.....       | E-18-14    | MOTOR ASSY., STARTER.....          | E-21-1     |
| FUSE, BLOCK 100A(L TYPE).....       | F-7-20-3   | HOUSING ASSY., L. INNER.....        | FOP-8-3    | MOUNT COMP., UPPER RUBBER.....     | F-10-6     |
| FUSE, MINI(10A).....                | F-7-20-10  | HOUSING ASSY., L. INNER.....        | FOP-8-2-3  | <N>                                |            |
| FUSE, MINI(15A).....                | F-7-20-11  | HOUSING ASSY., R. INNER.....        | FOP-8-2-4  | NIPPLE, GREASE.....                | F-10-50    |
| FUSE, MINI(30A).....                | F-7-20-12  | HOUSING ASSY., R. INNER.....        | FOP-8-4-2  | NIPPLE, SENSOR.....                | F-3-11     |
| <G>                                 |            | HOUSING COMP., DUAL REMOTE.....     | FOP-8-2-14 | NUT, ADJUSTER ROD.....             | F-10-36    |
| GASKET A, INJECTOR BASE.....        | E-14-11    | HOUSING COMP., REMOTE CONTROL.....  | FOP-8-13   | NUT, CASTLE, 18MM.....             | F-5-13     |
| GASKET B, IMPELLER.....             | F-4-6      | HOUSING COMP., REMOTE CONTROL.....  | FOP-8-6-10 | NUT, CLIP.....                     | F-8-20-16  |
| GASKET B, IMPELLER.....             | FOP-10-3   | HOUSING COMP., REMOTE CONTROL.....  | FOP-8-6-11 | NUT, FLANGE CAP, 10MM.....         | E-3-30     |
| GASKET B, IMPELLER.....             | FOP-10-1-6 | HOUSING, IMPELLER.....              | F-4-3      | NUT, FLANGE CAP, 6MM.....          | E-1-6      |
| GASKET COMP., CYLINDER HEAD.....    | E-9-20-6   | HOUSING, IMPELLER.....              | FOP-10-1-3 | NUT, FLANGE, 10MM.....             | F-10-37    |
| GASKET COMP., EX. MANIFOLD.....     | E-4-4      | HOUSING, LEAD.....                  | FOP-8-14   | NUT, FLANGE, 12MM.....             | F-3-20-13  |
| GASKET, EX. GUIDE.....              | F-9-6      | HOUSING, LEAD.....                  | FOP-8-2-15 | NUT, FLANGE, 12MM.....             | F-10-33    |
| GASKET, IDLE EX. PORT.....          | F-9-8      | HOUSING, LOWER CENTER MOUNTING..... | F-3-20-7   | NUT, FLANGE, 5MM.....              | FOP-6-1-2  |
| GASKET, MOUNT CASE.....             | E-6-8      | HOUSING, LOWER MOUNTING.....        | F-3-20-4   | NUT, FLANGE, 6MM.....              | E-14-29    |
| GASKET, UPPER MOUNTING HOLDER.....  | F-10-8     | HOUSING, REMOTE CONTROL BOX(C)..... | FOP-8-6-12 | NUT, FLANGE, 8MM.....              | E-14-28    |
| GAUGE COMP., OIL LEVEL.....         | E-6-5      | HOUSING, WATER SEAL.....            | F-4-15     | NUT, FLANGE, 8MM.....              | E-19-29    |
| GEAR ASSY., INTERNAL.....           | E-21-15    | <I>                                 |            | NUT, HEX., 12MM.....               | F-10-54    |
| GEAR ASSY., PLANETARY.....          | E-21-3     | IMPELLER, PUMP.....                 | F-4-2      | NUT, HEX., 16MM.....               | F-8-20-17  |
| GEAR ASSY.,INTERNAL.....            | E-21-23    | IMPELLER, PUMP.....                 | FOP-10-2   | NUT, HEX., 16MM.....               | FOP-6-1-16 |
| GEAR COMP., BEVEL(FORWARD 30T) ..   | F-5-7      | IMPELLER, PUMP.....                 | FOP-10-1-2 | NUT, HEX., 16MM.....               | FOP-8-6-53 |
| GEAR, BEVEL(RVS. 30T).....          | F-5-8      | INJECTOR ASSY., FUEL.....           | E-14-2     | NUT, HEX., 18MM.....               | F-4-21     |
| GEAR, PINION.....                   | F-4-16     | INSULATOR.....                      | E-18-10-31 | NUT, HEX., 20MM.....               | F-2-32     |
| GENERATOR ASSY., A.C.....           | E-19-15    | INSULATOR COMP.....                 | E-18-10-30 | NUT, HEX., 4MM.....                | FOP-12-8   |
| GENERATOR ASSY., A.C.....           | E-19-15    | <J>                                 |            | NUT, HEX., 5MM.....                | F-2-48     |
| GRIP.....                           | F-13-2     | JOINT A, BREATHER.....              | FOP-13-2   | NUT, HEX., 5MM.....                | FOP-8-29   |
| GRIP, REMOTE CONTROL HANDLE.....    | FOP-8-6    | JOINT ASSY (INLET).....             | F-6-2      | NUT, HEX., 5MM.....                | FOP-8-35   |
| GRIP, REMOTE CONTROL HANDLE.....    | FOP-8-2-7  | JOINT ASSY (OUTLET).....            | F-6-3      | NUT, HEX., 5MM.....                | FOP-8-2-33 |
| GRIP, REMOTE CONTROL HANDLE.....    | FOP-8-6-4  | JOINT SET.....                      | E-18-10-8  | NUT, HEX., 5MM.....                | FOP-8-2-34 |
| GROMMET, ELECTRONIC PARTS CASE..... | E-20-10-2  | JOINT, DRIVE.....                   | F-11-14    | NUT, HEX., 5MM.....                | FOP-8-2-40 |
| GROMMET, EXTENSION CASE.....        | F-4-12     | JOINT, FOUR-WAY.....                | E-4-10-6   | NUT, HEX., 5MM.....                | FOP-8-6-76 |
| GROMMET, GEAR CASE.....             | F-3-4      | JOINT, FUEL PIPE.....               | E-14-8     | NUT, HEX., 6MM.....                | E-19-31    |
| GROMMET, POWER TILT SWITCH.....     | F-8-20-4   | JOINT, FUEL PIPE.....               | E-14-9     | NUT, HEX., 6MM.....                | F-8-14     |
| GROMMET, RELAY.....                 | F-7-10-8   | JOINT, FUEL PIPE.....               | E-18-10-38 | NUT, HEX., 6MM.....                | FOP-8-4-25 |
| GROMMET, REMOTE CONTROL CABLE.....  | F-8-10-2   | JOINT, FUEL TUBE.....               | E-4-10-2   | NUT, HEX., 6MM.....                | FOP-8-6-54 |
| GROMMET, SILENCER.....              | E-15-6     | JOINT, FUEL TUBE.....               | E-18-1-19  | NUT, HEX., 6MM.....                | FOP-8-6-75 |
| GROMMET, SILENCER DUCT.....         | E-15-7     | JOINT, WATER HOSE.....              | F-9-12     | NUT, HEX., 6MM.....                | FOP-9-5    |
| GROMMET, TA SENSOR.....             | E-15-14    | <K>                                 |            | NUT, LOCK, 64MM.....               | F-4-20     |
| GROMMET, UNDER CASE.....            | E-13-4     | KEY, 4.5X21.....                    | E-7-16     | NUT, PULLEY LOCK.....              | E-19-7     |
| GROMMET, UNDER CASE.....            | E-15-15    | KEY, WOODRUFF.....                  | F-4-24     | NUT, SELF-LOCK(25X2.0).....        | F-10-35    |
| GROMMET, UNDER CASE(C).....         | F-8-10-3   | KEY, WOODRUFF.....                  | FOP-10-4   | NUT, SELF-LOCK(3/8-24UNF).....     | F-10-38    |
| GROMMET, UNDER COVER.....           | F-8-20-5   | KEY, WOODRUFF.....                  | FOP-10-1-9 | NUT, SELF-LOCK(7/8-14UNF).....     | F-10-34    |
| GROMMET, VAPOR SEPARATOR.....       | E-18-10-34 | KIT, CABLE(NMEA)(6FT).....          | FOP-11-1   | NUT, SELF-LOCK, 5MM.....           | F-3-17     |
| GROMMET, VAPOR SEPARATOR.....       | E-18-10-35 | KIT,COVER HOOK.....                 | F-8-15     | NUT, SELF-LOCK, 6MM.....           | F-3-16     |
| GROMMET, WATER CHECK.....           | F-8-20-13  | <L>                                 |            | NUT, TAPPET ADJUSTING.....         | E-9-30     |
| GROMMET, WATER TUBE.....            | E-6-6      | LABEL, FUSE.....                    | F-12-1     | NUT, TAPPET ADJUSTING.....         | E-9-31     |
| GUIDE COMP. B, CAM CHAIN.....       | E-9-12     | LABEL, FUSE(EU).....                | F-12-1     | NUT, WATER MOUTH.....              | F-9-11     |
| GUIDE COMP., BALANCER SHAFT.....    | E-10-7     | LABEL, OIL CAUTION(EF).....         | F-12-8     | NUT-WASHER, 5MM.....               | E-19-30    |
| GUIDE COMP., CAM CHAIN.....         | E-9-11     | LAMP ASSY., INDICATION.....         | FOP-8-6-44 | NUT-WASHER, 6MM.....               | F-7-4      |
| GUIDE COMP., EX.....                | F-9-5      | LAMP ASSY., INDICATION(4-LED).....  | FOP-6-1-11 | NUT-WASHER, 8MM.....               | F-7-10-13  |
| GUIDE COMP., ROD.....               | F-11-15    | LEVER SET.....                      | E-21-17    | <O>                                |            |
| GUIDE COMP., ROD.....               | F-11-16    | LEVER, COVER LOCK.....              | F-8-10-10  | OIL SEAL.....                      | F-11-35    |
| GUIDE, ENGINE COVER AIR.....        | F-8-6      | LEVER, HANDLE LOCK.....             | FOP-8-6-3  | OIL SEAL, 14X26X6.....             | F-2-44     |

|                                    |             |
|------------------------------------|-------------|
| OIL SEAL, 31X46X7(NOK).....        | E-5-21      |
| OIL SEAL, 39.5X52X6(ARAI).....     | F-10-51     |
| OIL SEAL, 43X58X7(ARAI).....       | E-9-10-22   |
| OIL SEAL, 46X60X9.....             | E-5-20      |
| OIL SEAL, 80X98X10(ARAI).....      | E-3-35      |
| ORIFICE, LOWER BLOCK.....          | E-3-4       |
| ORIFICE, OIL JET.....              | E-3-8       |
| O-RING.....                        | E-15-12     |
| O-RING.....                        | E-18-1-5    |
| O-RING.....                        | E-18-1-17   |
| O-RING.....                        | E-18-10-13  |
| O-RING.....                        | E-18-10-14  |
| O-RING.....                        | E-18-10-15  |
| O-RING.....                        | E-18-10-16  |
| O-RING.....                        | E-18-10-17  |
| O-RING.....                        | E-18-10-18  |
| O-RING.....                        | E-18-10-19  |
| O-RING SET, 3.5X31.7.....          | F-11-43     |
| O-RING, 1.8X69.6.....              | F-11-37     |
| O-RING, 1.8X7.7.....               | F-11-39     |
| O-RING, 1.9X11.....                | F-11-40     |
| O-RING, 105X3.1.....               | F-5-27      |
| O-RING, 11.5X3.5.....              | F-9-35      |
| O-RING, 13X1.5(ARAI).....          | E-3-39      |
| O-RING, 15.54X2.26.....            | F-10-52     |
| O-RING, 15X1.9.....                | E-9-10-27   |
| O-RING, 15X1.9.....                | E-9-20-22   |
| O-RING, 15X1.9.....                | E-9-20-23   |
| O-RING, 16MM.....                  | F-9-34      |
| O-RING, 2.0X70.5.....              | F-11-36     |
| O-RING, 20.6X2.6.....              | E-6-18      |
| O-RING, 22.5X2.4.....              | E-5-22      |
| O-RING, 25X2.4(NOK).....           | F-2-46      |
| O-RING, 26X2.7.....                | E-3-36      |
| O-RING, 3.5X35.7.....              | F-11-41     |
| O-RING, 3.5X38.7.....              | F-11-38     |
| O-RING, 3.5X41.7.....              | F-11-42     |
| O-RING, 33.2X2.4(NOK).....         | E-18-26     |
| O-RING, 37X2.4.....                | E-4-15      |
| O-RING, 55.6X3.5.....              | F-4-31      |
| O-RING, 58.5X3.5.....              | F-4-33      |
| O-RING, 59.4X3.1.....              | E-21-22     |
| O-RING, 6.5X1.5.....               | E-3-37      |
| O-RING, 6.9X1.45.....              | F-3-19      |
| O-RING, 7.45X3.61(NOK).....        | E-14-34     |
| O-RING, 7.47X3.6.....              | E-14-33     |
| O-RING, 7.8X1.9(ARAI).....         | E-14-32     |
| O-RING, 7.8X1.9(ARAI).....         | E-18-10-51  |
| O-RING, 76.4X3.1.....              | E-4-13      |
| O-RING, 79.8X3.1.....              | E-4-14      |
| O-RING, 9.5X1.5(HONDA KIKAKI)..... | E-9-10-25   |
| O-RING, 9.5X1.9.....               | E-3-38      |
| O-RING, 9.5X1.9.....               | E-4-16      |
| O-RING, 9.5X1.9.....               | E-9-10-26   |
| O-RING, CHAIN CASE.....            | E-9-10-23   |
| O-RING, THERMOSTAT COVER.....      | F-9-20      |
| O-RING, WATER PUMP.....            | F-4-32      |
| O-RING, WATER PUMP.....            | FOP-10-5    |
| O-RING, WATER PUMP.....            | FOP-10-1-10 |
| <P>                                |             |
| PACKING.....                       | E-21-16     |
| PACKING.....                       | F-11-45     |
| PACKING, CHAIN CASE.....           | E-9-10-24   |
| PACKING, CYLINDER HEAD COVER.....  | E-1-2       |
| PACKING, DUAL.....                 | FOP-8-2-19  |
| PACKING, ELECTRONIC AIR.....       | E-14-18     |
| PACKING, FLASH VALVE.....          | F-9-19      |
| PACKING, INTAKE MANIFOLD.....      | E-14-12     |
| PACKING, OIL PAN.....              | E-6-2       |
| PACKING, OIL PUMP BODY.....        | E-5-3       |
| PACKING, SINGLE.....               | FOP-8-18    |
| PACKING, THERMOSTAT COVER.....     | E-9-10-7    |
| PACKING, THERMOSTAT SPACER.....    | E-9-10-8    |
| PACKING, THROTTLE BODY.....        | E-14-13     |
| PANEL ASSY., TROLLING CONTROL..... | FOP-12-6    |
| PANEL KIT, SWITCH(4-LED).....      | FOP-6-1-1   |
| PANEL KIT, SWITCH(4-LED) (EU)..... | FOP-6-1-1   |
| PANEL, CONTROL.....                | FOP-6-1-3   |
| PANEL, CONTROL.....                | FOP-6-1-3   |
| PIN A, DOWEL, 12X16.....           | E-10-14     |
| PIN, 6X6.....                      | FOP-8-6-63  |
| PIN, LINK.....                     | F-2-38      |

|                                     |            |
|-------------------------------------|------------|
| PIN, LINK.....                      | F-2-40     |
| PIN, LOCK, 6MM.....                 | FOP-8-6-62 |
| PIN, PISTON.....                    | E-7-3      |
| PIN, SHIFT LINK.....                | F-2-39     |
| PIN, SHIFTER, 8X47.....             | F-5-2      |
| PIN, SNAP, 12MM.....                | F-2-41     |
| PIN, SPLIT, 4.0.....                | F-5-19     |
| PIN, SPRING, 2.5X20.....            | F-10-55    |
| PIN, UPPER CYLINDER.....            | F-11-26    |
| PIPE COMP., OIL LEVEL.....          | F-9-1      |
| PIPE, HARNESS GUIDE.....            | FOP-8-6-32 |
| PISTON A.....                       | E-7-2      |
| PISTON B.....                       | E-7-2      |
| PISTON COMP., FREE.....             | F-11-22    |
| PIVOT, SHIFT.....                   | F-2-15     |
| PIVOT, SHIFT.....                   | FOP-8-6-17 |
| PIVOT, SHIFT SLIDE.....             | F-2-16     |
| PLATE.....                          | E-18-1-18  |
| PLATE.....                          | E-18-10-10 |
| PLATE COMP., SLIDING.....           | FOP-8-6-15 |
| PLATE COMP., THROTTLE.....          | F-2-4      |
| PLATE SET, TRANSOM(5.5MM FLAT)..... | FOP-7-2    |
| PLATE SET, TRIM ADJUST.....         | FOP-7-1    |
| PLATE, CABLE CLAMP.....             | FOP-8-11   |
| PLATE, CABLE CLAMP.....             | FOP-8-2-12 |
| PLATE, CRANK PULSER.....            | E-7-13     |
| PLATE, DWELL.....                   | FOP-8-15   |
| PLATE, DWELL.....                   | FOP-8-2-16 |
| PLATE, DWELL.....                   | FOP-8-4-10 |
| PLATE, HANDLE.....                  | FOP-8-10   |
| PLATE, HANDLE.....                  | FOP-8-2-11 |
| PLATE, LEVER SETTING.....           | FOP-8-6-8  |
| PLATE, LOCK.....                    | F-2-17     |
| PLATE, REMOTE CONTROL.....          | FOP-8-6-47 |
| PLATE, REMOTE CONTROL CABLE.....    | F-2-5      |
| PLATE, RUBBER SETTING.....          | F-3-1      |
| PLATE, SHIFT.....                   | F-5-6      |
| PLATE, SHIFT PIVOT.....             | F-2-14     |
| PLATE, SPEED SENSOR TUBE.....       | FOP-13-7   |
| PLATE, SPRING SETTING.....          | FOP-8-6-23 |
| PLATE, STEERING.....                | F-10-19    |
| PLATE, STEERING.....                | F-10-20    |
| PLATE, TDC PULSE.....               | E-9-2      |
| PLATE, WATER TUBE.....              | E-6-7      |
| PLATE, WINKER BUZZER.....           | FOP-6-1-12 |
| PLATE, WINKER BUZZER.....           | FOP-8-6-45 |
| PLUG, INNER CONNECTOR.....          | FOP-6-1-5  |
| PLUG, INNER CONNECTOR.....          | FOP-8-6-35 |
| PLUG, INNER CONNECTOR.....          | FOP-11-3   |
| PLUG, OUTER CONNECTOR.....          | FOP-6-1-6  |
| PLUG, OUTER CONNECTOR.....          | FOP-8-6-36 |
| PLUG, OUTER CONNECTOR.....          | FOP-11-4   |
| PLUG, SPARK(IZFR6K-11).....         | E-20-4     |
| PLUG, SPARK(KJ20DR-M11).....        | E-20-4     |
| PLUG, SPARK(SKJ20DR-M11).....       | E-20-4     |
| PLUG, SPARK(IZFR6K-11).....         | E-20-4     |
| PLUG, TDC HOLE.....                 | E-9-20-14  |
| PLUG, VTC HOLE.....                 | E-9-20-9   |
| PORT, IDLE EXHAUST.....             | F-9-7      |
| PRIMER BULB.....                    | F-6-4      |
| PRIMER BULB ASSY.....               | F-6-1      |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PROPELLER COMP., THREE BLADES.....  | F-5-11     |
| PULLER, MINI FUSE.....              | F-7-20-4   |
| PULLEY.....                         | E-19-6     |
| PULLEY, CRANKSHAFT.....             | E-7-14     |
| PUMP ASSY.....                      | F-11-12    |
| PUMP ASSY., FUEL.....               | E-18-5     |
| PUMP ASSY., OIL.....                | E-5-2      |
| PUMP KIT, IMPELLER.....             | FOP-10-1   |
| PUMP KIT, IMPELLER.....             | FOP-10-1-1 |
| PUMP UNIT, FUEL.....                | E-18-10-4  |
| PUMP UNIT, FUEL(B).....             | E-18-10-9  |

|                                    |            |
|------------------------------------|------------|
| <R>                                |            |
| RECEIVER, THRUST.....              | F-10-22    |
| RECTIFIER ASSY.....                | E-19-21    |
| REGULATOR ASSY.....                | E-19-22    |
| REGULATOR ASSY., PRESSURE.....     | E-14-5     |
| RELAY ASSY., FUEL PUMP(DENSO)..... | F-7-20-5   |
| RELAY ASSY., POWER TILT.....       | F-7-10-7   |
| RELAY ASSY., POWER(12V-20A).....   | F-7-20-6   |
| RETAINER, VALVE SPRING.....        | E-9-24     |
| RING.....                          | E-18-10-32 |
| RING SET, PISTON(STD).....         | E-7-1      |
| RING, BACK UP.....                 | F-11-18    |
| RING, CROSS PIN.....               | F-5-3      |
| RING, INNER(15X20X23).....         | F-2-43     |
| RING, STOPPER.....                 | F-2-11     |
| RING, WATER TUBE SEAL.....         | F-4-8      |
| RING, WATER TUBE SEAL.....         | FOP-10-1-7 |
| ROD COMP. A, SHIFT(L).....         | F-2-10     |
| ROD COMP. A, SHIFT(XL).....        | F-2-10     |
| ROD COMP., CONNECTING.....         | E-7-6      |
| ROD COMP., CONNECTING.....         | E-7-6      |
| ROD COMP., PISTON.....             | F-11-20    |
| ROD COMP., PISTON.....             | F-11-21    |
| ROD COMP., PISTON(B).....          | F-11-13    |
| ROD COMP., SHIFT.....              | F-4-9      |
| ROD COMP., THROTTLE.....           | F-2-2      |
| ROD, ADJUSTING.....                | F-10-14    |
| ROD, STEERING.....                 | F-10-21    |
| ROLLER, 3X12.8.....                | F-5-25     |
| ROLLER, 5X8.....                   | E-5-28     |
| ROLLER, CLICK.....                 | FOP-8-6-64 |
| ROTOR ASSY.....                    | E-19-16    |
| ROTOR COMP.....                    | E-21-5     |
| ROTOR, INNER OIL PUMP.....         | E-5-8      |
| ROTOR, OUTER OIL PUMP.....         | E-5-9      |
| RUBBER B, STAND STOPPER.....       | F-8-20-23  |
| RUBBER COMP., LOWER MOUNT.....     | F-3-20-5   |
| RUBBER, FR. CARRIER CUSHION.....   | E-14-19    |
| RUBBER, MOUNT CASE SEAL.....       | F-9-22     |
| RUBBER, OIL PUMP.....              | E-6-3      |
| RUBBER, RING.....                  | E-9-10-29  |
| RUBBER, TROLLING CONTROL.....      | FOP-12-2   |
| <S>                                |            |
| SCREEN COMP., FUEL STRAINER.....   | E-18-10-40 |
| SCREEN, L. WATER.....              | F-3-7      |
| SCREEN, R. WATER.....              | F-3-6      |
| SCREW.....                         | E-19-9     |
| SCREW.....                         | E-19-12    |
| SCREW SET.....                     | E-15-1     |
| SCREW SET, DRAIN.....              | E-18-10-7  |
| SCREW, 6X95.....                   | FOP-8-6-52 |
| SCREW, FLAT, 5X12.....             | FOP-8-6-51 |
| SCREW, FLAT, 6X16.....             | E-5-23     |
| SCREW, OVAL, 5X50.....             | F-3-21     |
| SCREW, PAN.....                    | E-18-10-21 |
| SCREW, PAN, 4X10.....              | FOP-8-26   |
| SCREW, PAN, 4X10.....              | FOP-8-2-29 |
| SCREW, PAN, 5X10.....              | FOP-8-23   |
| SCREW, PAN, 5X10.....              | FOP-8-2-26 |
| SCREW, PAN, 5X10.....              | FOP-8-6-69 |
| SCREW, PAN, 5X12.....              | E-18-1-13  |
| SCREW, PAN, 5X16.....              | FOP-8-22   |
| SCREW, PAN, 5X16.....              | FOP-8-2-25 |
| SCREW, PAN, 5X16.....              | FOP-8-4-20 |
| SCREW, PAN, 5X18.....              | E-15-16    |
| SCREW, PAN, 5X18.....              | FOP-8-25   |
| SCREW, PAN, 5X18.....              | FOP-8-2-28 |
| SCREW, PAN, 5X20.....              | FOP-8-24   |
| SCREW, PAN, 5X20.....              | FOP-8-2-27 |
| SCREW, PAN, 5X30.....              | FOP-8-4-22 |
| SCREW, PAN, 5X40.....              | FOP-6-1-15 |
| SCREW, PAN, 5X40.....              | FOP-8-28   |
| SCREW, PAN, 5X40.....              | FOP-8-2-31 |
| SCREW, PAN, 5X55.....              | FOP-8-2-32 |
| SCREW, PAN, 5X65.....              | FOP-8-34   |
| SCREW, PAN, 5X65.....              | FOP-8-2-39 |
| SCREW, PAN, 5X8.....               | E-21-20    |
| SCREW, PAN, 6X10.....              | FOP-8-6-50 |
| SCREW, PAN, 6X18.....              | E-4-18     |
| SCREW, PAN, 6X18.....              | FOP-8-27   |
| SCREW, PAN, 6X18.....              | FOP-8-2-30 |
| SCREW, PAN, 6X22.....              | E-21-19    |
| SCREW, PAN, 6X22(SPECIAL).....     | E-21-19    |

|                                 |            |                                    |            |                                  |            |
|---------------------------------|------------|------------------------------------|------------|----------------------------------|------------|
| SCREW, PAN, 6X25.....           | F-8-20-22  | SLIDER, SHIFT.....                 | F-5-4      | THERMOSTAT ASSY.....             | E-9-10-4   |
| SCREW, PAN, 6X35.....           | FOP-8-4-23 | SLINGER, OIL.....                  | F-4-14     | THROTTLE BODY ASSY.....          | E-15-2     |
| SCREW, PAN, 6X8.....            | F-3-20-12  | SPACER KIT, REMOTE CONTROL BOX ..  | FOP-8-2    | TIE, CABLE.....                  | FOP-11-5   |
| SCREW, PAN, 6X8.....            | F-11-33    | SPACER KIT, REMOTE CONTROL BOX ..  | FOP-8-2-2  | TIE, CABLE(NATURAL)(2.4X92)..... | FOP-6-12   |
| SCREW, PAN, 6X8.....            | FOP-13-9   | SPACER, CABLE CLAMP.....           | FOP-8-17   | TIE, CABLE(NATURAL)(2.4X92)..... | FOP-8-6-37 |
| SCREW, RIVET, 5X10.....         | F-8-20-15  | SPACER, CABLE CLAMP.....           | FOP-8-2-18 | T-JOINT.....                     | E-18-15    |
| SCREW, RIVET, 5X10.....         | FOP-13-10  | SPACER, CABLE CLAMP.....           | FOP-8-4-13 | T-JOINT.....                     | F-9-3      |
| SCREW, TAPPET ADJUSTING.....    | E-9-20     | SPACER, CABLE CLAMP.....           | FOP-8-6-33 | TRIM METER ASSY (BLACK).....     | FOP-2-1    |
| SCREW, TAPPET ADJUSTING.....    | E-9-21     | SPACER, CLICK SPRING.....          | FOP-8-6-27 | TRIM-TILT ASSY., POWER.....      | F-11-11    |
| SCREW, TAPPING.....             | FOP-1-3    | SPACER, NEUTRAL SWITCH.....        | FOP-8-6-30 | TUBE A, WATER RELIEF.....        | E-4-10-4   |
| SCREW, TAPPING, 4X12.....       | F-8-13     | SPACER, REMOTE CONTROL BOX.....    | FOP-8-6-26 | TUBE ASSY. D, FUEL.....          | E-18-1-8   |
| SCREW, TAPPING, 5X10.....       | FOP-8-6-71 | SPACER, THERMOSTAT COVER.....      | E-9-10-5   | TUBE B, AIR VENT.....            | E-18-3     |
| SCREW, TAPPING, 5X12.....       | FOP-8-6-72 | SPRING COMP., CLICK.....           | F-10-2     | TUBE B, FUEL.....                | E-18-11    |
| SCREW, TAPPING, 5X20.....       | E-13-9     | SPRING, ACCELERATOR WHEEL.....     | FOP-8-6-21 | TUBE B, WATER RELIEF.....        | E-4-10-5   |
| SCREW, TAPPING, 5X25.....       | FOP-8-6-74 | SPRING, AIR FLOW TUBE.....         | E-15-3     | TUBE C, FUEL.....                | E-18-1-7   |
| SCREW, TAPPING, 5X8.....        | FOP-8-6-70 | SPRING, CHOKE RETURN.....          | FOP-8-6-25 | TUBE COMP. A, FUEL.....          | E-18-1-6   |
| SCREW, TAPPING, 6X16.....       | FOP-8-6-73 | SPRING, CLICK.....                 | F-2-9      | TUBE COMP. B, FUEL.....          | E-18-7     |
| SCREW, TAPPING, 6X30.....       | FOP-8-4-24 | SPRING, CLICK ASSIST.....          | F-10-3     | TUBE COMP. C, AIR VENT.....      | E-18-2     |
| SCREW, TRUSS, 4X12.....         | FOP-8-4-21 | SPRING, COVER LOCK HOOK.....       | F-8-10-14  | TUBE COMP. E, FUEL.....          | E-18-1-10  |
| SCREW, WASHER.....              | E-18-10-22 | SPRING, COVER LOCK HOOK.....       | F-8-10-15  | TUBE COMP. E, WATER.....         | E-4-10-7   |
| SCREW-WASHER.....               | E-18-10-20 | SPRING, EX. VALVE(GRAY).....       | E-9-23     | TUBE COMP., AIR VENT.....        | E-18-4     |
| SCREW-WASHER.....               | E-19-10    | SPRING, FLUSH VALVE.....           | F-9-15     | TUBE COMP., WATER RELIEF.....    | E-4-10-3   |
| SCREW-WASHER, 4X25.....         | E-19-11    | SPRING, IN. VALVE(PINK).....       | E-9-22     | TUBE D, FUEL.....                | E-18-8     |
| SCREW-WASHER, 5X15.....         | F-7-20-9   | SPRING, LOCK ADJUSTER.....         | F-8-5      | TUBE D, FUEL.....                | E-18-1-9   |
| SEAL A, COVER UNDER.....        | F-8-20-11  | SPRING, LOCK LEVER RETURN.....     | F-8-10-16  | TUBE F, FUEL.....                | E-18-10-39 |
| SEAL A, VALVE STEM(ARAI).....   | E-9-20-4   | SPRING, MOTOR.....                 | F-11-8     | TUBE F, WATER.....               | F-9-10     |
| SEAL A, VALVE STEM(NOK).....    | E-9-20-4   | SPRING, NEUTRAL LOCK ARM.....      | FOP-8-4-7  | TUBE G, WATER.....               | E-18-16    |
| SEAL B, COVER UNDER.....        | F-8-20-12  | SPRING, RELIEF VALVE.....          | E-5-6      | TUBE KIT, SPEED SENSOR.....      | FOP-13-1   |
| SEAL B, VALVE STEM(ARAI).....   | E-9-20-5   | SPRING, REMOTE CONTROL HANDLE ..   | FOP-8-6-7  | TUBE, 12X740.....                | E-15-25    |
| SEAL B, VALVE STEM(NOK).....    | E-9-20-5   | SPRING, SET.....                   | E-18-10-41 | TUBE, 5X140.....                 | F-3-22     |
| SEAL, ENGINE COVER.....         | F-8-2      | SPRING, SHIFT.....                 | F-5-5      | TUBE, 5X270.....                 | F-3-22     |
| SEAL, FR. SEPARATE COVER.....   | F-8-20-7   | SPRING, SHIFT CLICK.....           | FOP-8-6-24 | TUBE, 5X950.....                 | FOP-13-13  |
| SEAL, PLUG HOLE.....            | E-20-2     | SPRING, SHIFT ROD.....             | F-4-10     | TUBE, 7X120.....                 | E-4-10-14  |
| SEAL, SPARK PLUG TUBE(NOK)..... | E-1-3      | SPRING, SILENCER DUCT GROMMET ..   | E-15-8     | TUBE, 7X160.....                 | F-9-38     |
| SEAL, WATER.....                | F-11-44    | SPROCKET COMP., CHAIN DRIVE.....   | E-7-12     | TUBE, 7X200.....                 | F-9-39     |
| SEAL, WATER(14X26X8).....       | F-2-45     | SPROCKET, CAM CHAIN DRIVEN.....    | E-9-5      | TUBE, 7X40.....                  | F-9-37     |
| SEAL, WATER, 12X21X6.....       | F-4-30     | SPROCKET, CAM CHAIN DRIVEN IN....  | E-9-6      | TUBE, 7X75.....                  | E-4-10-12  |
| SEAL, WATER, 22X35X7.....       | F-9-33     | SPROCKET, DRIVEN(17T).....         | E-10-4     | TUBE, 7X90.....                  | E-4-10-13  |
| SEAL, WATER, 23X36X6.....       | F-4-29     | STAY A, PLATE.....                 | E-18-10-3  | TUBE, FUEL, 3.5X430.....         | E-18-31    |
| SEAL, WATER, 23X36X8.....       | F-4-28     | STAY, A.C. GENERATOR.....          | E-19-18    | TUBE, FUEL, 8X300.....           | F-9-36     |
| SEAL, WATER, 30X45X7.....       | F-5-26     | STAY, FUEL STRAINER.....           | E-18-1-15  | TUBE, OIL.....                   | E-4-10-1   |
| SEAT, VALVE SPRING.....         | E-9-25     | STAY, PLATE.....                   | E-18-10-36 | TUBE, PRESSURE REGULATOR.....    | E-14-7     |
| SEAT, WATER MOUTH.....          | F-9-13     | STAY, POWER TILT SWITCH.....       | F-8-20-3   | TUBE, SPEED SENSOR.....          | FOP-13-6   |
| SENSOR ASSY., AIR TEMP.....     | E-15-13    | STAY, VAPOR SEPARATOR.....         | E-18-10-37 | TUBE, SPIRAL.....                | F-11-3     |
| SENSOR ASSY., CRANK.....        | E-9-10-13  | STOPPER SET, SLEEVE.....           | E-21-8     | TUBE, SPIRAL.....                | FOP-13-4   |
| SENSOR ASSY., KNOCK.....        | E-3-13     | STOPPER SET, SLEEVE.....           | E-21-8     | TUBE, VINYL, 4X7X160.....        | E-15-24    |
| SENSOR ASSY., MAP.....          | E-15-11    | STOPPER(TOOL).....                 | E-9-9      | TUBE, WATER RELIEF.....          | F-9-9      |
| SENSOR ASSY., TDC.....          | E-9-20-13  | STOPPER, TILT.....                 | F-10-18    | TUBE, WATER(L).....              | F-4-7      |
| SENSOR ASSY., TRIM ANGLE.....   | F-10-4     | STRAINER ASSY., VTC.....           | E-9-20-10  | TUBE, WATER(XL).....             | F-4-7      |
| SENSOR ASSY., WATER.....        | E-3-16     | STRAINER COMP., FUEL.....          | E-18-1-11  | <V>.....                         |            |
| SENSOR ASSY., WATER.....        | E-4-7      | STRAINER COMP., OIL.....           | E-6-4      | VALVE ASSY., ELECTRONIC AIR..... | E-14-17    |
| SENSOR ASSY., WATER.....        | E-9-10-11  | STRAINER, FUEL.....                | E-18-1-12  | VALVE ASSY., RELIEF.....         | F-9-16     |
| SENSOR ASSY., WATER.....        | E-9-10-12  | STRAINER, FUEL PUMP.....           | E-18-9     | VALVE COMP., MANUAL.....         | F-11-23    |
| SENSOR, LAF.....                | E-4-6      | SUB HARNESS ASSY., POWER.....      | FOP-8-19   | VALVE COMP., RESERVOIR.....      | F-11-24    |
| SENSOR, OIL PRESSURE.....       | E-3-17     | SUB HARNESS ASSY., POWER.....      | FOP-8-2-20 | VALVE SET, FLOAT.....            | E-18-10-1  |
| SEPARATOR ASSY., VAPOR.....     | E-18-10-33 | SUB HARNESS ASSY., POWER.....      | FOP-8-2-21 | VALVE, CHECK.....                | E-18-17    |
| SEPARATOR ASSY., WATER.....     | E-18-1-2   | SUB HARNESS ASSY., POWER.....      | FOP-8-4-16 | VALVE, EX.....                   | E-9-19     |
| SHAFT ASSY., CLUTCH.....        | E-21-13    | SUSPENSION, STRAINER.....          | E-18-10    | VALVE, FLASH.....                | F-9-17     |
| SHAFT ASSY., CLUTCH.....        | E-21-13    | SUSPENSION, STRAINER.....          | E-18-1-16  | VALVE, IN.....                   | E-9-18     |
| SHAFT ASSY., GEAR.....          | E-21-14    | SWITCH ASSY., COMBINATION.....     | FOP-6-1-7  | VALVE, RELIEF.....               | E-5-5      |
| SHAFT ASSY., GEAR.....          | E-21-14    | SWITCH ASSY., COMBINATION.....     | FOP-8-6-38 | <W>.....                         |            |
| SHAFT COMP. A, SHIFT.....       | F-2-12     | SWITCH ASSY., EMERGENCY STOP.....  | FOP-6-1-8  | WASHER.....                      | F-2-35     |
| SHAFT COMP. B, SHIFT.....       | F-2-18     | SWITCH ASSY., EMERGENCY STOP.....  | FOP-8-6-41 | WASHER, 10MM.....                | F-10-42    |
| SHAFT COMP., FR. BALANCER.....  | E-10-2     | SWITCH ASSY., MAGNET.....          | E-21-12    | WASHER, 26MM.....                | F-3-20-14  |
| SHAFT COMP., RR. BALANCER.....  | E-10-3     | SWITCH ASSY., MAGNET.....          | E-21-12    | WASHER, 28MM.....                | FOP-8-6-61 |
| SHAFT, COVER OPEN.....          | F-8-10-17  | SWITCH ASSY., NEUTRAL.....         | F-2-22     | WASHER, 6MM.....                 | FOP-8-6-59 |
| SHAFT, EX. ROCKER.....          | E-9-16     | SWITCH ASSY., POWER TILT.....      | F-8-20-2   | WASHER, DRAIN PLUG, 12MM.....    | E-6-17     |
| SHAFT, FR. LOCK.....            | F-8-10-18  | SWITCH ASSY., POWER TRIM-TILT..... | FOP-8-20   | WASHER, DRAIN PLUG, 20MM.....    | E-5-24     |
| SHAFT, IN. ROCKER.....          | E-9-15     | SWITCH ASSY., POWER TRIM-TILT..... | FOP-8-2-22 | WASHER, DRAIN PLUG, 20MM.....    | E-9-20-24  |
| SHAFT, PROPELLER.....           | F-5-9      | SWITCH ASSY., POWER TRIM-TILT..... | FOP-8-2-23 | WASHER, HEAD COVER.....          | E-1-7      |
| SHAFT, THROTTLE BUTTON.....     | FOP-8-4-9  | SWITCH ASSY., POWER TRIM-TILT..... | FOP-8-4-17 | WASHER, LOCK, 5MM.....           | FOP-8-30   |
| SHAFT, TILTING.....             | F-10-15    | SWITCH ASSY., POWER TRIM-TILT..... | FOP-8-6-39 | WASHER, LOCK, 5MM.....           | FOP-8-2-35 |
| SHAFT, VERTICAL(L).....         | F-4-13     | SWITCH ASSY., TROLLING CONTROL ..  | FOP-12-1   | WASHER, LOCK, 5MM.....           | FOP-8-4-26 |
| SHAFT, VERTICAL(XL).....        | F-4-13     | <T>.....                           |            | WASHER, LOCK, 6MM.....           | FOP-8-32   |
| SHIFTER, CLUTCH.....            | F-5-1      | TAB, TRIM.....                     | F-3-8      | WASHER, LOCK, 6MM.....           | FOP-8-2-37 |
| SHIM A, BEVEL(0.10).....        | F-5-17     | TACHOMETER HOUR METER (BLACK) ..   | FOP-2-4    | WASHER, PIVOT.....               | F-2-7      |
| SHIM A, GEAR(0.10).....         | F-4-23     | TANK, OIL.....                     | F-11-27    | WASHER, PIVOT.....               | F-4-1      |
| SHIM B, BEVEL(0.15).....        | F-5-17     | TENSIONER ASSY., CAM CHAIN.....    | E-9-8      | WASHER, PLAIN.....               | E-18-10-24 |
| SHIM B, GEAR(0.15).....         | F-4-23     | TENSIONER COMP., BALANCER.....     | E-10-6     | WASHER, PLAIN.....               | E-18-10-25 |
| SHIM C, BEVEL(0.30).....        | F-5-17     | TERMINAL, CABLE.....               | FOP-8-16   | WASHER, PLAIN, 10MM.....         | F-5-18     |
| SHIM C, GEAR(0.30).....         | F-4-23     | TERMINAL, CABLE.....               | FOP-8-2-17 | WASHER, PLAIN, 10MM.....         | F-8-10-26  |
| SHIM D, BEVEL(0.50).....        | F-5-17     | TERMINAL, CABLE.....               | FOP-8-4-12 | WASHER, PLAIN, 10MM.....         | F-10-43    |
| SHIM D, GEAR(0.50).....         | F-4-23     | THERMOSTAT ASSY.....               | E-9-10-3   | WASHER, PLAIN, 10MM.....         | F-10-47    |

|                               |            |
|-------------------------------|------------|
| WASHER, PLAIN, 12MM .....     | E-6-16     |
| WASHER, PLAIN, 12MM .....     | F-2-34     |
| WASHER, PLAIN, 12MM .....     | F-3-20-15  |
| WASHER, PLAIN, 12MM .....     | F-4-22     |
| WASHER, PLAIN, 12MM .....     | F-8-11     |
| WASHER, PLAIN, 12MM .....     | F-10-44    |
| WASHER, PLAIN, 12MM .....     | F-10-45    |
| WASHER, PLAIN, 12MM .....     | F-10-46    |
| WASHER, PLAIN, 4MM .....      | FOP-8-6-55 |
| WASHER, PLAIN, 5MM .....      | FOP-6-1-18 |
| WASHER, PLAIN, 5MM .....      | FOP-8-31   |
| WASHER, PLAIN, 5MM .....      | FOP-8-33   |
| WASHER, PLAIN, 5MM .....      | FOP-8-2-36 |
| WASHER, PLAIN, 5MM .....      | FOP-8-2-38 |
| WASHER, PLAIN, 5MM .....      | FOP-8-6-56 |
| WASHER, PLAIN, 5MM .....      | FOP-8-6-57 |
| WASHER, PLAIN, 6MM .....      | F-2-36     |
| WASHER, PLAIN, 6MM .....      | F-8-10     |
| WASHER, PLAIN, 6MM .....      | FOP-8-4-27 |
| WASHER, PLAIN, 6MM .....      | FOP-8-6-58 |
| WASHER, PLAIN, 8MM .....      | F-2-37     |
| WASHER, PLAIN, 8MM .....      | F-7-10-14  |
| WASHER, PLAIN, 8MM .....      | F-8-10-25  |
| WASHER, PLAIN, 8MM .....      | F-8-10-28  |
| WASHER, PLAIN, 8MM .....      | FOP-8-6-60 |
| WASHER, PROPELLER .....       | F-5-16     |
| WASHER, PROPELLER THRUST..... | F-5-14     |
| WASHER, SEALING(22MM) .....   | E-3-7      |
| WASHER, SEALING, 28MM.....    | E-3-31     |
| WASHER, SEALING, 6MM.....     | E-18-10-49 |
| WASHER, SHIFT SHAFT.....      | F-2-33     |
| WASHER, SPRING, 4MM.....      | FOP-12-9   |
| WASHER, SPRING, 5MM.....      | FOP-6-1-19 |
| WASHER, THRUST.....           | E-7-10     |
| WASHER, THRUST.....           | E-9-17     |
| WASHER, THRUST BEARING .....  | F-5-15     |
| WASHER, THRUST, 34MM .....    | F-10-41    |
| WASHER, WAVE, 10MM .....      | F-8-10-27  |
| WASHER, WAVE, 26MM .....      | F-10-40    |
| WASHER, WAVE, 40MM .....      | F-10-39    |
| WHEEL, ACCELERATOR.....       | FOP-8-6-20 |
| WHEEL, CONTROL .....          | FOP-8-6-13 |
| WIRE, LEAD(1.5X116MM).....    | F-11-9     |
| WIRE, LEAD(1.5X137MM).....    | F-3-20-3   |
| WRENCH, EYE, 19MM .....       | F-13-11    |
| WRENCH, HEX., 6MM .....       | F-13-6     |
| WRENCH, PLUG.....             | F-13-5     |
| <Y>                           |            |
| YOKE ASSY.....                | F-11-7     |
| YOKE COMP. ....               | E-21-4     |

# INDEX (Parts Number)

|                              |            |                              |            |                          |            |                          |            |
|------------------------------|------------|------------------------------|------------|--------------------------|------------|--------------------------|------------|
| 332-70201-0 . . . . .        | F-6-8      | HCO-94301-10160 . . . . .    | E-9-20-25  | HMN5-17195-000 . . . . . | F-9-3      | HPNA-90042-003 . . . . . | E-9-29     |
| 3C7-70211-1 . . . . .        | F-6-4      | HCO-94301-12160 . . . . .    | E-10-14    | HMR5-16966-000 . . . . . | E-18-1-19  | HPNA-90703-300 . . . . . | E-9-32     |
| 3C7-70217-0 . . . . .        | F-6-5      | HCO-94301-14200 . . . . .    | E-5-26     | HMT8-18334-770 . . . . . | FOP-6-1-2  | HPNA-90704-000 . . . . . | E-7-16     |
| 3C7-70220-1 . . . . .        | F-6-2      | HCO-94301-14200 . . . . .    | E-6-21     | HMV1-16959-000 . . . . . | E-4-10-2   | HPNA-90715-000 . . . . . | E-3-34     |
| 3C7-70224-1 . . . . .        | F-6-3      | HCO-94301-14200 . . . . .    | E-9-20-26  | HMV5-91005-601 . . . . . | F-5-20     | HPNA-91214-014 . . . . . | E-3-35     |
| 3PU-72537-0 . . . . .        | FOP-2-6    | HCO-94305-25203 . . . . .    | F-10-55    | HMZ5-16952-000 . . . . . | E-18-11    | HPNA-91302-003 . . . . . | E-14-34    |
| 3PV-72571-0 . . . . .        | FOP-2-1    | HCO-94510-14000 . . . . .    | F-5-28     | HP01-91212-003 . . . . . | E-5-21     | HPNA-91302-004 . . . . . | E-9-10-23  |
| 3PV-72637-0 . . . . .        | FOP-2-4    | HCO-94540-03029 . . . . .    | FOP-8-6-77 | HP0X-91321-003 . . . . . | F-2-46     | HPNA-91307-003 . . . . . | E-3-38     |
| 3T1-70200-1 . . . . .        | F-6-1      | HCO-94540-04029 . . . . .    | F-2-49     | HP2A-37881-000 . . . . . | E-15-14    | HPNA-91307-003 . . . . . | E-4-16     |
| 98AB-701600 . . . . .        | F-6-7      | HCO-94540-04029 . . . . .    | FOP-8-6-78 | HP5A-13115-000 . . . . . | E-7-4      | HPNA-91307-003 . . . . . | E-9-10-26  |
| 98AB-70-700 . . . . .        | F-6-6      | HCO-94540-06029 . . . . .    | F-2-50     | HP64-31141-003 . . . . . | E-19-6     | HPNA-91333-003 . . . . . | E-9-10-27  |
| H121-51640-730 . . . . .     | E-14-19    | HCO-94540-06029 . . . . .    | F-8-10-29  | HP8A-13204-A01 . . . . . | E-7-5      | HPNA-91333-003 . . . . . | E-9-20-23  |
| H341-38403-672 . . . . .     | FOP-6-1-12 | HCO-94540-06029 . . . . .    | FOP-8-36   | HPA9-91317-003 . . . . . | E-18-26    | HPNB-37500-003 . . . . . | E-9-10-13  |
| H341-38403-672 . . . . .     | FOP-8-6-45 | HCO-94540-06029 . . . . .    | FOP-8-2-41 | HPC6-15233-000 . . . . . | E-5-7      | HPNB-37510-003 . . . . . | E-9-20-13  |
| H460-89221-840 . . . . .     | F-13-6     | HCO-94540-06029 . . . . .    | FOP-8-4-28 | HPC6-90715-000 . . . . . | E-3-33     | HPNC-91212-004 . . . . . | E-9-10-22  |
| H538-89102-000 . . . . .     | F-13-1     | HCO-94540-07029 . . . . .    | FOP-8-6-79 | HPC6-91324-000 . . . . . | E-6-18     | HPNE-14631-000 . . . . . | E-9-15     |
| H538-89103-000 . . . . .     | F-13-2     | HCO-94540-10019 . . . . .    | F-4-35     | HPCX-12342-004 . . . . . | E-1-3      | HPN4-90009-E01 . . . . . | E-18-10-44 |
| H723-90472-000 . . . . .     | F-4-22     | HCO-94540-12029 . . . . .    | F-2-51     | HPCX-90017-013 . . . . . | E-7-15     | HPPA-13210-000 . . . . . | E-7-6      |
| H750-90628-000 . . . . .     | FOP-13-12  | HCO-94540-15029 . . . . .    | F-11-47    | HPD1-31138-004 . . . . . | E-19-5     | HPPA-13310-000 . . . . . | E-7-8      |
| H759-16911-003 . . . . .     | E-18-9     | HCO-95001-35430-40 . . . . . | E-18-31    | HPD1-31142-004 . . . . . | E-19-7     | HPPA-14520-003 . . . . . | E-9-10     |
| H763-75538-C01 . . . . .     | F-2-26     | HCO-95001-80300-40 . . . . . | F-9-36     | HPD1-31148-004 . . . . . | E-19-11    | HPPA-14530-003 . . . . . | E-9-11     |
| H763-90681-A01 . . . . .     | F-10-49    | HCO-95003-07016-31 . . . . . | E-15-24    | HPD1-90231-014 . . . . . | E-19-30    | HPR3-91319-003 . . . . . | E-3-39     |
| H800-91303-000 . . . . .     | F-9-34     | HCO-95005-12740-20 . . . . . | E-15-25    | HPD6-90430-003 . . . . . | E-18-10-49 | HPRA-11106-013 . . . . . | E-3-3      |
| H805-91301-000 . . . . .     | E-3-36     | HCO-95005-50140-30 . . . . . | F-3-22     | HPE0-15231-000 . . . . . | E-5-5      | HPRA-90401-000 . . . . . | E-3-31     |
| H881-90105-000 . . . . .     | F-4-17     | HCO-95005-50270-30 . . . . . | F-3-22     | HPE0-90703-000 . . . . . | E-3-32     | HPRA-15290-000 . . . . . | E-3-10     |
| H881-90110-000 . . . . .     | F-10-30    | HCO-95005-50950-30 . . . . . | FOP-13-13  | HPER-31145-941 . . . . . | E-19-8     | HPRB-14721-A00 . . . . . | E-9-19     |
| H921-15611-000 . . . . .     | E-3-12     | HCO-95005-70040-30 . . . . . | F-9-37     | HPE9-31152-942 . . . . . | E-19-13    | HPRB-15280-A00 . . . . . | E-3-9      |
| H921-17936-000 . . . . .     | F-2-7      | HCO-95005-70075-30 . . . . . | E-4-10-12  | HPFB-30522-007 . . . . . | E-20-2     | HPSA-36454-003 . . . . . | E-14-16    |
| H921-17936-000 . . . . .     | F-4-1      | HCO-95005-70090-30 . . . . . | E-4-10-13  | HPG6-15232-000 . . . . . | E-5-6      | HPT0-14744-004 . . . . . | E-9-21     |
| H921-90302-000 . . . . .     | F-8-20-17  | HCO-95005-70120-30 . . . . . | E-4-10-14  | HPGK-37835-A01 . . . . . | E-15-12    | HPT0-14775-000 . . . . . | E-9-25     |
| H921-90302-000 . . . . .     | FOP-6-1-16 | HCO-95005-70160-30 . . . . . | F-9-38     | HPH1-90015-013 . . . . . | E-5-16     | HPT0-31147-003 . . . . . | E-19-10    |
| H921-90302-000 . . . . .     | FOP-8-6-53 | HCO-95005-70200-30 . . . . . | F-9-39     | HPH3-90011-000 . . . . . | E-5-15     | HPT0-90206-004 . . . . . | E-9-31     |
| H921-90504-010 . . . . .     | F-8-10     | HCO-95011-62000 . . . . .    | F-8-20-23  | HPJ7-31111-013 . . . . . | E-19-3     | HPT2-91005-N01 . . . . . | F-5-21     |
| H921-90504-010 . . . . .     | FOP-8-6-58 | HCO-95701-06014-08 . . . . . | E-10-15    | HPJ7-31114-013 . . . . . | E-19-4     | HPY3-17249-000 . . . . . | E-15-3     |
| H921-90511-000 . . . . .     | F-10-43    | HCO-95701-06018-09 . . . . . | E-6-22     | HPJ7-31146-003 . . . . . | E-19-9     | HPY3-31215-004 . . . . . | E-21-3     |
| H921-90512-010 . . . . .     | FOP-8-6-59 | HCO-95701-06020-08 . . . . . | E-9-34     | HPJ7-91309-010 . . . . . | F-9-35     | HPY3-31218-004 . . . . . | E-21-6     |
| H921-90518-000 . . . . .     | F-2-37     | HCO-95701-06020-08 . . . . . | E-9-20-27  | HPK1-32742-003 . . . . . | F-7-30-3   | HPZ1-12210-003 . . . . . | E-9-20-4   |
| H921-90518-000 . . . . .     | F-8-10-28  | HCO-95701-06030-08 . . . . . | E-9-35     | HPK2-91307-005 . . . . . | E-9-10-25  | HPZ1-12210-004 . . . . . | E-9-20-4   |
| H921-90518-000 . . . . .     | FOP-8-6-60 | HCO-95701-06032-08 . . . . . | E-9-20-28  | HPKC-37880-004 . . . . . | E-15-13    | HPZ1-12211-003 . . . . . | E-9-20-5   |
| H921-90602-000 . . . . .     | FOP-13-11  | HCO-95701-08032-08 . . . . . | E-5-27     | HPKC-91301-000 . . . . . | E-14-33    | HPZ1-12211-004 . . . . . | E-9-20-5   |
| H952-32901-770 . . . . .     | FOP-6-12   | HCO-95701-08050-08 . . . . . | E-10-16    | HPM3-90206-004 . . . . . | E-9-30     | HPZ1-31105-003 . . . . . | E-19-2     |
| H952-32901-770 . . . . .     | FOP-8-6-37 | HCO-95701-08075-08 . . . . . | E-10-17    | HPNA-11106-300 . . . . . | E-3-2      | HPZ1-31149-003 . . . . . | E-19-12    |
| HCO-92101-04020-4J . . . . . | FOP-12-7   | HCO-95701-08090-08 . . . . . | E-9-20-29  | HPNA-11135-000 . . . . . | E-3-4      | HPZ1-31153-003 . . . . . | E-19-14    |
| HCO-92101-05016-4J . . . . . | FOP-8-6-68 | HCO-95701-08110-08 . . . . . | E-9-20-30  | HPNA-12204-305 . . . . . | E-9-20-2   | HR40-13210-A00 . . . . . | E-7-6      |
| HCO-92101-06050-4J . . . . . | F-3-20     | HCO-95701-10105-08 . . . . . | E-10-18    | HPNA-12205-305 . . . . . | E-9-20-3   | HR40-13210-A00 . . . . . | E-7-8      |
| HCO-93500-05010-4J . . . . . | FOP-8-6-69 | HCO-95701-10110-09 . . . . . | E-6-23     | HPNA-12341-000 . . . . . | E-1-2      | HR40-14401-A01 . . . . . | E-9-7      |
| HCO-93500-05065-4J . . . . . | FOP-8-34   | HCO-95801-08035-09 . . . . . | F-10-56    | HPNA-13111-010 . . . . . | E-7-3      | HR40-14633-A00 . . . . . | E-9-16     |
| HCO-93500-05065-4J . . . . . | FOP-8-2-39 | HCO-96211-07000 . . . . .    | F-5-29     | HPNA-13321-003 . . . . . | E-7-9      | HR40-15115-A01 . . . . . | E-10-8     |
| HCO-93500-06018-4J . . . . . | E-4-18     | HCO-96211-09000 . . . . .    | F-5-30     | HPNA-13322-003 . . . . . | E-7-9      | HRAA-13620-A02 . . . . . | E-7-12     |
| HCO-93500-06025-4J . . . . . | F-10-22    | HCO-96220-50080 . . . . .    | E-5-28     | HPNA-13323-003 . . . . . | E-7-9      | HRAA-14620-A00 . . . . . | E-9-13     |
| HCO-93600-06016-0A . . . . . | E-5-23     | HCO-96300-06025-00 . . . . . | E-10-19    | HPNA-13324-003 . . . . . | E-7-9      | HRAA-14624-A00 . . . . . | E-9-14     |
| HCO-93700-05050-4J . . . . . | F-3-21     | HCO-96300-06032-00 . . . . . | E-10-20    | HPNA-13325-003 . . . . . | E-7-9      | HRAA-14647-A00 . . . . . | E-9-17     |
| HCO-93901-250J0 . . . . .    | FOP-8-6-70 | HCO-9807B-5615P . . . . .    | E-20-4     | HPNA-13326-003 . . . . . | E-7-9      | HRAA-14765-A00 . . . . . | E-9-24     |
| HCO-93901-251J0 . . . . .    | FOP-8-6-71 | HCO-9807B-5615W . . . . .    | E-20-4     | HPNA-13341-003 . . . . . | E-7-11     | HRAA-15815-A02 . . . . . | E-9-20-7   |
| HCO-93901-252J0 . . . . .    | FOP-8-6-72 | HCO-9807B-5617P . . . . .    | E-20-4     | HPNA-13342-003 . . . . . | E-7-11     | HRAA-15845-A01 . . . . . | E-9-20-11  |
| HCO-93903-254G0 . . . . .    | E-13-9     | HCO-9807B-5617W . . . . .    | E-20-4     | HPNA-13343-003 . . . . . | E-7-11     | HRAD-13410-010 . . . . . | E-10-2     |
| HCO-93903-262J0 . . . . .    | FOP-8-6-73 | HCO-98200-41000 . . . . .    | F-7-20-10  | HPNA-13344-003 . . . . . | E-7-11     | HRAD-13420-010 . . . . . | E-10-3     |
| HCO-93905-255J0 . . . . .    | FOP-8-6-74 | HCO-98200-41500 . . . . .    | F-7-20-11  | HPNA-13345-003 . . . . . | E-7-11     | HRBB-13204-004 . . . . . | E-7-5      |
| HCO-93913-142J0 . . . . .    | F-8-13     | HCO-98200-43000 . . . . .    | F-7-20-12  | HPNA-13346-003 . . . . . | E-7-11     | HRGM-14781-A01 . . . . . | E-9-26     |
| HCO-94001-04490-05 . . . . . | FOP-12-8   | HCO-99006-19000 . . . . .    | F-13-11    | HPNA-13432-000 . . . . . | E-10-4     | HRNA-37260-A01 . . . . . | E-3-17     |
| HCO-94001-05490-05 . . . . . | F-2-48     | HCO-99008-02300 . . . . .    | F-13-12    | HPNA-13441-004 . . . . . | E-10-5     | HRNA-37830-A01 . . . . . | E-15-11    |
| HCO-94001-05490-05 . . . . . | FOP-8-35   | HGE1-17357-670 . . . . .     | FOP-13-2   | HPNA-13450-004 . . . . . | E-10-6     | HRAA-30520-007 . . . . . | E-20-1     |
| HCO-94001-05490-05 . . . . . | FOP-8-2-40 | HGEV-90650-003 . . . . .     | E-14-30    | HPNA-13460-004 . . . . . | E-10-7     | HRTA-15400-004 . . . . . | E-5-10     |
| HCO-94001-06080-05 . . . . . | E-19-31    | HGHV-16163-610 . . . . .     | E-18-1     | HPNA-13622-003 . . . . . | E-7-13     | HRWC-14540-A02 . . . . . | E-9-12     |
| HCO-94001-06490-05 . . . . . | FOP-8-6-75 | HGHV-16163-610 . . . . .     | F-9-2      | HPNA-14114-003 . . . . . | E-9-2      | HS0A-91541-003 . . . . . | E-3-40     |
| HCO-94001-06490-05 . . . . . | FOP-9-5    | HHC4-90653-900 . . . . .     | F-8-20-19  | HPNA-14115-000 . . . . . | E-9-3      | HS0A-91541-003 . . . . . | F-7-6      |
| HCO-94001-12490-05 . . . . . | F-10-54    | HMN0-91305-A00 . . . . .     | E-4-15     | HPNA-14210-000 . . . . . | E-9-5      | HS0A-91541-003 . . . . . | F-7-10-16  |
| HCO-94002-05490-05 . . . . . | FOP-8-6-76 | HKJ2-90683-003 . . . . .     | F-8-20-20  | HPNA-14511-003 . . . . . | E-9-9      | HS0A-90683-003 . . . . . | E-18-1-24  |
| HCO-94002-06490-05 . . . . . | F-8-14     | HKM3-32161-003 . . . . .     | F-3-2      | HPNA-14711-000 . . . . . | E-9-18     | HSB2-90687-003 . . . . . | E-14-31    |
| HCO-94103-05400 . . . . .    | FOP-6-1-18 | HKM3-32161-003 . . . . .     | FOP-13-3   | HPNA-14744-004 . . . . . | E-9-20     | HSB2-90687-003 . . . . . | F-7-10-15  |
| HCO-94109-20000 . . . . .    | E-5-24     | HKV7-17368-671 . . . . .     | E-18-13    | HPNA-14762-003 . . . . . | E-9-23     | HSB6-91475-000 . . . . . | FOP-8-6-65 |
| HCO-94109-20000 . . . . .    | E-9-20-24  | HMB0-91359-000 . . . . .     | F-4-33     | HPNA-17055-004 . . . . . | E-14-11    | HSC2-90649-003 . . . . . | FOP-6-1-17 |
| HCO-94111-04500 . . . . .    | FOP-12-9   | HMG9-35701-950 . . . . .     | F-8-10-1   | HPNA-90003-000 . . . . . | E-9-27     | HSDA-39794-004 . . . . . | F-7-20-5   |
| HCO-94111-05400 . . . . .    | FOP-6-1-19 | HMG9-35701-950 . . . . .     | FOP-8-6-40 | HPNA-90004-000 . . . . . | E-10-9     | HSE0-53740-953 . . . . . | E-18-18    |
| HCO-94301-06100 . . . . .    | E-6-19     | HMJ0-91301-003 . . . . .     | E-14-32    | HPNA-90005-003 . . . . . | E-9-20-15  | HSE0-91547-003 . . . . . | E-18-27    |
| HCO-94301-08100 . . . . .    | E-10-13    | HMJ0-91301-003 . . . . .     | E-18-10-51 | HPNA-90006-003 . . . . . | E-3-21     | HSF1-91595-003 . . . . . | E-15-23    |
| HCO-94301-10120 . . . . .    | E-7-17     | HMM4-90105-000 . . . . .     | FOP-8-6-50 | HPNA-90011-003 . . . . . | E-9-20-16  | HSH3-91599-A32 . . . . . | E-18-30    |
| HCO-94301-10160 . . . . .    | E-5-25     | HMM8-90501-610 . . . . .     | F-8-10-25  | HPNA-90031-004 . . . . . | E-10-11    | HSM4-32134-003 . . . . . | F-7-30-2   |
| HCO-94301-10160 . . . . .    | E-6-20     | HMM8-90502-610 . . . . .     | F-8-10-26  | HPNA-90032-000 . . . . . | E-9-28     | HSM4-91558-003 . . . . . | E-18-29    |

|                |                 |                  |                 |                  |                  |                |                 |
|----------------|-----------------|------------------|-----------------|------------------|------------------|----------------|-----------------|
| HSP0-91546-A01 | .....E-9-10-28  | HZV5-40102-000   | .....E-13-4     | HZW1-50201-040ZC | .....F-10-9      | HZW5-06241-U10 | .....FOP-8-2-2  |
| HSP0-91546-A01 | .....E-13-7     | HZV5-40102-000   | .....E-15-15    | HZW1-50214-000   | .....F-10-11     | HZW5-06900-U00 | .....FOP-9-1    |
| HSTK-91540-003 | .....FOP-11-6   | HZV5-41171-000   | .....F-3-10     | HZW1-50301-070ZC | .....F-10-12     | HZW5-15113-000 | .....E-6-3      |
| HSV1-91549-L01 | .....F-2-47     | HZV5-41171-000   | .....FOP-13-5   | HZW1-50311-070ZC | .....F-10-13     | HZW5-15331-003 | .....E-5-8      |
| HSV4-91540-003 | .....E-4-17     | HZV5-41172-000   | .....F-3-11     | HZW1-50527-000   | .....F-10-17     | HZW5-15341-003 | .....E-5-9      |
| HSZ5-91531-003 | .....E-13-6     | HZV5-50214-003   | .....F-11-10    | HZW1-50529-000   | .....F-10-18     | HZW5-16081-010 | .....E-18-10-20 |
| HVD6-91360-003 | .....E-5-22     | HZV5-50522-000   | .....F-10-16    | HZW1-53234-010   | .....F-10-19     | HZW5-16086-000 | .....E-18-10-23 |
| HVM0-16965-771 | .....E-18-12    | HZV5-56117-821   | .....F-11-18    | HZW1-53238-010   | .....F-10-21     | HZW5-16087-000 | .....E-18-10-24 |
| HVM0-16965-771 | .....F-7-30-1   | HZV5-56118-820   | .....F-11-19    | HZW1-56110-701   | .....F-11-13     | HZW5-16708-003 | .....E-18-10-28 |
| HVBM-46391-003 | .....F-2-24     | HZV5-56513-010   | .....F-11-25    | HZW1-56113-701   | .....F-11-14     | HZW5-16715-023 | .....E-18-10-29 |
| HZB5-90626-730 | .....F-8-20-18  | HZV5-90081-010   | .....E-3-26     | HZW1-56115-305   | .....F-11-15     | HZW5-16733-000 | .....E-18-10-34 |
| HZC0-63515-700 | .....F-8-10-21  | HZV5-90081-010   | .....E-5-19     | HZW1-56116-701   | .....F-11-17     | HZW5-16915-000 | .....E-18-10    |
| HZE2-16731-003 | .....E-18-1-1   | HZV5-90119-000   | .....F-3-20-12  | HZW1-56120-305   | .....F-11-20     | HZW5-24810-U01 | .....FOP-8-3    |
| HZE2-90601-000 | .....E-6-17     | HZV5-90119-000   | .....F-11-33    | HZW1-56130-702   | .....F-11-22     | HZW5-24810-U01 | .....FOP-8-2-3  |
| HZH8-87522-W41 | .....F-12-7     | HZV5-90119-000   | .....FOP-13-9   | HZW1-56180-701   | .....F-11-24     | HZW5-24810-U11 | .....FOP-8-2-4  |
| HZV0-90604-000 | .....E-18-24    | HZV5-90125-000   | .....FOP-8-6-52 | HZW1-56516-000   | .....F-10-22     | HZW5-24811-U01 | .....FOP-8-4    |
| HZV0-90604-000 | .....E-18-1-23  | HZV5-90127-003   | .....F-8-20-15  | HZW1-56532-000   | .....F-11-26     | HZW5-24811-U01 | .....FOP-8-2-5  |
| HZV0-90604-000 | .....F-9-30     | HZV5-90127-003   | .....FOP-13-10  | HZW1-56539-000   | .....F-10-23     | HZW5-24812-U01 | .....FOP-8-5    |
| HZV1-24210-010 | .....F-10-2     | HZV5-90131-000   | .....E-6-15     | HZW1-56851-703   | .....F-11-27     | HZW5-24812-U01 | .....FOP-8-2-6  |
| HZV1-90127-010 | .....E-15-20    | HZV5-90302-003   | .....F-2-32     | HZW1-56860-701   | .....F-11-28     | HZW5-24813-U01 | .....FOP-8-6    |
| HZV3-90601-030 | .....E-15-21    | HZV5-90304-013   | .....F-10-34    | HZW1-90013-000   | .....E-13-5      | HZW5-24813-U01 | .....FOP-8-2-7  |
| HZV4-24221-010 | .....F-10-3     | HZV5-90307-003   | .....F-10-38    | HZW1-90013-000   | .....E-15-17     | HZW5-24813-U21 | .....FOP-8-2-8  |
| HZV4-36182-651 | .....FOP-6-1-9  | HZV5-90501-000   | .....F-10-39    | HZW1-90014-000   | .....E-14-20     | HZW5-24814-U01 | .....FOP-8-7    |
| HZV4-36182-651 | .....FOP-8-6-42 | HZV5-90502-000   | .....F-10-40    | HZW1-90014-000   | .....E-18-20     | HZW5-24814-U01 | .....FOP-8-2-9  |
| HZV4-36187-652 | .....FOP-6-1-10 | HZV5-90504-000   | .....F-10-41    | HZW1-90014-000   | .....E-18-10-45  | HZW5-24815-U01 | .....FOP-8-8    |
| HZV4-36187-652 | .....FOP-8-6-43 | HZV5-90552-000   | .....F-10-44    | HZW1-90102-000   | .....F-10-26     | HZW5-24816-U01 | .....FOP-8-9    |
| HZV4-90302-000 | .....F-3-17     | HZV5-90557-000   | .....FOP-8-6-61 | HZW1-90105-000   | .....F-10-27     | HZW5-24816-U01 | .....FOP-8-2-10 |
| HZV4-90304-000 | .....FOP-8-6-54 | HZV5-90559-000   | .....E-6-16     | HZW1-90106-004   | .....E-21-19     | HZW5-24816-U01 | .....FOP-8-4-8  |
| HZV4-90502-000 | .....FOP-8-31   | HZV5-90559-000   | .....F-10-45    | HZW1-90107-004   | .....E-21-20     | HZW5-24817-U01 | .....FOP-8-10   |
| HZV4-90502-000 | .....FOP-8-2-36 | HZV5-90559-000   | .....F-10-46    | HZW1-90108-000   | .....F-10-29     | HZW5-24817-U01 | .....FOP-8-2-11 |
| HZV4-90502-000 | .....FOP-8-6-57 | HZV5-90563-000   | .....F-5-18     | HZW1-90113-702   | .....F-11-29     | HZW5-24818-U01 | .....FOP-8-11   |
| HZV4-90512-000 | .....F-2-36     | HZV5-90563-000   | .....F-10-47    | HZW1-90114-702   | .....F-11-30     | HZW5-24818-U01 | .....FOP-8-2-12 |
| HZV4-90514-000 | .....F-10-42    | HZV5-90651-000   | .....F-10-48    | HZW1-90115-702   | .....F-11-31     | HZW5-24819-U01 | .....FOP-8-12   |
| HZV5-12155-000 | .....E-4-1      | HZV5-90751-000   | .....FOP-8-6-62 | HZW1-90116-702   | .....F-11-32     | HZW5-24819-U01 | .....FOP-8-2-13 |
| HZV5-12214-000 | .....E-3-7      | HZV5-90756-000   | .....F-3-18     | HZW1-90203-000   | .....F-7-10-13   | HZW5-24820-U01 | .....FOP-8-13   |
| HZV5-16881-000 | .....E-18-8     | HZV5-90756-000   | .....F-3-20-17  | HZW1-90242-000   | .....F-4-20      | HZW5-24820-U21 | .....FOP-8-2-14 |
| HZV5-17202-310 | .....F-9-4      | HZV5-90756-000   | .....F-4-25     | HZW1-90301-800   | .....F-5-13      | HZW5-24825-U01 | .....FOP-8-14   |
| HZV5-17838-000 | .....F-2-1      | HZV5-90772-000   | .....FOP-8-6-63 | HZW1-90304-013   | .....F-10-35     | HZW5-24825-U01 | .....FOP-8-2-15 |
| HZV5-24811-010 | .....FOP-8-6-2  | HZV5-91151-000   | .....FOP-8-6-64 | HZW1-90501-710   | .....F-3-20-14   | HZW5-24826-U01 | .....FOP-8-15   |
| HZV5-24812-000 | .....FOP-8-6-3  | HZV5-91203-821   | .....F-11-35    | HZW1-90518-800   | .....F-4-23      | HZW5-24826-U01 | .....FOP-8-2-16 |
| HZV5-24813-000 | .....FOP-8-6-4  | HZV5-91256-003   | .....F-10-51    | HZW1-90519-800   | .....F-4-23      | HZW5-24826-U01 | .....FOP-8-4-10 |
| HZV5-24814-010 | .....FOP-8-6-5  | HZV5-91302-821   | .....F-11-37    | HZW1-90520-800   | .....F-4-23      | HZW5-24831-U01 | .....FOP-8-16   |
| HZV5-24815-010 | .....FOP-8-6-6  | HZV5-91316-821   | .....F-11-38    | HZW1-90521-800   | .....F-4-23      | HZW5-24831-U01 | .....FOP-8-2-17 |
| HZV5-24816-000 | .....FOP-8-6-7  | HZV5-91352-000   | .....F-10-52    | HZW1-90559-000   | .....F-3-20-15   | HZW5-24831-U01 | .....FOP-8-4-12 |
| HZV5-24817-000 | .....FOP-8-6-8  | HZV5-91553-010   | .....E-13-8     | HZW1-90651-710   | .....F-3-20-16   | HZW5-24832-U01 | .....FOP-8-17   |
| HZV5-24818-003 | .....FOP-8-6-9  | HZV5-91553-010   | .....E-15-22    | HZW1-90652-702   | .....F-11-34     | HZW5-24832-U01 | .....FOP-8-2-18 |
| HZV5-24820-010 | .....FOP-8-6-10 | HZV5-91553-010   | .....E-20-10-6  | HZW1-90752-802   | .....F-4-24      | HZW5-24832-U01 | .....FOP-8-4-13 |
| HZV5-24830-010 | .....FOP-8-6-11 | HZV5-91553-010   | .....F-7-10-17  | HZW1-90752-802   | .....FOP-10-4    | HZW5-24834-U01 | .....FOP-8-18   |
| HZV5-24836-000 | .....FOP-8-6-12 | HZV5-91560-000   | .....F-10-53    | HZW1-90752-802   | .....FOP-10-1-9  | HZW5-24834-U21 | .....FOP-8-2-19 |
| HZV5-24841-000 | .....FOP-8-6-13 | HZV5-91567-000   | .....FOP-8-6-66 | HZW1-90758-800   | .....F-5-19      | HZW5-31217-003 | .....E-21-5     |
| HZV5-24845-000 | .....FOP-8-6-14 | HZV5-91570-000   | .....FOP-8-6-67 | HZW1-91054-B31   | .....F-4-27      | HZW5-31631-003 | .....E-19-16    |
| HZV5-24850-000 | .....FOP-8-6-15 | HZV7-90508-000   | .....F-2-35     | HZW1-91101-003   | .....F-5-25      | HZW5-31639-003 | .....E-19-19    |
| HZV5-24854-000 | .....FOP-8-6-16 | HZV7-90951-010   | .....F-10-50    | HZW1-91207-013   | .....F-11-36     | HZW5-31644-003 | .....E-19-20    |
| HZV5-24855-000 | .....FOP-8-6-17 | HZW1-06411-020   | .....F-10-1     | HZW1-91352-702   | .....F-11-39     | HZW5-31710-003 | .....E-19-21    |
| HZV5-24860-000 | .....FOP-8-6-18 | HZW1-12217-010   | .....E-5-1      | HZW1-91353-703   | .....F-11-40     | HZW5-32168-003 | .....E-18-10-43 |
| HZV5-24865-000 | .....FOP-8-6-19 | HZW1-15665-020   | .....F-9-1      | HZW1-91354-701   | .....F-11-41     | HZW5-35370-U02 | .....FOP-8-20   |
| HZV5-24875-000 | .....FOP-8-6-20 | HZW1-19210-B04   | .....F-4-2      | HZW1-91355-701   | .....F-11-42     | HZW5-35370-U02 | .....FOP-8-2-22 |
| HZV5-24876-000 | .....FOP-8-6-21 | HZW1-19210-B04   | .....FOP-10-2   | HZW1-91356-800   | .....F-4-32      | HZW5-35370-U12 | .....FOP-8-2-23 |
| HZV5-24878-000 | .....FOP-8-6-22 | HZW1-19210-B04   | .....FOP-10-1-2 | HZW1-91356-800   | .....FOP-10-5    | HZW5-35673-003 | .....E-9-10-11  |
| HZV5-24881-000 | .....FOP-8-6-23 | HZW1-19223-B00   | .....F-4-4      | HZW1-91356-800   | .....FOP-10-1-10 | HZW5-50151-000 | .....F-10-6     |
| HZV5-24883-000 | .....FOP-8-6-24 | HZW1-19223-B00   | .....FOP-10-1-4 | HZW1-91357-701   | .....F-11-43     | HZW5-50155-000 | .....F-3-20-5   |
| HZV5-24884-000 | .....FOP-8-6-25 | HZW1-19252-000   | .....E-6-6      | HZW1-91358-701   | .....F-11-44     | HZW5-50341-010 | .....F-10-14    |
| HZV5-24885-000 | .....FOP-8-6-26 | HZW1-19253-B01   | .....F-4-8      | HZW1-91361-701   | .....F-11-45     | HZW5-53234-010 | .....F-10-20    |
| HZV5-24887-000 | .....FOP-8-6-27 | HZW1-19253-B01   | .....FOP-10-1-7 | HZW1-91554-000   | .....E-14-35     | HZW5-90002-013 | .....E-5-14     |
| HZV5-24891-000 | .....FOP-8-6-28 | HZW1-19286-800   | .....F-3-1      | HZW1-91554-000   | .....E-18-28     | HZW5-90011-010 | .....E-19-23    |
| HZV5-24892-000 | .....FOP-8-6-29 | HZW1-24102-B00   | .....F-5-2      | HZW1-91554-000   | .....E-18-10-52  | HZW5-90018-000 | .....E-5-18     |
| HZV5-24894-000 | .....FOP-8-6-30 | HZW1-24103-B00   | .....F-5-3      | HZW1-91557-701   | .....F-11-46     | HZW5-90018-000 | .....E-9-20-19  |
| HZV5-24895-000 | .....FOP-8-6-31 | HZW1-24327-000   | .....F-2-11     | HZW2-90003-000   | .....E-20-10-4   | HZW5-90018-000 | .....E-20-10-5  |
| HZV5-24897-000 | .....FOP-8-6-32 | HZW1-31229-004   | .....E-21-8     | HZW2-90301-F00   | .....E-14-29     | HZW5-90018-000 | .....F-7-20-8   |
| HZV5-24898-000 | .....FOP-8-6-33 | HZW1-31247-004   | .....E-21-15    | HZW4-90108-000   | .....FOP-8-6-51  | HZW5-90021-U00 | .....FOP-9-2    |
| HZV5-32823-003 | .....FOP-6-1-5  | HZW1-31249-004   | .....E-21-16    | HZW4-90126-000   | .....E-14-26     | HZW5-90101-000 | .....F-10-25    |
| HZV5-32823-003 | .....FOP-8-6-35 | HZW1-31250-004   | .....E-21-17    | HZW4-90151-000   | .....E-14-27     | HZW5-90101-U00 | .....FOP-8-22   |
| HZV5-32823-003 | .....FOP-11-3   | HZW1-31261-004   | .....E-21-18    | HZW4-90156-000   | .....E-3-28      | HZW5-90101-U00 | .....FOP-8-2-25 |
| HZV5-32824-003 | .....FOP-6-1-6  | HZW1-38551-000   | .....F-7-10-8   | HZW4-90162-000   | .....E-3-29      | HZW5-90101-U00 | .....FOP-8-4-20 |
| HZV5-32824-003 | .....FOP-8-6-36 | HZW1-40107-700   | .....F-8-10-3   | HZW4-90162-000   | .....E-9-10-21   | HZW5-90102-U00 | .....FOP-8-23   |
| HZV5-32824-003 | .....FOP-11-4   | HZW1-40204-000   | .....F-4-12     | HZW4-90163-000   | .....E-19-28     | HZW5-90102-U00 | .....FOP-8-2-26 |
| HZV5-35370-823 | .....FOP-8-6-39 | HZW1-40210-710   | .....F-3-20-2   | HZW4-90164-000   | .....E-21-21     | HZW5-90103-U01 | .....FOP-8-24   |
| HZV5-36104-821 | .....F-11-3     | HZW1-41102-800   | .....F-3-4      | HZW4-90170-000   | .....E-4-11      | HZW5-90103-U01 | .....FOP-8-2-27 |
| HZV5-36136-821 | .....F-11-8     | HZW1-41109-800   | .....F-3-9      | HZW4-90306-003   | .....F-10-37     | HZW5-90104-U00 | .....FOP-8-25   |
| HZV5-36180-033 | .....FOP-6-1-8  | HZW1-41116-B00   | .....F-4-14     | HZW4-90401-000   | .....FOP-8-6-55  | HZW5-90104-U00 | .....FOP-8-2-28 |
| HZV5-36180-033 | .....FOP-8-6-41 | HZW1-50111-010ZC | .....F-3-20-4   | HZW4-90402-000   | .....FOP-8-6-56  | HZW5-90105-U01 | .....FOP-8-26   |
| HZV5-38410-003 | .....FOP-6-1-13 | HZW1-50156-010   | .....F-3-20-6   | HZW4-91301-003   | .....F-3-19      | HZW5-90105-U01 | .....FOP-8-2-29 |
| HZV5-38410-003 | .....FOP-8-6-46 | HZW1-50161-020ZC | .....F-3-20-7   | HZW5-06241-U00   | .....FOP-8-2     | HZW5-90106-U00 | .....FOP-8-27   |

HZW5-90106-U00 . . . . FOP-8-2-30  
HZW5-90107-U00 . . . . FOP-8-28  
HZW5-90107-U00 . . . . FOP-8-2-31  
HZW5-90108-U00 . . . . FOP-8-2-32  
HZW5-90109-000 . . . . FOP-6-1-15  
HZW5-90203-010 . . . . E-19-29  
HZW5-90301-U00 . . . . FOP-8-29  
HZW5-90301-U00 . . . . FOP-8-2-33  
HZW5-90302-003 . . . . F-3-20-13  
HZW5-90302-003 . . . . F-10-33  
HZW5-90302-U21 . . . . FOP-8-2-34  
HZW5-90303-000 . . . . F-4-21  
HZW5-90304-000 . . . . F-10-36  
HZW5-90501-000 . . . . F-2-33  
HZW5-90501-U00 . . . . FOP-8-30  
HZW5-90501-U00 . . . . FOP-8-2-35  
HZW5-90501-U00 . . . . FOP-8-4-26  
HZW5-90502-U00 . . . . FOP-8-32  
HZW5-90502-U00 . . . . FOP-8-2-37  
HZW5-90503-U00 . . . . FOP-8-33  
HZW5-90503-U00 . . . . FOP-8-2-38  
HZW5-90509-711 . . . . F-5-15  
HZW5-90511-U00 . . . . FOP-9-3  
HZW5-90512-U00 . . . . FOP-9-4  
HZW5-90601-030 . . . . E-18-22  
HZW5-90602-030 . . . . E-18-1-22  
HZW5-91056-003 . . . . F-5-24  
HZW5-91201-003 . . . . E-5-20  
HZW5-91202-003 . . . . F-9-33  
HZW5-91251-003 . . . . F-2-44  
HZW7-24810-U01 . . . . FOP-8-4-2  
HZW7-24811-U01 . . . . FOP-8-4-3  
HZW7-24812-U01 . . . . FOP-8-4-4  
HZW7-24813-U01 . . . . FOP-8-4-5  
HZW7-24814-U01 . . . . FOP-8-4-6  
HZW7-24815-U01 . . . . FOP-8-4-7  
HZW7-24817-U01 . . . . FOP-8-4-9  
HZW7-24830-U01 . . . . FOP-8-4-11  
HZW7-24832-U01 . . . . FOP-8-4-14  
HZW7-24833-U01 . . . . FOP-8-4-15  
HZW7-32530-U00 . . . . FOP-8-19  
HZW7-32530-U00 . . . . FOP-8-2-20  
HZW7-32530-U10 . . . . FOP-8-2-21  
HZW7-32530-U20 . . . . FOP-8-4-16  
HZW7-35370-U02 . . . . FOP-8-4-17  
HZW7-87701-U01 . . . . FOP-8-4-18  
HZW7-87703-U00 . . . . FOP-8-4-19  
HZW7-90101-U01 . . . . FOP-8-4-21  
HZW7-90102-U01 . . . . FOP-8-4-22  
HZW7-90103-U01 . . . . FOP-8-4-23  
HZW7-90104-U01 . . . . FOP-8-4-24  
HZW7-90301-U01 . . . . FOP-8-4-25  
HZW7-90502-U00 . . . . FOP-8-4-27  
HZW9-19279-000 . . . . F-9-15  
HZW9-19291-000 . . . . F-9-17  
HZW9-19297-000 . . . . F-9-19  
HZW9-19303-003 . . . . E-9-10-29  
HZW9-19317-000 . . . . F-9-20  
HZW9-32114-730 . . . . E-3-14  
HZW9-87702-800 . . . . FOP-8-6-48  
HZW9-90008-000 . . . . FOP-8-6-49  
HZW9-90009-000 . . . . F-10-24  
HZW9-90011-000 . . . . E-3-22  
HZW9-90011-000 . . . . E-9-10-14  
HZW9-90011-000 . . . . F-7-10-9  
HZW9-90013-000 . . . . F-7-3  
HZW9-90013-000 . . . . F-7-10-10  
HZW9-90013-000 . . . . F-7-20-7  
HZW9-90016-000 . . . . E-3-23  
HZW9-90016-000 . . . . E-5-17  
HZW9-90016-000 . . . . E-18-21  
HZW9-90016-000 . . . . E-18-10-46  
HZW9-90016-000 . . . . F-9-24  
HZW9-90101-003 . . . . F-3-12  
HZW9-90102-000 . . . . E-6-14  
HZW9-90102-000 . . . . F-2-30  
HZW9-90103-010 . . . . F-3-20-9  
HZW9-90105-000 . . . . F-2-31  
HZW9-90105-000 . . . . F-4-18  
HZW9-90105-000 . . . . F-10-28  
HZW9-90154-000 . . . . F-10-32  
HZW9-90506-000 . . . . F-8-10-27  
HXZ1-17110-003 . . . . E-14-14

HZX1-32100-020 . . . . F-7-1  
HXZ1-34750-023 . . . . E-20-10-3  
HXZ1-50100-000 . . . . F-10-5  
HXZ1-63100-R00ZA . . . . F-8-1  
HXZ1-63100-R01ZA . . . . F-8-1  
HXZ1-87121-R00 . . . . F-12-2  
HXZ1-87132-R00 . . . . F-12-3  
HXZ1-87133-R00 . . . . F-12-10  
HXZ1-90101-R00 . . . . F-8-7  
HXZ2-41107-C00ZC . . . . F-3-8  
HXZ2-90129-000 . . . . F-10-31  
HZY1-90205-000 . . . . F-3-16  
HZY1-90650-003 . . . . FOP-11-5  
HZY3-16017-U02 . . . . FOP-1-1  
HZY3-16011-000 . . . . E-18-10-1  
HZY3-16013-000 . . . . E-18-10-2  
HZY3-16024-000 . . . . E-18-10-7  
HZY3-16026-000 . . . . E-18-10-8  
HZY3-16041-000 . . . . E-18-10-10  
HZY3-16042-000 . . . . E-18-10-11  
HZY3-16061-000 . . . . E-18-10-12  
HZY3-16072-000 . . . . E-18-10-13  
HZY3-16073-000 . . . . E-18-10-14  
HZY3-16074-000 . . . . E-18-10-15  
HZY3-16075-000 . . . . E-18-10-17  
HZY3-16076-000 . . . . E-18-10-17  
HZY3-16077-000 . . . . E-18-10-18  
HZY3-16078-000 . . . . E-18-10-19  
HZY3-16082-000 . . . . E-18-10-21  
HZY3-16083-000 . . . . E-18-10-22  
HZY3-16087-000 . . . . E-18-10-25  
HZY3-16088-000 . . . . E-18-10-26  
HZY3-16721-000 . . . . E-18-10-31  
HZY3-16733-000 . . . . E-18-10-35  
HZY3-16752-000 . . . . E-14-8  
HZY3-16752-000 . . . . E-18-10-38  
HZY3-16807-003 . . . . E-18-1-4  
HZY3-16818-003 . . . . E-18-1-5  
HZY3-16900-003 . . . . E-18-1-11  
HZY3-16901-003 . . . . E-18-1-12  
HZY3-16904-003 . . . . E-18-1-13  
HZY3-16911-010 . . . . E-18-10-40  
HZY3-16912-003 . . . . E-18-1-14  
HZY3-16913-000 . . . . E-18-10-41  
HZY3-16915-010 . . . . E-18-1-16  
HZY3-16918-003 . . . . E-18-1-17  
HZY3-16919-003 . . . . E-18-1-18  
HZY3-17748-U01 . . . . FOP-1-2  
HZY3-17749-U01 . . . . FOP-1-3  
HZY3-19270-000 . . . . F-9-11  
HZY3-19271-000 . . . . F-9-12  
HZY3-19272-000 . . . . F-9-13  
HZY3-19300-023 . . . . E-9-10-3  
HZY3-23173-010 . . . . F-9-22  
HZY3-24318-000 . . . . F-4-10  
HZY3-24618-000 . . . . F-2-15  
HZY3-24619-000 . . . . F-2-17  
HZY3-30280-003 . . . . F-11-1  
HZY3-31106-003 . . . . F-11-2  
HZY3-31116-000 . . . . E-5-13  
HZY3-31207-003 . . . . E-21-2  
HZY3-31246-003 . . . . E-21-14  
HZY3-32128-000 . . . . E-15-10  
HZY3-32411-003 . . . . F-7-10-3  
HZY3-35470-023 . . . . F-2-22  
HZY3-35645-000 . . . . F-8-20-3  
HZY3-35673-003 . . . . E-3-16  
HZY3-35673-003 . . . . E-4-7  
HZY3-35673-003 . . . . E-9-10-12  
HZY3-36122-013 . . . . F-11-5  
HZY3-36123-013 . . . . F-11-6  
HZY3-40119-003 . . . . F-8-10-4  
HZY3-40219-013 . . . . F-11-9  
HZY3-50388-U00 . . . . FOP-7-1  
HZY3-50388-U10 . . . . FOP-7-2  
HZY3-56170-013 . . . . F-11-23  
HZY3-58130-T00 . . . . F-5-11  
HZY3-58130-T10 . . . . F-5-11  
HZY3-58130-T20 . . . . F-5-11  
HZY3-58130-T30 . . . . F-5-11  
HZY3-58130-T40 . . . . F-5-11  
HZY3-58130-T50 . . . . F-5-11  
HZY3-58130-V01ZA . . . . F-5-11

HZY3-58130-V11ZA . . . . F-5-11  
HZY3-58130-V21ZA . . . . F-5-11  
HZY3-58130-V31ZA . . . . F-5-11  
HZY3-58130-V41ZA . . . . F-5-11  
HZY3-58130-V51ZA . . . . F-5-11  
HZY3-63107-000 . . . . F-8-3  
HZY3-63108-000 . . . . F-8-4  
HZY3-63119-000 . . . . F-8-5  
HZY3-63201-000ZC . . . . F-8-10-10  
HZY3-63205-000 . . . . F-2-25  
HZY3-63205-000 . . . . F-8-10-11  
HZY3-63208-000 . . . . F-8-10-13  
HZY3-63212-000 . . . . F-8-10-14  
HZY3-63224-000 . . . . F-8-10-17  
HZY3-63260-000 . . . . F-8-10-20  
HZY3-63260-C00 . . . . F-8-10-20  
HZY3-90016-000 . . . . E-9-10-15  
HZY3-90017-000 . . . . E-9-10-16  
HZY3-90017-000 . . . . E-9-20-18  
HZY3-90017-000 . . . . E-18-10-47  
HZY3-90017-000 . . . . E-19-24  
HZY3-90017-000 . . . . F-2-27  
HZY3-90017-000 . . . . F-9-25  
HZY3-90021-000 . . . . E-4-9  
HZY3-90021-000 . . . . E-9-10-17  
HZY3-90021-000 . . . . E-9-20-20  
HZY3-90021-000 . . . . E-14-21  
HZY3-90021-000 . . . . E-18-1-20  
HZY3-90021-000 . . . . F-2-28  
HZY3-90026-000 . . . . E-3-24  
HZY3-90026-000 . . . . E-19-25  
HZY3-90028-000 . . . . F-2-29  
HZY3-90030-000 . . . . E-4-10  
HZY3-90030-000 . . . . F-7-10-11  
HZY3-90030-000 . . . . F-8-10-23  
HZY3-90030-000 . . . . F-9-26  
HZY3-90035-000 . . . . E-19-26  
HZY3-90040-000 . . . . E-9-10-19  
HZY3-90042-000 . . . . E-14-22  
HZY3-90046-000 . . . . E-6-13  
HZY3-90049-000 . . . . E-18-10-48  
HZY3-90054-000 . . . . E-3-25  
HZY3-90054-000 . . . . E-14-25  
HZY3-90055-000 . . . . E-19-27  
HZY3-90056-000 . . . . E-15-19  
HZY3-90056-000 . . . . F-9-28  
HZY3-90084-000 . . . . E-1-5  
HZY3-90084-000 . . . . E-20-3  
HZY3-90107-000 . . . . F-7-10-12  
HZY3-90109-010 . . . . F-8-8  
HZY3-90111-000 . . . . F-8-20-14  
HZY3-90120-000 . . . . F-3-14  
HZY3-90133-000 . . . . F-8-9  
HZY3-90204-000 . . . . E-3-30  
HZY3-90205-000 . . . . E-14-28  
HZY3-90304-000 . . . . F-7-4  
HZY3-90405-000 . . . . F-7-10-14  
HZY3-90506-000 . . . . F-5-14  
HZY3-90507-000 . . . . F-2-34  
HZY3-90507-000 . . . . F-8-11  
HZY3-90512-000 . . . . F-5-16  
HZY3-90528-000 . . . . F-5-17  
HZY3-90529-000 . . . . F-5-17  
HZY3-90530-000 . . . . F-5-17  
HZY3-90531-000 . . . . F-5-17  
HZY3-90601-030 . . . . E-4-10-8  
HZY3-90601-030 . . . . F-9-29  
HZY3-90602-020 . . . . E-4-10-9  
HZY3-90653-003 . . . . F-7-5  
HZY3-90751-000 . . . . F-2-38  
HZY3-91001-003 . . . . F-2-42  
HZY3-91152-003 . . . . F-2-43  
HZY3-91254-003 . . . . F-4-30  
HZY3-91255-003 . . . . F-2-45  
HZY3-91303-000 . . . . E-21-22  
HZY3-91351-003 . . . . F-5-27  
HZY3-91556-000 . . . . F-8-12  
HZY5-14110-000 . . . . E-9-1  
HZY6-06122-010ZA . . . . E-9-20-1  
HZY6-06192-000 . . . . FOP-10-1  
HZY6-06193-A01 . . . . FOP-10-1-1  
HZY6-06411-000 . . . . FOP-13-1  
HZY6-06631-006 . . . . F-8-15

HZY6-11100-405 . . . . E-3-1  
HZY6-11321-010ZB . . . . E-6-1  
HZY6-11381-010 . . . . E-6-2  
HZY6-11410-425ZA . . . . E-9-10-1  
HZY6-11412-000 . . . . E-9-10-2  
HZY6-11911-000 . . . . E-3-5  
HZY6-11912-000 . . . . E-19-1  
HZY6-12000-415ZA . . . . E-3-6  
HZY6-12251-003 . . . . E-9-20-6  
HZY6-12310-010ZA . . . . E-1-1  
HZY6-12500-000 . . . . E-1-4  
HZY6-13010-000 . . . . E-7-1  
HZY6-13101-000 . . . . E-7-2  
HZY6-13102-000 . . . . E-7-2  
HZY6-13211-004 . . . . E-7-7  
HZY6-13212-004 . . . . E-7-7  
HZY6-13213-004 . . . . E-7-7  
HZY6-13214-004 . . . . E-7-7  
HZY6-13215-004 . . . . E-7-7  
HZY6-13216-004 . . . . E-7-7  
HZY6-13217-004 . . . . E-7-7  
HZY6-13331-013 . . . . E-7-10  
HZY6-13400-000 . . . . E-10-1  
HZY6-13811-000 . . . . E-7-14  
HZY6-14120-000 . . . . E-9-4  
HZY6-14311-000 . . . . E-9-6  
HZY6-14510-003 . . . . E-9-8  
HZY6-14751-003 . . . . E-9-22  
HZY6-15100-000ZA . . . . E-5-2  
HZY6-15112-000 . . . . E-5-3  
HZY6-15121-000 . . . . E-5-4  
HZY6-15152-000 . . . . E-3-8  
HZY6-15220-010 . . . . E-6-4  
HZY6-15299-000 . . . . E-3-11  
HZY6-15410-010ZA . . . . E-5-11  
HZY6-15425-010 . . . . E-4-10-1  
HZY6-15655-000 . . . . E-6-5  
HZY6-15834-000 . . . . E-9-20-9  
HZY6-15840-000ZA . . . . E-9-20-10  
HZY6-16014-003 . . . . E-18-10-3  
HZY6-16016-003 . . . . E-15-1  
HZY6-16017-043 . . . . E-18-10-4  
HZY6-16019-003 . . . . E-18-10-5  
HZY6-16020-023 . . . . E-18-10-6  
HZY6-16036-003 . . . . E-18-10-9  
HZY6-16089-000 . . . . E-14-1  
HZY6-16196-000 . . . . E-18-2  
HZY6-16198-000 . . . . E-18-3  
HZY6-16199-000 . . . . E-18-4  
HZY6-16400-013 . . . . E-15-2  
HZY6-16450-003 . . . . E-14-2  
HZY6-16451-000 . . . . E-14-3  
HZY6-16621-000 . . . . E-14-4  
HZY6-16700-013 . . . . E-18-5  
HZY6-16701-003 . . . . E-18-10-27  
HZY6-16718-013 . . . . E-18-10-30  
HZY6-16723-003 . . . . E-18-10-32  
HZY6-16730-063 . . . . E-18-10-33  
HZY6-16734-003 . . . . E-18-10-36  
HZY6-16736-003 . . . . E-18-10-37  
HZY6-16740-003 . . . . E-14-5  
HZY6-16744-010 . . . . E-14-6  
HZY6-16748-000 . . . . E-14-7  
HZY6-16752-000 . . . . E-14-9  
HZY6-16755-003 . . . . E-18-6  
HZY6-16800-003 . . . . E-18-1-2  
HZY6-16805-003 . . . . E-18-1-3  
HZY6-16840-A00 . . . . E-18-10-39  
HZY6-16850-000 . . . . E-18-1-6  
HZY6-16860-000 . . . . E-18-7  
HZY6-16871-000 . . . . E-18-1-7  
HZY6-16880-030 . . . . E-18-1-8  
HZY6-16881-000 . . . . E-18-1-9  
HZY6-16890-000 . . . . E-18-1-10  
HZY6-16914-010 . . . . E-18-1-15  
HZY6-17051-000ZA . . . . E-14-10  
HZY6-17105-000 . . . . E-14-12  
HZY6-17109-000 . . . . E-14-13  
HZY6-17371-020 . . . . E-15-5  
HZY6-17374-000 . . . . E-15-6  
HZY6-17397-013 . . . . E-15-7  
HZY6-17398-000 . . . . E-15-8  
HZY6-17431-000 . . . . E-13-1

|                           |            |                           |            |                          |             |                          |            |
|---------------------------|------------|---------------------------|------------|--------------------------|-------------|--------------------------|------------|
| HZY6-17432-000. . . . .   | E-13-2     | HZY6-32113-000. . . . .   | E-9-10-10  | HZY6-90005-000. . . . .  | E-3-20      | HZZ3-35100-R11 . . . . . | FOP-8-6-38 |
| HZY6-17723-020. . . . .   | E-18-14    | HZY6-32114-010. . . . .   | E-3-15     | HZY6-90006-000. . . . .  | E-15-16     | HZZ3-35340-741. . . . .  | FOP-12-1   |
| HZY6-17840-000. . . . .   | F-2-2      | HZY6-32115-000. . . . .   | E-15-9     | HZY6-90010-000. . . . .  | E-18-19     | HZZ3-35341-740. . . . .  | FOP-12-2   |
| HZY6-17845-000. . . . .   | F-2-3      | HZY6-32116-000. . . . .   | E-9-20-12  | HZY6-90011-000. . . . .  | E-9-20-17   | HZZ3-35342-740. . . . .  | FOP-12-3   |
| HZY6-17860-000. . . . .   | F-2-4      | HZY6-32166-003. . . . .   | E-18-10-42 | HZY6-90013-000. . . . .  | E-4-8       | HZZ3-35343-740. . . . .  | FOP-12-4   |
| HZY6-17877-010. . . . .   | F-2-5      | HZY6-32370-004. . . . .   | F-7-20-1   | HZY6-90014-000. . . . .  | F-9-23      | HZZ3-35344-740. . . . .  | FOP-12-5   |
| HZY6-17931-000. . . . .   | F-2-6      | HZY6-32371-004. . . . .   | F-7-20-2   | HZY6-90017-000. . . . .  | E-6-10      | HZZ3-35345-741. . . . .  | FOP-12-6   |
| HZY6-18110-415ZA. . . . . | E-4-2      | HZY6-32410-020. . . . .   | F-7-10-2   | HZY6-90018-000. . . . .  | E-6-11      | HZZ3-41117-000. . . . .  | F-4-15     |
| HZY6-18112-030ZA. . . . . | E-4-3      | HZY6-32414-300. . . . .   | F-7-2      | HZY6-90019-000. . . . .  | E-6-12      | HZZ3-87301-R00 . . . . . | F-12-4     |
| HZY6-18115-003. . . . .   | E-4-4      | HZY6-32414-300. . . . .   | F-7-10-4   | HZY6-90020-000. . . . .  | E-10-10     | HZZ3-87701-R00 . . . . . | FOP-8-6-47 |
| HZY6-18130-000ZA. . . . . | F-9-5      | HZY6-32414-640. . . . .   | F-7-10-5   | HZY6-90023-000. . . . .  | E-9-10-18   | HZZ3-87703-R01 . . . . . | FOP-8-2-24 |
| HZY6-18135-003. . . . .   | F-9-6      | HZY6-32418-000. . . . .   | F-2-21     | HZY6-90043-000. . . . .  | E-14-23     | HZZ3-87703-R81 . . . . . | FOP-8-21   |
| HZY6-18211-000. . . . .   | F-9-7      | HZY6-32419-000. . . . .   | F-7-10-6   | HZY6-90045-000. . . . .  | F-9-27      | HZZ3-90129-000. . . . .  | F-10-31    |
| HZY6-18212-000. . . . .   | F-9-8      | HZY6-35475-000. . . . .   | F-2-23     | HZY6-90047-000. . . . .  | E-14-24     | HZZ3-91252-003. . . . .  | F-5-26     |
| HZY6-19221-A00 . . . . .  | F-4-3      | HZY6-35640-003. . . . .   | F-8-20-2   | HZY6-90048-010. . . . .  | E-9-20-21   | HZZ3-91253-003. . . . .  | F-4-29     |
| HZY6-19221-A00 . . . . .  | FOP-10-1-3 | HZY6-35660-013. . . . .   | F-10-4     | HZY6-90059-000. . . . .  | E-9-10-20   | HZZ5-06325-600. . . . .  | FOP-6-2    |
| HZY6-19231-000. . . . .   | F-4-5      | HZY6-35668-003. . . . .   | E-4-6      | HZY6-90082-003. . . . .  | E-3-27      | HZZ5-06325-800. . . . .  | FOP-6-2    |
| HZY6-19231-000. . . . .   | FOP-10-1-5 | HZY6-36104-003. . . . .   | FOP-13-4   | HZY6-90103-000. . . . .  | F-3-13      | HZZ5-06325-800. . . . .  | FOP-6-2    |
| HZY6-19234-000. . . . .   | F-4-6      | HZY6-36120-013. . . . .   | F-11-4     | HZY6-90104-000. . . . .  | F-5-12      | HZZ5-32185-600. . . . .  | FOP-6-4    |
| HZY6-19234-000. . . . .   | FOP-10-3   | HZY6-36129-013. . . . .   | F-11-7     | HZY6-90105-000. . . . .  | F-3-20-10   | HZZ5-32185-700. . . . .  | FOP-6-4    |
| HZY6-19234-000. . . . .   | FOP-10-1-6 | HZY6-36135-003. . . . .   | E-18-17    | HZY6-90105-000. . . . .  | F-8-10-24   | HZZ5-32185-800. . . . .  | FOP-6-4    |
| HZY6-19251-000. . . . .   | F-4-7      | HZY6-36550-003. . . . .   | E-14-17    | HZY6-90116-000. . . . .  | F-4-19      | HZZ5-32530-000. . . . .  | FOP-8-6-34 |
| HZY6-19251-611. . . . .   | F-4-7      | HZY6-36551-003. . . . .   | E-14-18    | HZY6-90116-000. . . . .  | FOP-10-1-8  | HZZ5-32545-000. . . . .  | FOP-6-1-4  |
| HZY6-19254-000. . . . .   | E-6-7      | HZY6-37521-000. . . . .   | E-9-20-14  | HZY6-90118-000. . . . .  | F-3-20-11   | HZZ5-32580-600. . . . .  | FOP-6-9    |
| HZY6-19256-000. . . . .   | F-9-9      | HZY6-38228-003. . . . .   | F-7-20-3   | HZY6-90123-000. . . . .  | F-3-15      | HZZ5-32580-700. . . . .  | FOP-6-9    |
| HZY6-19260-020. . . . .   | E-4-10-3   | HZY6-38235-004. . . . .   | F-7-20-4   | HZY6-90135-004. . . . .  | F-7-20-9    | HZZ5-32580-800. . . . .  | FOP-6-9    |
| HZY6-19261-010. . . . .   | E-4-10-4   | HZY6-38550-003. . . . .   | F-7-10-7   | HZY6-90201-000. . . . .  | E-1-6       | HZZ5-37210-013. . . . .  | FOP-8-6-44 |
| HZY6-19262-010. . . . .   | E-4-10-5   | HZY6-38552-000. . . . .   | E-3-18     | HZY6-90301-000. . . . .  | F-8-20-16   | HZZ5-37210-712. . . . .  | FOP-6-1-11 |
| HZY6-19263-000. . . . .   | E-4-10-6   | HZY6-39794-003. . . . .   | F-7-20-6   | HZY6-90401-000. . . . .  | E-1-7       | HZZ5-38414-003. . . . .  | FOP-6-1-14 |
| HZY6-19266-000. . . . .   | E-4-10-7   | HZY6-40105-020. . . . .   | F-8-10-2   | HZY6-90601-000. . . . .  | E-18-23     | HZZ5-50211-000. . . . .  | F-10-10    |
| HZY6-19267-010. . . . .   | F-9-10     | HZY6-40114-010. . . . .   | F-8-20-4   | HZY6-90601-000. . . . .  | E-18-1-21   |                          |            |
| HZY6-19268-000. . . . .   | E-4-5      | HZY6-40116-000. . . . .   | F-8-20-5   | HZY6-90602-020. . . . .  | E-4-10-10   |                          |            |
| HZY6-19269-000. . . . .   | E-18-15    | HZY6-40151-010ZD. . . . . | F-8-20-6   | HZY6-90603-003. . . . .  | E-4-10-11   |                          |            |
| HZY6-19273-000. . . . .   | E-18-16    | HZY6-40152-300. . . . .   | F-8-20-7   | HZY6-90604-003. . . . .  | E-4-12      |                          |            |
| HZY6-19289-000. . . . .   | F-8-20-1   | HZY6-40154-000ZC. . . . . | F-8-10-5   | HZY6-90605-003. . . . .  | E-18-25     |                          |            |
| HZY6-19290-003. . . . .   | F-9-16     | HZY6-40155-000. . . . .   | F-8-10-6   | HZY6-90606-003. . . . .  | F-9-31      |                          |            |
| HZY6-19295-000. . . . .   | F-9-18     | HZY6-40157-000. . . . .   | F-8-10-7   | HZY6-90607-000. . . . .  | E-18-10-50  |                          |            |
| HZY6-19300-003. . . . .   | E-9-10-4   | HZY6-40201-000ZC. . . . . | F-3-20-1   | HZY6-90651-000. . . . .  | F-9-32      |                          |            |
| HZY6-19313-000ZB. . . . . | E-9-10-5   | HZY6-40201-611ZC. . . . . | F-3-20-1   | HZY6-90701-000. . . . .  | E-10-12     |                          |            |
| HZY6-19315-010. . . . .   | E-9-10-6   | HZY6-40212-020ZC. . . . . | F-8-20-8   | HZY6-90752-000. . . . .  | F-2-39      |                          |            |
| HZY6-19318-010. . . . .   | E-9-10-7   | HZY6-40219-023. . . . .   | F-3-20-3   | HZY6-90753-000. . . . .  | F-2-40      |                          |            |
| HZY6-19319-000. . . . .   | E-9-10-8   | HZY6-41100-040ZC. . . . . | F-3-10-1   | HZY6-90755-003. . . . .  | F-2-41      |                          |            |
| HZY6-23170-000ZA. . . . . | F-9-21     | HZY6-41100-614ZC. . . . . | F-3-10-1   | HZY6-91051-003. . . . .  | F-5-22      |                          |            |
| HZY6-23172-000. . . . .   | E-6-8      | HZY6-41101-020ZC. . . . . | F-3-3      | HZY6-91052-003. . . . .  | F-4-26      |                          |            |
| HZY6-24101-000. . . . .   | F-5-1      | HZY6-41104-010. . . . .   | F-3-6      | HZY6-91055-004. . . . .  | F-5-23      |                          |            |
| HZY6-24122-000. . . . .   | F-5-4      | HZY6-41105-010. . . . .   | F-3-7      | HZY6-91251-003. . . . .  | F-4-28      |                          |            |
| HZY6-24123-000. . . . .   | F-5-5      | HZY6-41112-010. . . . .   | F-4-13     | HZY6-91301-003. . . . .  | E-4-13      |                          |            |
| HZY6-24124-000. . . . .   | F-5-6      | HZY6-41112-611. . . . .   | F-4-13     | HZY6-91302-003. . . . .  | E-4-14      |                          |            |
| HZY6-24166-000. . . . .   | F-2-8      | HZY6-41131-000. . . . .   | F-4-16     | HZY6-91303-003. . . . .  | E-9-20-22   |                          |            |
| HZY6-24218-000. . . . .   | F-2-9      | HZY6-41140-000. . . . .   | F-5-7      | HZY6-91304-010. . . . .  | E-9-10-24   |                          |            |
| HZY6-24310-000. . . . .   | F-4-9      | HZY6-41151-000. . . . .   | F-5-8      | HZY6-91305-003. . . . .  | E-3-37      |                          |            |
| HZY6-24320-000. . . . .   | F-2-10     | HZY6-41161-000. . . . .   | F-5-9      | HZY6-91351-003. . . . .  | F-4-31      |                          |            |
| HZY6-24320-610. . . . .   | F-2-10     | HZY6-41173-000. . . . .   | FOP-13-6   | HZY6-91502-003. . . . .  | E-9-33      |                          |            |
| HZY6-24343-000. . . . .   | F-4-11     | HZY6-41201-000ZC. . . . . | F-5-10     | HZY6-91552-000. . . . .  | F-4-34      |                          |            |
| HZY6-24610-000. . . . .   | F-2-12     | HZY6-50167-000. . . . .   | F-10-7     | HZY6-91552-000. . . . .  | FOP-10-1-11 |                          |            |
| HZY6-24612-020. . . . .   | F-2-13     | HZY6-50168-003. . . . .   | F-10-8     | HZY6-91553-000. . . . .  | F-8-20-21   |                          |            |
| HZY6-24614-000. . . . .   | F-2-14     | HZY6-50209-000. . . . .   | FOP-13-7   | HZY9-15815-000. . . . .  | E-9-20-8    |                          |            |
| HZY6-24618-000. . . . .   | F-2-16     | HZY6-56000-043. . . . .   | F-11-11    | HZY9-17315-000. . . . .  | E-15-4      |                          |            |
| HZY6-24620-000. . . . .   | F-2-18     | HZY6-56100-013. . . . .   | F-11-12    | HZY9-30419-003. . . . .  | E-20-10-2   |                          |            |
| HZY6-24628-000. . . . .   | F-2-19     | HZY6-56118-000. . . . .   | FOP-13-8   | HZY9-31207-H01 . . . . . | E-21-2      |                          |            |
| HZY6-24629-000ZA. . . . . | F-2-20     | HZY6-60180-003. . . . .   | F-8-10-8   | HZY9-31226-H01 . . . . . | E-21-19     |                          |            |
| HZY6-30410-000. . . . .   | E-20-10-1  | HZY6-60185-003. . . . .   | F-8-10-9   | HZY9-31229-H01 . . . . . | E-21-8      |                          |            |
| HZY6-30530-003. . . . .   | E-3-13     | HZY6-63102-010. . . . .   | F-8-2      | HZY9-31240-003. . . . .  | E-21-12     |                          |            |
| HZY6-31110-000ZA. . . . . | E-5-12     | HZY6-63144-000. . . . .   | F-8-6      | HZY9-31242-H01 . . . . . | E-21-13     |                          |            |
| HZY6-31200-003. . . . .   | E-21-1     | HZY6-63205-000. . . . .   | F-8-10-12  | HZY9-31246-H01 . . . . . | E-21-14     |                          |            |
| HZY6-31216-003. . . . .   | E-21-4     | HZY6-63212-000. . . . .   | F-8-10-15  | HZY9-31251-H01 . . . . . | E-21-23     |                          |            |
| HZY6-31226-003. . . . .   | E-21-7     | HZY6-63223-000. . . . .   | F-8-10-16  | HZY9-50381-000. . . . .  | F-10-15     |                          |            |
| HZY6-31227-003. . . . .   | E-21-7     | HZY6-63225-000. . . . .   | F-8-10-18  | HZY9-56115-003. . . . .  | F-11-16     |                          |            |
| HZY6-31231-003. . . . .   | E-21-9     | HZY6-63240-000. . . . .   | F-8-10-19  | HZY9-56120-003. . . . .  | F-11-21     |                          |            |
| HZY6-31232-003. . . . .   | E-21-9     | HZY6-63240-010. . . . .   | F-8-10-19  | HZY9-90017-000. . . . .  | E-15-18     |                          |            |
| HZY6-31235-003. . . . .   | E-21-10    | HZY6-63711-010ZC. . . . . | F-8-20-9   | HZZ3-06240-R30 . . . . . | FOP-8-1     |                          |            |
| HZY6-31236-003. . . . .   | E-21-11    | HZY6-63716-010ZC. . . . . | F-8-20-10  | HZZ3-06240-R40 . . . . . | FOP-8-4-1   |                          |            |
| HZY6-31240-003. . . . .   | E-21-12    | HZY6-63718-000. . . . .   | F-8-20-11  | HZZ3-06240-R60 . . . . . | FOP-8-2-1   |                          |            |
| HZY6-31242-003. . . . .   | E-21-13    | HZY6-63719-000. . . . .   | F-8-20-12  | HZZ3-06323-R10 . . . . . | FOP-6-1-1   |                          |            |
| HZY6-31630-003. . . . .   | E-19-15    | HZY6-82873-000. . . . .   | F-8-20-13  | HZZ3-06323-R30 . . . . . | FOP-6-1-1   |                          |            |
| HZY6-31630-013. . . . .   | E-19-15    | HZY6-87117-640. . . . .   | F-12-1     | HZZ3-06328-762. . . . .  | FOP-11-1    |                          |            |
| HZY6-31636-010. . . . .   | E-19-17    | HZY6-87117-U80 . . . . .  | F-12-1     | HZZ3-19277-000. . . . .  | F-9-14      |                          |            |
| HZY6-31637-000. . . . .   | E-19-18    | HZY6-87531-620. . . . .   | F-12-8     | HZZ3-24800-R00 . . . . . | FOP-8-6-1   |                          |            |
| HZY6-31638-003. . . . .   | E-13-3     | HZY6-89216-000. . . . .   | F-13-5     | HZZ3-24800-R50 . . . . . | FOP-8-6-1   |                          |            |
| HZY6-31750-003. . . . .   | E-19-22    | HZY6-90001-000. . . . .   | E-3-19     | HZZ3-32186-000. . . . .  | FOP-11-2    |                          |            |
| HZY6-32101-000. . . . .   | F-7-10-1   | HZY6-90001-000. . . . .   | F-8-10-22  | HZZ3-32346-R11 . . . . . | FOP-6-1-3   |                          |            |
| HZY6-32111-000. . . . .   | E-14-15    | HZY6-90002-000. . . . .   | E-6-9      | HZZ3-32346-R31 . . . . . | FOP-6-1-3   |                          |            |
| HZY6-32112-000. . . . .   | E-9-10-9   | HZY6-90002-000. . . . .   | F-3-20-8   | HZZ3-35100-R11 . . . . . | FOP-6-1-7   |                          |            |

## Note

## Note

## Note



**TOHATSU CORPORATION**

**Address : 5-4,3-chome,Azusawa,Itabashi-ku,  
TOKYO,174-0051 JAPAN**

**Phone : TOKYO (03)3966-3117**

**FAX : TOKYO (03)3966-0090**

**Website : [www.tohatsu.co.jp](http://www.tohatsu.co.jp)**

**2016  
PARTS CATALOG**

**BFT 115A**